

Please do not upload this copyright pdf document to any other website. Breach of copyright may result in a criminal conviction.

This Acrobat document was generated by me, Colin Hinson, from a document held by me. It is presented here (for free) and this pdf version of the document is my copyright in much the same way as a photograph would be. If you believe the document to be under other copyright, please contact me. The Teletype Corporation, originally part of Western Electrics, ceased in 1990, whilst part of AT&T.

The document should have been downloaded from my website <https://blunham.com/Radar>, or any mirror site named on that site. If you downloaded it from elsewhere, please let me know (particularly if you were charged for it). You can contact me via my Genuki email page: <https://www.genuki.org.uk/big/eng/YKS/various?recipient=colin>

You may not copy the file for onward transmission of the data nor attempt to make monetary gain by the use of these files. If you want someone else to have a copy of the file, point them at the website. (<https://blunham.com/Radar>). Please do not point them at the file itself as it may move or the site may be updated.

It should be noted that most of the pages are identifiable as having been processed by me.

I put a lot of time into producing these files which is why you are met with this page when you open the file.

In order to generate this file, I need to scan the pages, split the double pages and remove any edge marks such as punch holes, clean up the pages, set the relevant pages to be all the same size and alignment. I then run Omnipage (OCR) to generate the searchable text and then generate the pdf file.

Hopefully after all that, I end up with a presentable file. If you find missing pages, pages in the wrong order, anything else wrong with the file or simply want to make a comment, please drop me a line (see above).

It is my hope that you find the file of use to you personally – I know that I would have liked to have found some of these files years ago – they would have saved me a lot of time !

Colin Hinson

In the village of Blunham, Bedfordshire.

**BULLETIN 280B
VOL. 2**

**TECHNICAL MANUAL
MODEL 35
AUTOMATIC SEND-RECEIVE
TELETYPEWRITER SET
(ASR)**



**TELETYPE[®]
CORPORATION**

5555 TOUHY AVENUE, SKOKIE, ILLINOIS

280B
Volume 2

INTRODUCTION

Bulletin 280B is a technical manual that provides general and specific technical information about the Model 35 Automatic Send-Receive Teletypewriter Set (ASR) and its component units.

The bulletin is made up of two volumes. Volume 1 contains descriptions and principles of operation, lubrication, and disassembly and reassembly. Volume 2 contains adjustments.

Each volume is made up of a group of appropriate independent sections. The sections are complete within themselves; they are separately identified by title and section number and the pages of each section are numbered consecutively, independent of other sections.

The identifying number of a section, a 9-digit number, appears at the top of each page of the section, in the left corner of the left-hand pages and the right corner of the right-hand pages. The sections are placed in the manual in ascending numerical order.

To locate specific information refer to the table of contents on the following page. Find the name of the involved component in column one and the title of the section in column two. The correct 9-digit section number will then be found in column three. Turn to page one of the section indicated, where the contents of that section will be found (except where a section is small and does not require a listing of contents).

The sections comprising this bulletin are now stocked separately and may be individually ordered if the entire bulletin is not needed.

TABLE OF CONTENTS

FILING INSTRUCTIONS

1. The following filing instructions apply to changes sent to the field.
2. Asterisks (*) in the table of contents indicate changes.
3. When the issue of a section changes, replace the old issue with the attached new one.
4. In the case of addendums, turn to the affected section and follow the instructions on the first page of the attached addendum.
5. Replace the old table of contents with this new one.

<u>Equipment</u>	<u>Title</u>	<u>Section</u>	<u>Issue</u>
Typing Unit (LP)	Adjustments	574-220-700TC	8*
Keyboard (LAK)	Adjustments	574-222-700TC	5*
Transmitter Distributor Base (LCXB)	Adjustments and Lubrication	574-223-700TC	3
Nontyping Reperforator (LRPE)	Adjustments	574-224-700TC	4
Transmitter Distributor (LXD)	Adjustments	574-225-700TC	4*
Cabinet (LAAC)	Adjustments	574-228-700TC	4*
35 Reperforator Bases (LRB)	Adjustments	574-232-703TC	1
Typing Reperforator (LPR)	Adjustments	574-233-700TC	5*
Answer-Back Assembly	Adjustments	574-235-700TC	5

Note: For information on motor units, see Bulletin 295B.

35 TYPING UNIT (LP)

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL.	4	Paper finger latch spring (sprocket feed)	82
2. BASIC UNITS	8	Paper finger shaft spring (sprocket feed)	82
Codebar Mechanism		Paper finger spring (friction feed) . . .	77
Codebar detent.	78	Paper guide (sprocket feed)	87
Codebar detent spring	78	Paper pressure bail spring (friction feed)	77
Codebar shift lever.	23	Paper straightener collar (friction feed)	76
Codebar shift lever drive arm	20	Paper straightener lever spring (friction feed)	76
Codebar yield spring.	78	Platen detent bail spring	68
Common transfer lever spring	21	Platen endplay (sprocket feed)	85
Intermediate arm backstop bracket. . .	22	Pressure roller lever spring (friction feed)	77
Intermediate latch eccentric.	24	Printed line (sprocket feed)	85
Intermediate reset bail eccentric . . .	25	Right margin with automatic carriage return-line feed ring	75
Intermediate reset bail spring	25	Single-double line feed stripper bail assembly springs	74
Intermediate reset lever spring	25	Sprocket pin separation (sprocket feed).	85
Transfer lever eccentric.	21	Sprocket pin spring (sprocket feed). . .	87
Transfer lever spring	21		
Function Mechanism		Main Shaft and Trip Shaft Mechanisms	
Function bar spring	71	Antideflexion plate.	28
Function contact spring	72	Clutch drum position (except selector).	35
Function lever spring	71	Clutch latchlever spring (except selector).	26
Function pawl spring.	71	Clutch shoe lever	34
Function pawl timing contact	72	Clutch shoe lever spring	35
Function reset bail blade	43	Clutch shoe spring	35
Function reset bail spring	43	Clutch trip lever spring.	30
Stripper blade drive cam position . . .	70	Clutch trip shaft set collars	29
Stripper slide bail arm	88	Codebar clutch cam follower spring	27
Stripper slide bail torsion spring . . .	89	Codebar clutch trip lever.	26
Stripper slide spring.	89	Function clutch trip lever	27
Line Feed and Platen Mechanism		Function clutch trip lever trip arm. . .	28
Left margin (sprocket feed)	84	Intermediate lever spring	30
Line feed bar bellcrank spring (friction feed)	68	Line feed clutch trip lever adjusting screw	32
Line feed bar bellcrank spring (sprocket feed).	87	Line feed clutch trip lever eccentric post	32
Line feed bar bumper (six stop clutch only).	69		
Line feed bar release lever spring . . .	68		
Line feed clutch gear phasing	37		
Line feed spur gear detent eccentric. .	68		
Paper finger (friction feed)	77		
Paper finger (sprocket feed).	86		

CONTENTS	PAGE	CONTENTS	PAGE
Spacing clutch trip cam		Printing hammer stop bracket	61
follower spring	31	Printing hammer yield spring.	60
Spacing clutch trip lever	30	Printing track	60
Trip shaft lever spring	26	Print suppression blocking bail	
Typebox clutch trip lever		spring	81
eccentric post	33	Print suppression blocking levers. . .	80
Typebox clutch trip lever trip arm . .	33	Print suppression blocking levers	
		spring	80
Positioning Mechanism		Print suppression mechanism.	80
Bail arm assembly spring	49	Ribbon feed lever bracket	66
Decelerating slide spring.	47	Ribbon feed lever spring	66
Horizontal positioning drive linkage . .	45	Ribbon lever spring	67
Horizontal positioning drive		Ribbon ratchet wheel friction	
linkage spring	45	spring	66
Horizontal positioning locklever		Ribbon reverse detent.	65
spring	38	Ribbon reverse detent lever spring . .	65
Horizontal shift link shock		Ribbon reverse spur gear	65
absorber spring.	47	Ribbon tension spring	67
Horizontal stop slide spring.	76	Stabilizing spring.	54
Left vertical positioning lever		Typebox alignment	64
eccentric stud	40	Typebox carriage roller arm	
Reversing slide adjusting stud	44	spring	54
Reversing slide brackets.	44	Typebox clutch suppression arm. . . .	81
Reversing slide detent spring.	44	Type pallet spring	61
Right vertical positioning lever			
eccentric stud	39	Selector Mechanism	
Rocker shaft bracket eccentric stud . .	38	Marking locklever spring.	17
Rocker shaft left bracket.	37	Pushlever reset bail spring	18
Shift drive pawl guide bracket.	49	Rangefinder knob	8
Shift drive pawl operating bail	48	Selector armature	9
Shift linkage (final).	59	Selector armature downstop (final) . .	15
Shift linkage (preliminary).	46	Selector armature downstop	
Shift linkage spring.	59	(preliminary).	10
Shift pawl selector link yield spring . .	50	Selector armature spring (double	
Shift rocker bail spring.	48	button) (final).	12
Shift rocker bar bearing bracket. . . .	46	Selector armature spring (double	
Shift rocker lever.	48	button) (preliminary).	12
Shift selector arm bellcrank.	50	Selector armature spring (single	
Typebox position (sprocket feed). . . .	83	button)	11
Vertical positioning lever spring. . . .	39	Selector cam lubricator.	22
Vertical positioning locklever.	41	Selector clutch drum.	16
Vertical positioning locklever		Selector clutch latchlever spring. . . .	18
spring	40	Selector clutch stop arm	8
		Selector lever spring	16
Printing Mechanism		Selector magnet bracket	13
Printing arm.	61	Selector magnet bracket (vertical	
Printing carriage lower roller	54	adjustment)	14
Printing carriage position	58	Selector pushlever spring	16
Printing hammer bearing stud	58	Selector receiving margin	17
Printing hammer operating bail		Spacing locklever spring	18
latch spring.	60	Start lever spring.	19
Printing hammer operating bail			
spring	60	Spacing Mechanism	
Printing hammer operating bail		Automatic CR-LF bellcrank spring . .	62
spring (not as illustrated)	60	Carriage draw-wire rope.	52
Printing hammer plunger spring.	60	Carriage return latch bail.	55

CONTENTS	PAGE	CONTENTS	PAGE
Carriage return latch bail spring . . .	55	Tabulator pawl horizontal adjustment .	109
Carriage return lever	56	Tabulator pawl (preliminary)	107
Carriage return spring	53	Tabulator pawl vertical adjustment	
Dashpot vent screw.	57	(final).	108
Left margin.	62	Tabulator stops settings	110
Lower draw-wire rope pulley bail		Keyboard Lock Mechanism	
spring	52	Keyboard locklever spring	114
Margin indicator lamp.	79	Local Backspace Mechanism	
Oscillating rail slide position		Camming bail spring.	115
(friction feed)	51	Camming bail stop arm.	115
Right margin.	63	Lower Solenoid (for Applicable Units)	
Spacing cutout transfer bail spring. . .	63	Lower solenoid	121
Space suppression bypass spring. . . .	63	Solenoid spring	121
Spacing feed pawl release link		Low Paper and Paper Out Alarm	
spring	53	Mechanisms	
Spacing feed pawl spring	51	Low paper and paper out alarm	
Spacing gear clearance	36	(sprocket feed)	99
Spacing gear phasing.	36	Paper out alarm assembly	
Spacing suppression bail spring	73	(friction feed)	101
Spacing trip lever bail cam plate. . . .	42	Paper out alarm bellcrank follower	
Spacing trip lever bail spring.	42	spring (friction feed).	101
Spacing trip lever spring.	42	Paper out alarm sensing lever	
Transfer slide spring	57	spring (sprocket feed).	99
3. VARIABLE FEATURES		Paper Out Alarm Mechanism	
Form-Out Mechanism		(Friction Type) (Later Design)	
Form feed-out nonrepeat slide		Lever.	100
spring	97	Lever spring.	100
Form-out lever backstop.	97	Switch	100
Nonrepeat slide	98	Print-Nonprint Solenoid Mechanism	
Solenoid lever	97	Contact button and solenoid pin	
Horizontal Tabulator Mechanism		alignment	126
Cam plate stripper bail	105	Solenoid contact.	122
Columnar tabulator stops.	110	Solenoid plunger.	122
Horizontal tab blocking lever		Solenoid energized	124
return spring.	108	Solenoid de-energized (suppression	
Horizontal tab intermediate bail		codebar marking).	125
spring	103	Suppression bar return spring (for	
Horizontal tab operating lever cam		units employing the print suppress	
plate spring.	105	solenoid mechanism).	123
Horizontal tab operating lever cam		Timing Contact Mechanism	
plate	104	(Operated by Selector)	
Horizontal tab operating lever		Alignment of operating lever with	
extension link spring.	102	cam.	128
Horizontal tab operating lever link . .	102	"B" contact springs	127
Horizontal tab pawl spring.	108	Contact assembly position	128
Horizontal tab slide arm spring	105	Correction of timing.	130
Horizontal tab spacing trip lever. . . .	104	"M" contact springs	127
Right margin adjustment	106		
Right margin tabulator stop (with			
wide shelf)	110		
Space suppression bypass spring. . . .	106		
Spacing cutout transfer bail set			
collar.	106		

CONTENTS	PAGE
Operating lever spring	128
"S" - "B" contact springs	127
"S" - "M" contact gap	127
Timing verification, 11.00 unit code . .	129
Twin "B" contact springs.	127
Twin springs ("M" contacts).	127
Transmitter Control Contacts (Later Design)	
Contact bracket	119
Normally open contact gap.	119
Switch contact pressure.	119
Transmitter Distributor Transfer Control Contacts	
Contact assembly bracket (final). . . .	111
Contact assembly bracket (preliminary).	111
Normally closed contact spring.	111
Normally open contact gap.	111
Normally open contact spring.	111
Transfer contact spring.	111
Transmitter control contact gap	111
Transmitter Distributor Transfer Control Contacts (Later Design)	
Contact assembly bracket (final). . . .	113
Contact assembly bracket (preliminary).	112
Contact spring.	112
Normally open contact gap.	112
Normally open contact spring.	112
Transfer contact spring.	112
Transmitter control contact gap	113
Two Color Ribbon Mechanism	
Contact activating lever.	131
Contact gap.	132
Contact spring.	132
Ribbon levers	131
Universal Function Bar	
Coding	133/134
Upper Solenoid (for Applicable Units)	
Solenoid spring	120
Upper solenoid.	120
Vertical Tabulator Mechanism	
Blocking lever	117
Blocking lever spring	118
Form-out pawl spring.	96
Form-out stop plate position	117

CONTENTS	PAGE
Form start gear play	116
Function contact spring.	118
Indexing disc	116
Line feed clutch trip lever spring . . .	118
Mounting bracket	116
Pointer.	117
Switch contact pressure.	117
Tabulation stop plate position.	118
Transmitter control switch (single contact type)	118
Vertical tabulator bail spring.	96
Vertical tabulator slide retainer. . . .	116
Vertical Tabulator Mechanism (For Bell System Switched Network Service)	
Blocking arm (form-out)	94
Blocking arm (vertical tab)	94
Form feed-out torsion spring.	96
Form-out pawl spring.	96
Form start gear play	91
Indexing disc	91
Mounting bracket	90
Off normal contact	
Contact bracket	95
Follower lever.	95
Long contact spring	95
Short contact spring	95
Pointer adjustment.	91
Transmitter control switch	
Contact bracket	92
Normally closed contact gap.	93
Normally closed contact spring. . .	93
Normally open contact gap.	92
Normally open contact spring. . . .	92
Transfer contact spring.	92
Vertical tab blocking lever arm . .	92
Vertical tab blocking lever spring .	92
Vertical tabulator bail spring.	96
Vertical tabulator slide retainer. . . .	90

1. GENERAL

1.01 This section contains the specific requirements and adjustments for the 35 typing unit.

1.02 This section has been revised to include recent engineering changes and additions, and to rearrange the text, so as to bring the section generally up-to-date. Since this is a general revision, marginal arrows used to indicate changes have been included.



CAUTION: REMOVE POWER FROM SET OR UNIT BEFORE MAKING ADJUSTMENTS.

1.03 The adjustments in this section are arranged in a sequence that should be followed if a complete readjustment of the unit is undertaken. A complete adjusting procedure should be read before attempting to make the adjustment. After an adjustment is completed, be sure to tighten any nuts or screws that may have been loosened, unless otherwise instructed.

1.04 The adjusting illustrations indicate tolerances, positions of moving parts, spring tensions, and the angle at which scales should be applied. The tools required to make adjustments and check spring tensions are not supplied with the equipment, but are listed in Section 570-005-800TC. Springs which do not meet the requirements, and for which there are no adjusting procedures, should be discarded and replaced by new springs.

1.05 References made to left, right, up, down, front, rear, etc, apply to the unit in its normal operating position as viewed from the front.

1.06 When a requirement calls for a clutch to be disengaged, the clutch shoe lever must be fully latched between its trip lever and latch-lever so that the clutch shoes release their tension on the clutch drum. When engaged, the clutch shoe lever is unlatched and the clutch shoes are wedged firmly against the clutch drum.

Note: When the main shaft is rotated by hand, the clutch does not fully disengage upon reaching its stop position. In order to relieve drag and permit the main shaft to rotate freely, apply pressure on the lug of the clutch disc with a screwdriver to cause it to engage its latch lever and fully disengage the clutch.

1.07 To manually operate the typing unit proceed as follows.

(a) Attach the TP312709 armature clip to the selector magnet armature by carefully placing the spring loop over the magnet terminal insulator. Press down to engage the hook of the clip on the underside of the armature and release. The spring tension of the armature clip will hold the selector armature in the marking (attracted) position.

(b) While holding the selector magnet armature operated by means of the armature clip, use the handwheel, included with the special tools for servicing 28 teletypewriter apparatus, to manually rotate the main shaft in a counterclockwise direction until all the

clutches are brought to their disengaged position.

(c) Fully disengage all clutches in accordance with 1.06, Note.

(d) Release the selector magnet armature momentarily to permit the selector clutch to engage.

(e) Rotate the main shaft slowly until all the pushlevers have fallen to the left of their selecting levers.

(f) Strip the pushlevers from their selector levers, which are spacing in the code combination of the character function that is being selected, and allow the pushlevers to move to the right.

(g) The pushlevers and the selector levers move in succession starting with the no. 1 to the no. 7; the no. 8 is always marking and is not equipped with a selector lever.

(h) Continue to rotate the main shaft until all operations initiated by the selector action clear through the unit.

1.08 Where adjustment instructions call for removal of components, assemblies, subassemblies or parts, all adjustments which the removal of these parts might facilitate should be made before the parts are replaced or as the equipment is reassembled. When a part mounted on shims is removed, the number of shims and their location should be noted so that the identical pile-up can be made when the part is replaced.

1.09 All electrical contact points should meet squarely. Contacts with the same diameter should not be out of alignment more than 25 percent of the contact diameter. Check contacts for pitting and corrosion and clean or bur-nish them before making specified adjustment or tolerance measurement. Avoid sharp kinks or bends in the contact springs.

CAUTION: KEEP ALL ELECTRICAL CONTACTS FREE OF OIL AND GREASE.

1.10 When making a complete adjustment of the unit, the following conditioning operations should be performed to prevent damage.

(a) Loosen the shift lever drive arm clamp screw (2.13).

SECTION 574-220-700TC

- (b) Move the right and left vertical positioning lever eccentric studs (2.32 and 2.33) in rocker shaft brackets to their lowest position.**
- (c) Loosen the two bearing stud mounting screws and the two connecting strip clamp screws in the horizontal positioning drive linkage (2.38).**
- (d) Loosen the clamp screws and move the reversing slide brackets to their uppermost position (2.37).**
- (e) Loosen the function reset bail blade mounting screws (2.36).**
- (f) Loosen the carriage return lever clamp screw (2.49).**
- (g) Loosen the clamp screws in the oscillating rail slide (2.44).**
- (h) Loosen the reversing slide adjusting stud (2.37).**
- (i) Loosen clamp and pivot screws on shift arm bearing bracket and move to extreme downward position (2.39).**
- (j) Loosen the clamp screw on the shift drive pawl operating bail (2.41).**
- (k) Check the following adjustments during each lubricating period.**
 - (1) Printing carriage position (2.51).**
 - (2) Printing hammer bearing stud (2.51).**
 - (3) Printing hammer stop bracket. Also see Note in 2.54.**
 - (4) Lower draw wire rope (2.45).**
 - (5) Dashpot vent screw adjustment and check transfer slide for binds (2.50).**

2. BASIC UNITS

2.01 Selector Mechanism


(A) RANGEFINDER KNOB

Requirement

With rangefinder knob turned to either end of rack, and inner teeth of knob and teeth of sector assembly engaged, ϕ mark on scale should be within ± 3 divisions of scribed line on rangefinder plate.

To Adjust

Loosen knob mounting nut and engage teeth of sector in position that most closely aligns the mark on the plate with the ϕ mark on the knob.



(B) SELECTOR CLUTCH STOP ARM

Requirement


Range scale set at 60. Selector clutch disengaged. Armature in marking position. Clutch stop arm should engage clutch shoe lever by approximately full thickness of clutch stop arm.

To Adjust

Position stop arm on trip lever bail with clamp screw loosened.

2.02 Selector Mechanism (continued)

Note: To facilitate making the following adjustments, remove the rangefinder and selector magnet assemblies. To insure better operation, pull a piece of bond paper between the armature and the pole pieces to remove any oil or foreign matter that may be present. Make certain that no lint or pieces of paper remain between the pole pieces and armature.




Note: This requirement need not be made nor checked if the selector magnet bracket and receiving margin requirements are met.

- (1) Requirement (Armature Clamp Strip)
Clearance between armature clamp strip and casting
Min 0.010 inch

To Adjust
Position armature spring adjusting nut to hold armature firmly against pivot edge of casting.

- (2) Requirement (Armature Alignment)
Outer edge of armature should be flush within Max 0.015 inch with outer edge of pole pieces.



(Front View)

To Adjust
Position armature and backstop with mounting screws loosened.

2.03 Selector Mechanism (continued)


Note: Replace rangefinder and selector magnet assembly.

SELECTOR ARMATURE DOWNSTOP (PRELIMINARY)

Requirement

Magnet de-energized. Locklevers on high part of cam. With armature resting against downstop

Min 0.030 inch---Max 0.035 inch
clearance between end of armature and left
edge of left pole piece.



2.04 Selector Mechanism (continued)

SELECTOR ARMATURE SPRING

(For Units Employing Selector Armature With Single Antifreeze Button Only)

Requirement (Preliminary)

With locklevers and start lever on high part of their cams, scale applied as nearly vertical as possible under end of armature extension. It should require the following tensions to move armature to marking position:


- 0.060 ampere – Min 2-1/2 oz---Max 3 oz
- 0.030 ampere – Min 1-1/2 oz---Max 2 oz
- 0.500 ampere – Min 4-1/2 oz---Max 5-1/2 oz

Note: This spring can be adjusted for maximum selector performance only when printer is connected to the specific circuit over which it is to operate under service conditions. Since there are several operating speeds and since circuits vary widely, it is impossible to adjust spring for maximum performance at the factory. The foregoing spring tension requirement is given to permit operation prior to measurement of receiving margins. Readjustment made to obtain satisfactory receiving margin should not be disturbed in order to meet requirements of this adjustment.

To Adjust
Position adjusting nut.

Requirement (Final)

See SELECTOR RECEIVING MARGIN adjustment (2.10).



(Right Side View)

2.05 Selector Mechanism (continued)

SELECTOR ARMATURE SPRING (PRELIMINARY)


(For Units Employing Selector Armature With Two Antifreeze Buttons Only)

Requirement

With locklevers and start lever on high part of their cams, gram scale applied under end of armature extension, it should require approximately the following tensions to move the rear antifreeze button against the magnet core:

→	}	0.020 ampere	— 14 grams
→		0.030 ampere	— 18 grams
		0.060 ampere	— 21 grams
		0.500 ampere	— 28 grams

To Adjust
Position adjusting nut.




SELECTOR ARMATURE SPRING (FINAL)


Requirement

When a Distortion Test Set is available, the selector armature spring tension should be refined, if necessary, to obtain satisfactory receiving margins. The front antifreeze button must contact the magnet core when the magnet coils are energized.

(See SELECTOR RECEIVING MARGIN adjustment, 2.10.)



2.06 Selector Mechanism (continued)



SELECTOR MAGNET BRACKET

- (1) Requirement (For Units Employing Either One or Two Antifreeze Buttons)
 Spacing locklever on each peak of cam. Armature in contact with front pole piece (magnet energized). Clearance between end of armature extension and shoulder on spacing locklever.
 Min 0.020 inch---Max 0.035 inch

To Adjust
 Loosen two magnet bracket mounting screws and adjusting link clamp screw. Position magnet bracket by means of adjusting link and tighten link clamp screw only.

- (2) Requirement
 Armature in contact with front pole piece (magnet energized). Clearance between upper surface of armature extension and lower surface of spacing locklever when locklever is held downward.
 Min some---Max 0.003 inch


To Adjust
 Position upper end of magnet bracket. Tighten two magnet bracket mounting screws. Recheck Requirement (1).

2.07 Selector Mechanism (continued)

SELECTOR MAGNET BRACKET (VERTICAL ADJUSTMENT)

Requirement (For Units Employing Either One or Two Antifreeze Buttons)

Marking locklever on low of cam. Armature in contact with left pole piece (magnet energized). There should be some clearance between lower surface of armature extension and upper surface of marking locklever. Gauge by eye.



To Adjust
 With mounting screw loosened position upper end of magnet bracket by means of pry point. Recheck Requirements (1) and (2) of SELECTOR MAGNET BRACKET (2.06).

2.08 Selector Mechanism (continued)

SELECTOR ARMATURE DOWNSTOP
(FINAL)


Requirement

Magnet de-energized. Locklevers on low part of their cams


Min 0.005 inch---Max 0.015 inch clearance between top of armature extension and bottom of spacing lock-lever.

To Adjust

Refine SELECTOR ARMATURE DOWNSTOP (PRELIMINARY) (2.03).



2.09 Selector Mechanism (continued)



SELECTOR PUSHLEVER SPRING

Requirement

Pushlever in spacing position
 — Min 3/4 oz --- Max 1-1/2 oz
 to move pushlevers from selector levers on all except first pushlever in sequence of selection. It should require
 — Min 2 oz --- Max 3 oz
 to move this pushlever from its selector lever. This spring is copper color.

SELECTOR LEVER SPRING

Requirement

Typing unit upside down.
 Reset bail on peak of its cam.
 — Min 1-1/2 oz --- Max 3 oz
 to start each lever moving.
 If necessary, unhook start lever spring to check selector lever springs near the start lever spring.


SELECTOR CLUTCH DRUM

Requirement


Clutch latched in stop position. Cam-clutch assembly should have some endplay
 — Max 0.010 inch

To Adjust

Position the clutch drum on main shaft with mounting screw loosened. Tighten screw.



2.10 Selector Mechanism (continued)



MARKING LOCKLEVER

SELECTOR RECEIVING MARGIN

- (1) Requirement (For Units Employing Armature With One Antifreeze Button)
When a signal Distortion Test Set is used for determining the receiving margins of the selector, and where the condition of the components is equivalent to that of new equipment, the range and distortion tolerances below should be met.
- (2) Requirement (For Units Employing Armature With Two Antifreeze Buttons)
When a Distortion Test Set is available, the selector armature spring tension should be refined, if necessary, to obtain satisfactory receiving margins. The front anti-freeze button must contact the magnet core when the magnet coils are energized.


To Adjust

Refine the SELECTOR ARMATURE SPRING adjustments (2.04, 2.05).

Selector Receiving Margin Minimum Requirements


<u>Current</u>	<u>Speed in WPM</u>	<u>Points Range With Zero Distortion</u>	<u>Percentage of Marking and Spacing Bias</u>	<u>End Distortion Tolerated With Scale at Bias Optimum Setting</u>
0.500 Amp (Windings Parallel)	100	72	38	35
0.060 Amp (Windings Parallel) (For LP821 Only)	100	72	35	33

2.11 Selector Mechanism (continued)



PUSHLEVER RESET BAIL SPRING

Requirement
 Pushlever reset bail on low part of cam.
 32 oz scale applied to reset bail.
 — Min 4 oz---Max 8 oz
 to move bail from cam.



SELECTOR CLUTCH LATCHLEVER SPRING

Requirement
 Latch resting on low part of the clutch disc.
 — Min 2 oz---Max 3-1/2 oz
 to start latch moving.

SPACING LOCKLEVER SPRING


Requirement
 Selector armature released. Spacing
 locklever on low part of its cam. Spring
 scale applied to lower end of spacing
 locklever.
 — Min 3 oz---Max 6 oz
 to move spacing locklever from its pivot
 shaft.

2.12 Selector Mechanism (continued)


START LEVER SPRING

Requirement

Latchlever spring unhooked. Stop arm bail in indent of its cam.
 Range scale set at 60.
 Min 2-1/2 oz---Max 4-1/2 oz to start stop arm moving.



2.13 Codebar Mechanism




2.14 Codebar Mechanism (continued)

COMMON TRANSFER LEVER SPRING

Requirement

Transfer lever in spacing position. Scale applied near upper end of common transfer lever.

Min 1/2 oz---Max 1-1/4 oz to start lever moving.



TRANSFER LEVER ECCENTRIC

Requirement



Pushlevers positioned for rubout. Selector clutch disengaged. Codebar shift lever link in uppermost position, clearance between rear codebar shift lever and rear edge of shift bar farthest from rear codebar shift lever
Min 0.010 inch---Max 0.025 inch

Note 1: On units having the intermediate storage mechanism, the clearance between the rear shift lever and the rear edge of the shift bar should be
Min 0.010 inch---Max 0.025 inch when play of shift bar is taken up for maximum clearance.

To Adjust

Rotate eccentric bushing with clamp screw loosened. High part of eccentric should be above horizontal center line.

Note 2: One or more codebar shift bars can touch codebar shift levers.




TRANSFER LEVER SPRING

Requirement

Transfer lever held in spacing position
Min 1-1/2 oz---Max 2-1/2 oz to start intermediate arm moving.

2.15 Codebar and Selector Mechanisms (continued)



(A) INTERMEDIATE ARM BACKSTOP BRACKET

Requirement


Pushlevers not selected. All codebar shift bars to the right. Selector clutch disengaged. Codebar shift lever link in lowermost position. Clearance between front codebar shift lever and the front edge of the inner step of the codebar shift bar farthest from front codebar shift lever

Min 0.010 inch---Max 0.025 inch when play in parts is taken up for maximum clearance.

To Adjust

Position backstop bracket with its two clamp screws loosened.

Note: Number 7 codebar shift bar does not have to meet the maximum requirement until the SHIFT SELECTOR ARM BELLCRANK (2.43) adjustment has been made.



(B) SELECTOR CAM LUBRICATOR

Requirement

The lubricator tube should clear the high part of the locklever cam

Min 0.020 inch

The high part of the selector lever cams should touch the lubricator wick, but should not raise it more than 1/32 inch.

Note: There should be some clearance between the marking locklever spring and the reservoir.

To Adjust

Position the lubricator bracket with its mounting screws loosened.

2.16 Codebar Mechanism (continued)

CODEBAR SHIFT LEVER

Requirement

Motion of front and rear codebar shift levers should be equalized with respect to codebar travel.

(1) To Check (Front)

Select blank combination and rotate main shaft until codebar shift lever link reaches highest travel. Take up play for maximum clearance. Clearance between front codebar shift lever and shoulder on nearest codebar shift bar

Min 0.002 inch---Max 0.025 inch

(2) To Check (Rear)



Select rubout combination. Check clearance between rear codebar shift lever and shoulder on nearest codebar shift bar in same way.

Min 0.002 inch---Max 0.025 inch


Note: The clearance on units containing the intermediate storage mechanism should be
Min 0.002 inch---Max 0.012 inch

To Adjust

Position adjusting plates (front and rear) with clamp screws loosened.



2.17 Codebar Mechanism (continued)



INTERMEDIATE LATCH ECCENTRIC

Note: This adjustment applies to units containing the intermediate storage mechanism.

Requirement

Pushlevers positioned for rubout. Selector clutch disengaged. Clearance between the top of latch surface on the latch and the bottom of the intermediate arm having the least clearance.

Min 0.002 inch---Max 0.006 inch

Check all latches.

To Adjust

Rotate the latch eccentric post to meet the requirement keeping the high part of the eccentric to the front.

2.18 Codebar Mechanism (continued)

(A) INTERMEDIATE RESET LEVER SPRING

Note: This adjustment applies to units containing the intermediate storage mechanism.

Requirement

With the intermediate reset lever in its unoperated position and the spring removed from the lever

Min 1 oz---Max 2 oz _____
to stretch the spring to its installed length. Replace the spring.


(B) INTERMEDIATE RESET BAIL SPRING

Note: This adjustment applies to units containing the intermediate storage mechanism.

Requirement

With all pushlevers in the marking condition and the latches in a latched position, push against the reset bail at the spring hole

Min 5 oz---Max 7 oz _____
to move the latches out of engagement of the intermediate arms.

**(C) INTERMEDIATE RESET BAIL ECCENTRIC**

Note 1: This adjustment applies to units containing the intermediate storage mechanism (for applicable unit).

Requirement

With the intermediate reset lever on the high part of its cam. Clearance between the latch and the intermediate arm should be



Min 0.010 inch _____
with the high part of the eccentric to the rear.

To Adjust

Rotate eccentric to meet requirement.

Note 2: The codebar positioning mechanism is assembled at the factory and at this time the guide bracket is biased to the rear by means of the play in the body holes. If this assembly is removed from the printer, it will be necessary to bias the guide bracket to the rear during reassembly.

2.19 Main Shaft and Trip Shaft Mechanisms



CLUTCH LATCHLEVER SPRING (EXCEPT SELECTOR)

Requirement

Clutch latchlever on high surface of clutch disc

Min 5 oz--- Max 7-1/4 oz

to move latchlever from lug.

This requirement applies to codebar clutch, function clutch, spacing clutch, line feed clutch, and typebox clutch.

CODEBAR CLUTCH TRIP LEVER

Requirement

Selector clutch and codebar clutch disengaged.

Codebar clutch trip lever should engage clutch shoe lever by full thickness of shoe lever and have some endplay

---Max. 0.006 inch

To Adjust

Position trip lever on its shaft with clamp screw loosened.

SELECTOR CLUTCH CAM

TRIP SHAFT LEVER SPRING

TRIP SHAFT LEVER

(Right Side View)

TRIP SHAFT LEVER



TRIP SHAFT LEVER SPRING

Requirement

Trip shaft lever on low part of cam. Codebar clutch engaged. Rotate 1/4 turn.

---Min 1 oz---Max 2 oz to start lever moving.

2.20 Main Shaft and Trip Shaft Mechanisms (continued)



FUNCTION CLUTCH TRIP LEVER
(On Units Equipped With One Piece Trip Lever)

Requirement

Codebar clutch and function clutch disengaged. Function clutch trip lever should engage clutch shoe lever by full thickness of shoe lever. (Check at lug with least bite on two stop clutches.)

To Adjust


Position trip lever on its shaft with clamp screw loosened, letting shaft have endplay
Min some---Max 0.006 inch

CODEBAR CLUTCH CAM FOLLOWER SPRING

Requirement

Cam follower roller on low part of cam. The spring unhooked from spring bracket.

Min 20 oz---Max 24 oz
to pull spring to installed length.



(Left Side View)

2.21 Main Shaft and Trip Shaft Mechanisms (continued)

(A) FUNCTION CLUTCH TRIP LEVER TRIP ARM
(On Units Equipped With Adjustable Backstop)

Requirement

Codebar clutch and function clutch disengaged. Clearance between edge of bail of function clutch trip lever and projection on trip lever trip arm.



Min 0.040 inch---Max 0.050 inch

When making this adjustment, position the trip lever trip arm so that the trip shaft has some endplay

Min some---Max 0.006 inch

To Adjust

Position trip arm on trip shaft with its clamp screw loosened.



(Left Side View, Upside Down)

(B) ANTIDEFLECTION PLATE

Requirement

With typing unit upside down and function, spacing, line feed, and type-box clutches disengaged and latched

Min 1 lb---Max 5 lb

to pull trip shaft away from anti-deflection plate.

To Adjust

Position plate with mounting screws loosened.

2.22 Main Shaft and Trip Shaft Mechanisms (continued)

(A) CLUTCH TRIP SHAFT SET COLLARS

- (1) Requirement
 Spacing cutout lever should have side play
 Min some---Max 0.008 inch


To Adjust
 Position spacing cutout lever set collar.

- (2) Requirement
 Approximate alignment of right end of stop extensions on trip lever and shoe lever.

To Adjust
 Position line feed clutch trip lever set collar.

- (3) Requirement
 Line feed clutch latchlever should have side play
 Min some---Max 0.008 inch

To Adjust
 Position line feed clutch latchlever set collar.



2.23 Main Shaft and Trip Shaft Mechanisms (continued)

SPACING CLUTCH TRIP LEVER

Requirement


Clearance between trip lever and clutch drum should be 0.018 to 0.035 inch less than clearance between shoe lever and drum at stop showing greatest clearance. There should be some overbite on all stop-lugs. Gauge by eye.

To Check

Disengage the clutch. Trip clutch trip lever and slowly rotate main shaft until trip lever is over the shoe lever. Take up play of shoe lever inward by snapping the trip lever over the shoe lever. Check clearance between shoe lever and drum at each stop position. With the trip lever at the stop position which yields greatest clearance, rotate main shaft slowly until the trip lever just falls off the stop-lug. Check clearance between trip lever and drum.

To Adjust

Position the trip lever by means of its clamp screw.



(Right Side View)


CLUTCH TRIP LEVER SPRING

Requirement

Clutch engaged and rotated until trip lever rests on stop-lug

Clutch Function	Min	Max
Spacing	1-1/2 oz	4 oz
Line Feed	11 oz	16 oz
Typebox	10 oz	13 oz
	5 oz	7-1/4 oz

to move lever away from stop-lug.



(Rear View)

INTERMEDIATE LEVER SPRING (On Units Equipped With Three Piece Spacing Clutch Trip Lever Bail)

Requirement

Trip spacing clutch and turn the main shaft so that the spacing clutch stop lever arm is in its unoperated position. Unhook the spring from the intermediate lever bail and pull spring to installed length.


Min 1-1/2 oz---Max 3-1/2 oz

2.24 Main Shaft and Trip Shaft Mechanisms (continued)

SPACING CLUTCH TRIP CAM FOLLOWER SPRING (If Used)**Requirement**

With the function clutch in the stop position, unhook the spring from the spring ear. Hook a scale to the spring loop.

Min 2-1/2 oz---Max 3-1/2 oz _____
to pull the spring to its position length.



(Right Side View)

2.25 Main Shaft and Trip Shaft Mechanisms (continued)

LINE FEED CLUTCH TRIP LEVER ECCENTRIC POST

Requirement

Clearance between trip lever and clutch drum should be:

For 3-stop clutch — 0.018 inch to 0.035 inch

For 6-stop clutch — 0.012 inch to 0.025 inch

less than clearance between shoe lever and drum at stop which shows least clearance.

To Check

Disengage clutch. Trip clutch trip lever and slowly rotate main shaft until trip lever is over shoe lever. Take up play of shoe lever inward by snapping trip lever over shoe lever. Check clearance between shoe lever and drum at each stop position. With trip lever at stop position which yields least clearance, rotate main shaft slowly until trip lever just falls off stop-lug. Check clearance between trip lever and drum.

To Adjust

Back off trip lever adjusting screw and position trip lever eccentric stop post.

LINE FEED CLUTCH TRIP LEVER
ADJUSTING SCREW

(1) Requirement

Clearance between end of trip lever adjusting screw and trip arm

Min some---Max 0.006 inch

To Check

Line feed function slide arm in rear position. Clutch trip lever against its eccentric post. Trip arm held against its function slide arm.

To Adjust


Position adjusting screw.

(2) Requirement

Clearance between line feed trip lever and all line feed clutch shoe levers should be Min 0.004 inch when form-out and vertical tab is selected.

To Adjust

Check and refine if necessary: Requirement (1), FUNCTION RESET BAIL BLADE (2.36), LINE FEED CLUTCH TRIP LEVER ECCENTRIC POST (2.25), MOUNTING BRACKET (3.01).



LINE FEED CLUTCH TRIP LEVER (Right Side View)

2.26 Main Shaft and Trip Shaft Mechanisms (continued)

TYPEBOX CLUTCH TRIP LEVER ECCENTRIC POST


Requirement

Typebox clutch disengaged. Trip lever should engage the clutch shoe lever by the full thickness of the shoe lever.

To Adjust

Position the trip lever eccentric post.

(Right Side View)



TYPEBOX CLUTCH TRIP LEVER TRIP ARM

(1) **Requirement**

Clutch trip shaft cam follower roller (see 2.20) on lowest surface of cam (located on codebar clutch). Clearance between inner face of typebox clutch trip lever and the clutch disc stop-lug. Min 0.025 inch---Max 0.045 inch

To Adjust


Loosen clamp screw and position stop.

(2) **Requirement**

When positioning the trip arm determine that the latchlever has some side play Max 0.008 inch

To Adjust

Position the clutch trip arm on its shaft with the clamp screw loosened.



(Left Side View)

2.27 Main Shaft and Trip Shaft Mechanisms (continued)

CLUTCH SHOE LEVER

Requirement

Gap between clutch shoe lever and its stop-lug should be 0.055 inch to 0.085 inch greater when clutch is engaged than when the clutch is disengaged.


To Check

Disengage the clutch and measure the gap. Trip the clutch and rotate it until the clutch shoe lever is toward the bottom of the unit. Again measure the gap with the clutch thus engaged.

Note 1: On multiple stop clutches check the clearance at the stop-lug that is adjacent to the form in the clutch adjusting disc.

To Adjust

Loosen the two clamp screws on the clutch disc. Engage a wrench or screwdriver on the lug of the adjusting disc and rotate the disc.



(Bottom View)

Note 2: After above adjustment is made, disengage clutch, remove drum mounting screw, and rotate drum in its normal direction of rotation to make certain that it does not drag on shoe. If drum drags, refine above adjustment towards maximum.

2.28 Main Shaft and Trip Shaft Mechanisms (continued)

CLUTCH SHOE LEVER SPRING

Requirement

Clutch engaged. Hold cam disc to prevent turning. Spring scale pulled at tangent to clutch.


One-Stop Clutches:

Min 15 oz---Max 20 oz

Multiple-Stop Clutches:

Min 16 oz---Max 22 oz

to move the shoe lever in contact with the stop-lug.



CLUTCH DRUM POSITION (EXCEPT SELECTOR)


Requirement

Clutch shoe lever held disengaged. Clutch should have some endplay

Max 0.015 inch

To Adjust

Position each drum and spacing clutch set collar with mounting screws loosened.



CLUTCH SHOE SPRING

Note: In order to check this spring, it is necessary to remove the clutch from the main shaft. Therefore, it should not be checked unless there is good reason to believe that it does not meet its requirement.

Requirement

Clutch drum removed. Spring scale applied to primary shoe at a tangent to the friction surface.

Min 3 oz---Max 5 oz

to start the primary shoe moving away from secondary shoe at point of contact.

2.29 Spacing Mechanism

(B) SPACING GEAR PHASING


Requirement

Spacing clutch disengaged. Index line on the spacing pawl should be as near as possible to the center of the two lines on the pawl retaining washer.

To Adjust

Remove the mounting screw from the spacing shaft gear. Hold the pawls in alignment and engage the spacing shaft gear with the clutch gear at a point where the spacing shaft gear mounting screw hole is in line with the tapped hole in the spacing shaft and insert the mounting screw.

RETAINING WASHER



(Front View)

UPPER MOUNTING SCREW

FRONT PLATE

LOWER MOUNTING SCREW

SHIMS

(A) SPACING GEAR CLEARANCE

Requirement

Carriage fully returned. Minimum backlash of spacing gears without bind.

To Adjust

Insert shims between the spacing shaft bearing and front plate at upper mounting screw to increase clearance and at lower mounting mounting screw to decrease clearance.

SPACING SHAFT BEARING


SPACING SHAFT

MOUNTING SCREW

(Bottom View)

SPACING SHAFT GEAR

2.30 Line Feed, Platen Mechanism, and Positioning Mechanism



2.31 Positioning Mechanism

ROCKER SHAFT BRACKET ECCENTRIC STUD

(1) Requirement

Typebox clutch disengaged. Play in locking arm taken up towards front. Gap between lower side of locklever roller and top edge of shoulder on horizontal positioning locklever
Min 0.055 inch---Max 0.090 inch

To Adjust

Position eccentric stud in lower end of rocker shaft left bracket. Keep high part of eccentric (marked with dot) below center line of drive link.


(2) Requirement

Rocker shaft drive link bearing stud should be free to move, parallel to the main shaft, in its typebox clutch bearing when the clutch is in stop position and 180 degree position.

To Adjust

Refine the above to adjust.

Note: Any change in this adjustment after making related adjustments will require a rechecking of the following adjustments: HORIZONTAL POSITIONING DRIVE LINKAGE (2.38), RIGHT VERTICAL POSITIONING LEVER ECCENTRIC STUD (2.32), LEFT VERTICAL POSITIONING LEVER ECCENTRIC STUD (2.33), VERTICAL POSITIONING LOCKLEVER (2.34), RIBBON FEED LEVER BRACKET (2.59), SPACING TRIP LEVER BAIL CAM PLATE (2.35), PRINTING TRACK (2.53), PRINTING ARM (2.54), REVERSING SLIDE BRACKETS (2.37), and RIBBON REVERSE SPUR GEAR (2.58).



2.32 Positioning Mechanism (continued)

RIGHT VERTICAL POSITIONING LEVER ECCENTRIC STUD



Requirement

Typebox clutch disengaged, common codebar in spacing position. Play taken up by pressing downward on common codebar at guide block.

Min 0.030 inch---Max 0.050 inch clearance between the toe of vertical positioning lever and the bottom of the common codebar when play is taken up to make clearance a minimum.

To Adjust

Position the eccentric stud in the right rocker shaft bracket. Position high part of eccentric (marked with dot) toward the rear. (The high part of the eccentric can also be identified by the exposed portion of the flat surface of the vertical positioning link.)



VERTICAL POSITIONING LEVER SPRING


Requirement

Vertical positioning lever toes (right and left) in contact with the suppression codebar, levers not buckled.

Min 4 oz---Max 12 oz to move the link extension away from the vertical positioning lever. Check both right and left springs.

ROCKER SHAFT BRACKET (Right Side View)

2.33 Positioning Mechanism (continued)



VERTICAL POSITIONING LOCK-LEVER SPRING

Requirement
 Typebox clutch disengaged
 Min 5 oz---Max 8 oz
 to start locklever moving.
 Check right and left springs.

COMMON CODEBAR

VERTICAL POSITIONING LEVER TOE

LEFT VERTICAL POSITIONING LEVER ECCENTRIC STUD

Requirement
 Right and left vertical positioning levers should buckle equally within 0.006 inch.

To Check

Common codebar in spacing position. Trip typebox clutch. Rotate main shaft until right vertical positioning lever toe touches common codebar, buckling its lower link approximately 0.008 inch. Left vertical positioning lever toe should touch common codebar, buckling its lower link equally within 0.006 inch.

To Adjust

Position eccentric stud on rocker shaft left bracket inner arm. Position high part of cam (marked with dot) toward rear.


Note: On units containing intermediate storage mechanism, position the eccentric stud in the right rocker shaft bracket. (The high part of the eccentric can also be identified by the exposed portion of the flat surface of the vertical positioning link.)

2.34 Positioning Mechanism (continued)

VERTICAL POSITIONING LOCKLEVER

(1) Requirement

Rubout combination set up on codebars.
Main side operating levers at upper end of travel. Upper notch of vertical positioning locklever fully engaged (manually if necessary) with vertical slide projection. Upper surface of follower arm rear extension should be Min in contact with---Max 0.004 inch away from inner extension of main side lever.



(2) Requirement

With play taken up by pulling upward with 8 oz tension on typebox carriage track, vertical surfaces Min in contact with---Max 0.012 inch away from each other.

To Adjust

Position right and left vertical positioning locklevers with clamp screws loosened.

(Left Side View)

2.35 Spacing Mechanism (continued)

(A) SPACING TRIP LEVER BAIL CAM PLATE


Requirement

Spacing trip lever arm in upward position. Typebox clutch rotated through approximately one-half of its cycle. All function pawls disengaged from function bars. Clearance between top surface of trip lever arm extension and spacing trip lever shoulder

Min 0.010 inch---Max 0.040 inch

To Adjust

Position cam plate on rocker shaft with mounting screws loosened. Position forward edge of cam plate parallel to shaft.



(B) SPACING TRIP LEVER SPRING

Requirement

Typebox clutch disengaged.

Min 2-1/2 oz---Max 5 oz to start lever moving.

(C) SPACING TRIP LEVER BAIL SPRING

Requirement

Spacing trip lever bail against stop. Spacing trip lever bail spring unhooked.

Min 8 oz---Max 12 oz to pull spring to installed length.


2.36 Function Mechanism

(B) FUNCTION RESET BAIL SPRING

Requirement

With typing unit upside down, hold no. 1 codebar in its marking position so that no function bar is selected. Rotate the main shaft until the function reset bail springs are in their minimum length position. Place pull rod of 32 ounce scale between clutch trip shaft and space suppression bail, hook scale on front edge of reset bail (at middle of bail) and pull toward rear.

Min 10 oz---Max 22 oz
to start bail moving.



(A) FUNCTION RESET BAIL BLADE

(1) **Requirement**

Function and typebox clutches disengaged. Function pawls unlatched. Function bar held in maximum rearward position. Clearance between function bar and reset bail blade


Min 0.018 inch---Max 0.035 inch

To Check

Measure clearance at bars located in stunt box slots 1, 4, 11, 18, 23, 33, 38, and 41. If there is no bar in a designated slot, use nearest bar. If there is a bar on each side of a designated vacant slot, use bar in highest numbered slot. (Note: Facing rear of unit, slots are numbered from left to right.)

To Adjust

Position blade on reset bail with its mounting screws friction tight.



(2) **Requirement**

Function pawl should overtravel function bar by
Min 0.002 inch


To Check

If carriage return lever adjustment has not been made, its clamp screw should be loosened. Position function clutch so that lug on clutch disc is toward bottom of unit. Strip off any selected function pawls. Hold function lever in maximum rearward position (do not put over 2 lb of tension on lever) and hold function pawl to rear with a tension of 32 oz. (As load on reset bail affects overtravel, do not latch more than one pawl at a time.) Measure clearance. Repeat for each function pawl on stunt box.

To Adjust

If necessary, refine Requirement (1) within the following limits

Min 0.018 inch---Max 0.035 inch



(Right Side View)


2.37 Positioning Mechanism (continued)

(A) REVERSING SLIDE DETENT SPRING

Requirement

Slide in left hand position. Scale hooked in upper right hand detent notch.

Min 2 oz---Max 4-1/2 oz
to start detent moving.




(B) REVERSING SLIDE ADJUSTING STUD

Requirement

Typebox clutch disengaged. With no. 3 codebar in spacing position (right), the reversing slide detent rollers should be fully seated in the right-hand notches of the detent lever. With no. 3 codebar in marking position (left), the reversing slide detent rollers should be fully seated in the left-hand notches of the detent lever.

To Adjust

Position the reversing slide stud in its elongated hole with its mounting nut loosened.



(C) REVERSING SLIDE BRACKETS

Requirement

Typebox clutch, codebar clutch, and function clutch disengaged. Reversing slide moved to right and left through its full travel. Right motion should buckle left horizontal positioning drive linkage and left motion should buckle right horizontal positioning drive linkage. The amount of buckling in each case should be
Min 0.035 inch---Max 0.050 inch
measured at point of maximum clearance.

To Adjust

Position each reversing slide bracket with its clamp screw loosened.

2.38 Positioning Mechanism (continued)

HORIZONTAL POSITIONING DRIVE LINKAGE

(1) Requirement

Typebox clutch disengaged. Codebars in spacing position. Clearance between longest horizontal stop and positioning linkage slides

Min 0.090 inch---Max 0.110 inch

clearance at two sides should be equal within 0.008 inch, with positioning linkage in straight position. Move reversing slide to right and left to check both sides.

To Adjust

Loosen two screws in drive linkage bearing posts and two screws in bearing posts tie bar. With reversing slide in right hand position, locate right hand bearing post so clearance between longest horizontal stop and right hand positioning lever slide

Min 0.095 inch---Max 0.105 inch

Tighten two screws in bearing posts tie bar. Do not tighten bearing posts mounting screws. Move reversing slide to left hand position, check clearance between longest horizontal stop and left hand positioning lever slide. Equalize clearance at right and left positioning slides within 0.008 inch by moving two bearing posts as a unit.


(2) Requirement

Horizontal positioning mechanism should be free of jams or binds.

To Check

Typebox clutch disc should have some movement in the normal direction of rotation in the stop position.

Note: Each positioning linkage should return freely to its straight position after buckling. Recheck REVERSING SLIDE BRACKETS (2.37).



2.39 Positioning Mechanism (continued)


SHIFT LINKAGE (PRELIMINARY)

Requirement

With codebar and typebox clutches disengaged
 Min 0.030 inch---Max 0.050 inch
 between shift breaker slide and pad on shift link, with link buckled and shift breaker slide pushed upwards against stop. Clearance at two sides equal within 0.010 inch.

To Adjust

Position shift link mounting brackets up or down by means of play in mounting holes.



(Front View)

SHIFT ROCKER BAR BEARING BRACKET

Requirement

Note: Verify SHIFT ROCKER LEVER (2.41) before proceeding with this adjustment.

Codebar and typebox clutches disengaged.
 Clearance between shift rocker bar and lower end of right shift breaker slide

Min 0.050 inch---Max 0.070 inch

Check left side in similar manner.

To Check

Raise left end of shift rocker bar to uppermost position, holding left shift breaker slide against stop. Make sure right shift link is straight, and hold right shift breaker slide against shift link pad.

To Adjust

Position shift rocker bar bearing bracket with clamp screw friction tight.


2.40 Positioning Mechanism (continued)

HORIZONTAL SHIFT LINK SHOCK ABSORBER SPRING

Requirement

Typebox carriage at left side of typing unit. Right hand shift link in straight or unbuckled position.

Min 10 lb---Max 12 lb
to start shock absorber slide moving.




(Front View)

DECELERATING SLIDE SPRING

Requirement

Printing bail in downward position. Printing carriage and decelerating slide assembly in right hand position.

Min 1/2 oz---Max 1-1/2 oz
to start the slide moving. With the printing carriage and decelerating slide in their left hand position, check the left hand decelerating slide spring.



(Front View)

DECELERATING SLIDE

DECELERATING SLIDE SPRING

2.41 Positioning Mechanism (continued)


SHIFT ROCKER LEVER

Requirement

With the codebar bail arm assembly roller on the high part of the cam, make a left and right shift selection. On each shift selection measure the clearance between the raised end of the shift rocker bar and the lower end of the associated shift breaker slide. On the shift selection which yields the smaller clearance, take up the play in an upward direction at the lower end of the shift rocker lever with a force of 2 ounces. The resulting clearance should be equal within 0.010 inch to the clearance between the raised end of the shift rocker bar and the lower end of the associated shift breaker slide when the opposite shift selection is made.

To Adjust

Loosen shift rocker lever clamp screw friction tight and position shift rocker lever. Tighten clamp screw.



(Front View)

SHIFT DRIVE PAWL OPERATING BAIL

Requirement

With shift drive pawl operating bail cam follower on high dwell of cam, clearance between shift rocker bar and lower end of raised shift breaker slide

Min 0.005 inch---Max 0.025 inch
when slide is held against stop. To be held within

Min 0.005 inch---Max 0.035 inch
when the 0.010 inch parallel requirement is held in the SHIFT ROCKER LEVER adjustment.

To Adjust

Position operating bail cam follower arm by means of its clamp screw. Recheck SHIFT ROCKER LEVER adjustment.

SHIFT ROCKER BAIL SPRING (For Applicable Units)

Requirement

Position the shift rocker bail alternately in the letters or figures position. While spring is extended it should require

Min 2 oz---Max 6 oz
to pull spring to its installed length.

2.42 Positioning Mechanism (continued)

SHIFT DRIVE PAWL GUIDE BRACKET


Requirement

Codebar clutch disengaged. Bail arm assembly spring removed. Movement of its bail arm assembly should cause shift drive pawl to move freely in its guide bracket throughout its entire travel. Clearance between shift drive pawl and bottom of slot in guide bracket

Min Some---Max 0.010 inch

To Adjust

Position shift drive pawl guide bracket with clamp screw and clamp nut loosened friction tight. Recheck requirement after guide bracket is tightened.



(Bottom View)

BAIL ARM ASSEMBLY SPRING

Requirement

Drive pawl bail arm assembly on low part of cam. Unhook spring.

Min 6 oz---Max 12 oz _____
to pull spring to installed length.

2.43 Positioning Mechanism (continued)

SHIFT SELECTOR ARM BELLCRANK

Requirement

Shift pushlever in marking position (toward front), selector clutch and codebar clutch disengaged. Shift pawl should clear end of shift drive pawl bearing post.

Min 0.005 inch---Max 0.020 inch


Note: On units containing storage mechanism, shift pushlever in spacing position (toward rear), shift intermediate storage lever marking, selector clutch and codebar clutch disengaged. Shift pawl should clear end of shift drive pawl bearing post.

Min 0.005 inch---Max 0.020 inch

Recheck INTERMEDIATE ARM BACKSTOP BRACKET (2.15). Refine requirement above.

To Adjust

Loosen shift selector arm bellcrank clamp screw friction tight. Position to meet requirement.



SHIFT PAWL SELECTOR LINK YIELD SPRING

Requirement

Shift pushlever in marking position, selector clutch and codebar clutch disengaged

Min 5 oz---Max 7 oz
to pull spring to installed length.

2.44 Spacing Mechanism (continued)

Note: Check related adjustments, (See 2.48, 2.55, and 2.56) if the following adjustments are remade.

OSCILLATING RAIL SLIDE POSITION
FRICTION FEED

Requirement

Right end of oscillating rail slide should clear edge of pulley
Min 0.025 inch---Max 0.050 inch



To Check

Locate spacing cut-out arm and automatic carriage return-line feed arm (if used) in maximum counterclockwise position on spacing drum. Spacing clutch disengaged. Feed pawl which is farthest advanced engaging tooth immediately above cutaway section of ratchet.

To Adjust

Position slide on wire rope with clamp screws loosened.

(See 2.77 for similar type of adjustment for sprocket feed typing unit.)




SPACING FEED PAWL SPRING

Requirement

Each spacing pawl in least advanced position resting against ratchet wheel. Each spring unhooked from bracket

Min 3 oz---Max 5 oz
to pull springs to installed length.

2.45 Spacing Mechanism (continued)



LOWER DRAW-WIRE ROPE PULLEY BAIL SPRING

Requirement

Spring unhooked from pulley bail, bail extension resting on opening in front plate.

Min 26 oz ---Max 30 oz
to pull spring to position length.

CARRIAGE DRAW-WIRE ROPE

Requirement

Clearance between lower draw-wire rope and carriage return latch bail post should be

Min 0.006 inch


With the horizontal positioning mechanism in its lowest position, clearance between the lower draw-wire rope and the left horizontal positioning drive linkage should be

Min 0.030 inch

To Adjust

Advance printing carriage to extreme left hand position. Rotate typebox clutch 1/2 revolution. Loosen rope clamp screw one turn only. Position pulley bearing studs, with their mounting screws loosened, to meet requirement. Check that cable has moved around its equalizing clamp so that cables have equal tension (gauge by feel). Tighten clamp screw. Check related typebox position adjustment (2.77).

2.46 Spacing Mechanism (continued)



(Front View)

CARRIAGE RETURN SPRING

Requirement

Pull required to start drum moving
Min 3-1/2 lb---Max 4-1/4 lb

To Check

Spacing drum in returned position. Printing track in lowest position. Remove lower cable roller and print hammer carriage stabilizer springs. Hold spacing pawls, buffer slide, and carriage return latch to prevent interference with spacing drum.


To Adjust

Spring drum nut loosened. Rotate spring drum ratchet wheel to increase tension. Operate escapement lever to decrease tension.

SPACING FEED PAWL RELEASE LINK SPRING

Requirement

Min 1/2 oz---Max 2-1/2 oz
to start link moving.



(Front View)



2.47 Printing Mechanism


STABILIZING SPRING

Requirement
Typebox clutch disengaged
Min 5 oz ---Max 8 oz
to pull spring to installed
length.

PRINTING CARRIAGE
LOWER ROLLER


Requirement
Carriage vertical play on track
minimum without binding.

To Adjust
Position eccentric of lower roller
with screw nut loosened. Keep
high part of eccentric (chamfered
corner) toward right.



TYPEBOX CARRIAGE
ROLLER ARM SPRING

Requirement
Min 28 oz ---Max 36 oz
to start upper roller, nearest type-
box latch, moving away from carriage
track.



TYPEBOX CARRIAGE ROLLER ARM SPRING

(Rear View)

2.48 Spacing Mechanism (continued)

CARRIAGE RETURN LATCH BAIL


Requirement

Carriage fully returned. Play in carriage return bail taken up to right by holding right side of bail against its retainer. Clearance between carriage return latch bail and carriage return lever

Min 0.004 inch---Max 0.040 inch

To Adjust

Position latch bail plate with clamp screw loosened.




CARRIAGE RETURN LATCH BAIL SPRING

Requirement

Spacing drum fully returned
Min 3 oz---Max 4-1/2 oz
to start latch bail moving.

2.49 Spacing Mechanism (continued)




CARRIAGE RETURN LEVER

Requirement (Units Equipped with One-Stop Function Clutch)

Carriage return function set up on selector. Main shaft rotated until function clutch stop-lug is toward bottom of unit. Carriage return function pawl hooked over its function bar. Spacing drum held so that carriage return latch bail is latched. Clearance between latch bail and carriage return lever
 Min 0.006 inch---Max 0.035 inch


To Adjust

Position carriage return lever on carriage return bail with clamp screw loosened.



CARRIAGE RETURN LEVER

(Front View)



(Right Side View)

2.50 Spacing Mechanism (continued)

DASHPOT VENT SCREW

Requirement


Typebox carriage should return from any length of line without bouncing.

To Check

Printer operated at any speed from automatic transmission with one CR and one LF signal between lines. First character of each line should be printed in same location as if unit was manually operated slowly.

To Adjust

Turn down vent screw until slight pneumatic bounce is perceptible. Back off screw until effect disappears, then back screw off 1/4 turn. Tighten nut.



(Front View)

TRANSFER SLIDE SPRING


Requirement

Transfer slide in extreme left position. Spring unhooked.

Min 3-1/2 oz---Max 4-1/2 oz
to pull spring to installed length.

2.51 Printing Mechanism (continued)

Note: Check related adjustments (2.44, 2.46, and 2.56), if the following adjustments are remade.




Requirement

Combination set up to print an apostrophe. Printing carriage at approximate midpoint of track. Rotate printer shaft so typebox is in printing position. Proper type pallet should be approximately in center of printing hammer

To Adjust

Position printing carriage on wire rope with clamp screw loosened.

Note: Take up play in typebox carriage alternately in each direction. Secure carriage at point where print hammer is approximately center of play.




Requirement

Print hammer in contact with type pallet in top row, eighth from right. The hammer face should be fully on the end of the type pallet.

To Adjust

Add or remove shims between shoulder on bearing post and stop bracket. When checking, take up play in hammer operating bail downward on post.

2.52 Positioning Mechanism (continued)



(A) SHIFT LINKAGE (FINAL)

Requirement


Typebox in position to print eighth character from right in the top row at midpoint of platen. Proper type pallet should align with print hammer.

To Adjust


Position oscillator left hand shift link bracket with two clamp screws loosened. With printer operating alternate characters (& and C), refine adjustment for correct alignment if necessary.

Note: Take up typebox carriage play in both directions and set print hammer to approximate center of play, as gauged by eye.

Do not disturb preliminary adjustment (2.39).



(Front View)



(Front View)

(B) SHIFT LINKAGE SPRING

Requirement

Link in straight position
 Min 6 oz --- Max 14 oz
 to start each link moving.
 Measure both right and left links.

2.53 Printing Mechanism (continued)

(A) PRINTING TRACK


Requirement

Printing track in its extreme downward position. Extreme right hand character selected. Printing hammer operating bail latching extension held with left face in line with the latch shoulder. Printing arm slide positioned alternately over each track mounting screw. Printing bail reset each time. Clearance between latching extension and operating bail latch should be

Min 0.015 inch---Max 0.040 inch

To Adjust

Position the printing track up or down with its mounting screws loosened. Hold clearance to maximum.



(B) PRINTING HAMMER PLUNGER SPRING

Requirement

Min 3 oz---Max 5-3/4 oz to start plunger moving.

(Top View)

(E) PRINTING HAMMER OPERATING BAIL LATCH SPRING (Not as Illustrated)

Requirement

Printing track in its extreme upward position

Min 3 oz---Max 4-1/2 oz to start latch moving.

(C) PRINTING HAMMER OPERATING BAIL SPRING

Requirement

Use notch no. 1 for printing one to three copies, no. 2 for four or five copies, and no. 3 for six or more copies.

To Adjust

Position spring adjusting bracket in required notch.

(F) PRINTING HAMMER OPERATING BAIL SPRING (Not as Illustrated)

Requirement

Operating bail latched. Spring adjusting bracket in left hand (no. 1) notch. Hammer yield spring unhooked

Min 10 oz---Max 13 oz to start bail moving.

(D) PRINTING HAMMER YIELD SPRING

Requirement

Printing hammer operating bail against its stop

Min 1 oz---Max 2-1/2 oz to start hammer bail moving (horizontal position).

2.54 Printing Mechanism (continued)

PRINTING HAMMER STOP BRACKET

Requirement

Printing hammer in upper left typebox position.
 Printing track in its max downward position.
 Printing hammer stop bracket held toward the platen with 8 oz of pressure. Clearance between printing hammer and upper left type pallet
 Min 0.005 inch---Max 0.035 inch
 check at both ends of platen.

Note: Refine this adjustment to 0.005 to 0.015 inch on sprocket feed printer, if necessary to improve copy legibility on multiple forms.

To Adjust

Position stop bracket by means of its two mounting screws.


Note: The printing hammer operating bail spring bracket positions no. 2 and 3 are to be used only for making multiple copies.

TYPE PALLET SPRING

Requirement

Typebox removed from the unit.
 8 oz scale applied vertically to the end of the pallet shank.

Min 1/4 oz---Max 3/4 oz
 to start pallet moving.



(1) Requirement
 Clearance between secondary printing arm and forward extension of hammer operating bail
 Min some---Max 0.015 inch

To Check
 Printing carriage near middle of platen. Printing hammer operating bail spring bracket in no. 1 position. Printing track in max downward position. Printing hammer operating bail against stop.

(2) Requirement
 Clearance between latching extension of printing hammer operating bail and latching surface of operating bail latch
 Min 0.006 inch

To Check
 Printing track in uppermost position. Check both right and left positions.

To Adjust
 Position secondary printing arm with clamp screws loosened.

2.55 Spacing Mechanism (continued)

Note 1: Check related adjustments (2.44, 2.48, and 2.56), if the following adjustments are remade.

Note 2: For sprocket feed units see 2.76 thru 2.83.

LEFT MARGIN

(1) Requirement (72 Character Line)

Typebox clutch disengaged. Spacing drum in returned position. Typebox shifted to left position. Clearance between left edge of platen and left print indicator

Min 15/16 inch---Max 1-1/16 inch


(In Bell System Switched-Network Services
Min 9/16 inch---Max 11/16 inch)

AUTOMATIC CR-LF BELLCRANK SPRING
(For Units So Equipped)

Requirement

Function clutch disengaged.

Min 2-1/2 oz---Max 7 oz
to move the bellcrank.



PLATEN

(Top View)

PRINT INDICATOR

(2) Requirement

Spacing clutch disengaged. Front spacing feed pawl farthest advanced. Spacing drum fully returned. Play in spacing shaft gear (2.29) taken up clockwise. Clearance between pawl and shoulder of ratchet wheel tooth immediately ahead

Min some---Max 0.008 inch

(3) Requirement

Rear pawl, when farthest advanced, should rest at bottom of indentation between ratchet wheel teeth.

To Adjust

Shift typebox to left hand position. Return print carriage to its left position. Loosen four indicated carriage return ring mounting screws. Hold carriage return ring in its counterclockwise position. Locate typebox so its left indicator is in the required position. Tighten the four mounting screws.

FEED PAWLS

AUTOMATIC CR-LF BELLCRANK


MOUNTING SCREWS

CARRIAGE RETURN RING

SPACING DRUM RATCHET WHEEL

(This view shows the spacing drum fully returned.)


(Front View)



Note 3: The left margin may be varied as required. Maximum range of adjustment for mechanisms with standard 10 characters per inch spacing is: friction feed platen 85 characters and sprocket feed platen 74 characters.

2.56 Spacing Mechanism (continued)

Note 1: Check related adjustments (2.36, 2.55, and 2.48), if the following adjustments are remade.

**Requirement**

Typebox clutch disengaged. Carriage in position to print character on which spacing cutout is to occur. Front feed pawl farthest advanced. Spacing cutout transfer bail held in its uppermost position. On units having two piece spacing cutout bail, push the cutout bail towards rear of unit through hole in front plate. Clearance between extension on space suppression ring and transfer bail

Min 0.006 inch---Max 0.025 inch

To Adjust

Position space suppression ring with four indicated mounting screws loosened.

Note 2: Range of adjustment is from 0 to 85 characters on units with ring-type cutout arm. (Printers used in Bell System switched network services should be adjusted to 72 characters.)

Note 3: On units equipped with automatic carriage return-line feed ring, this adjustment is not applicable.

Requirement

Min 1 oz---Max 3-1/2 oz
to start bail moving.

SPACE SUPPRESSION BYPASS SPRING (On Unit Equipped With Separate Cutout Lever and Spring)**Requirement**

With typing unit upside down, hook a scale on the spacing cutout lever extension pawl next to the spring and pull towards the rear of the unit.

Min 20 oz---Max 26 oz
to start the pawl moving.

2.57 Printing Mechanism (continued)

TYPEBOX ALIGNMENT


Requirement

Printed impression of characters at top and at bottom should be equal (gauge visually).

To Adjust

Loosen nut. Operate printer under power. Repeat characters E and Z. Turn adjusting screw in or out (in steps of 1/4 turn) to meet requirement. Tighten nut.

Note: Check and refine PRINTING HAMMER STOP BRACKET (2.54) if necessary.



2.58 Printing Mechanism (continued)

(A) RIBBON REVERSE SPUR GEAR



Requirement

When right reversing lever is in max downward position, the left reversing lever should be in its max upward position.

To Adjust

Loosen the setscrews in the detent cam. Loosen the left spur gear nut. Securely tighten the right spur gear nut. Move the right reversing lever to its max upward position and hold the left reversing lever in its max downward position. Then tighten the left spur gear nut.

Note: Rotate typebox clutch 1/2 turn. Right reversing lever upward. Move right ribbon lever under right ribbon reversing lever. There should be some clearance between levers. Check left side same way. Refine adjustment if necessary.



(B) RIBBON REVERSE DETENT


Requirement

Ribbon reverse detent link buckled in its downward position, clearance between detent link and detent lever

Min some---Max 0.055 inch when play in the lever is taken up lightly toward the right side of the printer.

To Adjust

Hold left ribbon reversing lever in its downward position, position detent link, and tighten the upper setscrew in the hub of the detent link. Buckle the detent link upward and tighten lower setscrew.



(C) RIBBON REVERSE DETENT LEVER SPRING

Requirement

Detent link buckled in upward position
Min 10 oz---Max 18 oz
to start detent lever moving toward rear.

2.59 Printing Mechanism (continued)

RIBBON FEED LEVER BRACKET

(1) Requirement (Left-Hand Mechanism)

Left reversing lever in upward position. Ribbon mechanism in upper position. Ratchet wheel held against the detent lever. Clearance between the front face of the feed lever and the shoulder of a tooth on the ratchet wheel

Min 0.015 inch---Max 0.035 inch


(2) Requirement (Right-Hand Mechanism)

Right reversing lever and ribbon mechanism in upward position. Adjust feed lever bracket in the same manner.

Note 1: Rotate the main shaft. The ratchet wheel should step one tooth only with each operation.

To Adjust

Position the feed lever bracket with its mounting screws loosened.



RIBBON FEED LEVER SPRING

Requirement

Ribbon feed levers in uppermost position. For Long Lever: Push downward near its spring.

For Short Lever: Push downward at point near long lever spring.

Min 3/4 oz---Max 2 oz

to start feed levers moving. Measure all four levers.

Note 2: If minimum requirement of short lever is not met, pull lower end of torsion spring to rear.

RIBBON RATCHET WHEEL FRICTION SPRING

Requirement

Feed levers disengaged.

Min 3 oz---Max 7-1/2 oz


to start the ratchet wheel moving.

2.60 Printing Mechanism (continued)

RIBBON LEVER SPRING

Requirement

Min 1-1/2 oz---Max 3 oz
to start the lever moving. Check both
right and left springs.



RIBBON TENSION SPRING

Requirement

Ribbon ratchet wheel positioned so
that each driving pin is toward the
outside of the spool shaft.

Min 3 oz---Max 5-1/2 oz
to start spool shaft moving.

(Top View)

2.61 Line Feed and Platen Mechanism (continued)

(B) PLATEN DETENT BAIL SPRING

Requirement

Detent seated between two teeth on line feed spur gear.

Min 16 oz---Max 32 oz to start detent bail moving.

(C) LINE FEED BAR RELEASE LEVER SPRING

Requirement

Min 3 oz---Max 8 oz to start lever moving.

HANDWHEEL

LINE FEED BAR RELEASE LEVER

(A) LINE FEED SPUR GEAR DETENT ECCENTRIC

Requirement

Line feed clutch disengaged. Platen rotated until detent stud is seated between two teeth on line feed spur gear. When hand wheel is released, manually set the teeth on the line feed bars into engagement with the teeth on the line feed spur gear. The detent stud should contact one gear tooth and be not more than 0.010 inch from other tooth.

To Adjust


Rotate the detent eccentric with its mounting screw loosened. Keep high part of eccentric upward.

(D) LINE FEED BAR BELLCRANK SPRING (FRICTION FEED)

Requirement


Left-hand line feed bar in rear position

Min 19 oz---Max 24 oz to start bar moving.



(Rear Right View)

2.62 Line Feed and Platen Mechanism (continued)

LINE FEED BAR BUMPER (SIX STOP CLUTCH ONLY)**Requirement**

With the line feed clutch tripped manually, rotate the main shaft until the line feed bar adjacent to side frame is at its maximum travel away from the line feed spur.

Min 0.065 inch---Max 0.080 inch _____
clearance between the other line feed bar and the line feed bar bumper.

To Adjust

Loosen the two bracket mounting nuts and position the bracket thru its elongated slots until proper clearance is obtained. Then tighten the two mounting nuts.

Note: Recheck vertical tab or form-out adjustment (variable features).

2.63 Function Mechanism (continued)

STRIPPER BLADE DRIVE CAM POSITION

Requirement

Stripper blade drive cam should move each stripper blade cam arm on equal distance above and below center line of its pivot (gauge by eye).


- (a) Upward direction
- (b) Downward direction

To Check

With function clutch disengaged observe engagement of stripper blade drive cam (upper peak) with stripper blade cam arm. Then rotate clutch to turn cam to its extreme downward position and observe engagement of lower cam peak.

To Adjust

With stripper blade drive arm mounting screws loosened. Equalize the overtravel of each cam peak.



(Rear View)

2.64 Function Mechanism (continued)

(A) FUNCTION LEVER SPRING

Note: If a function lever operates a contact or a slide, hold off the contact or slide when checking the spring.

Requirement

Function lever in unoperated position. Suppression bail held forward.


Min 1-1/2 oz---Max 2-3/4 oz to start function lever moving. Check each spring.

(B) FUNCTION PAWL SPRING

Requirement


Rear end of function pawl resting on function bar

Min 3 oz---Max 5 oz to start pawl moving. Check each spring.



CAUTION: SEVERE WEAR TO THE POINT OF OPERATION FAILURE WILL RESULT IF THE TELETYPEWRITER IS OPERATED WITHOUT EACH FUNCTION PAWL HAVING EITHER A RELATED FUNCTION BAR OR, WHERE A FUNCTION BAR IS MISSING, A RELATED FUNCTION PAWL CLIP TO HOLD THE FUNCTION PAWL AWAY FROM THE STRIPPER BLADE.

2.65 Function Mechanism (continued)



FUNCTION PAWL TIMING CONTACT

Note 1: This adjustment applies to the ATX stunt box arrangement slot 32.



Requirement

With the function pawl in the nonselect position (contact resting on adjusting stud of function pawl), clearance between the contact arm and the near contact should be

Min 0.005 inch---Max 0.015 inch

To Adjust

Position adjusting stud by means of its mounting screw.




(Rear View)

Note 2: If the switches are removed from the stunt box, the following requirements apply.

Provide at least 0.006 inch clearance between the contact arm and the vertical portion of the contact clip. If the switch has contacts front and rear, this clearance applies to both front and rear. To obtain this clearance, position the contact plate before tightening the contact plate screws.

On switches with contacts front and rear, check to see that there is a gap of not less than 0.008 inch between the formed-over end of the front contact clip and the bottom of the contact arm when the rear contact is closed.

2.66 Spacing Mechanism (continued)




SPACING SUPPRESSION BAIL SPRING

Requirement

Spacing suppression bail in rear position. Scale applied near center of horizontal portion of bail.

Min 1/2 oz---Max 1-1/2 oz
to start bail moving.

2.67 Line Feed and Platen Mechanism (continued)



2.68 Line Feed and Platen Mechanism (continued)

RIGHT MARGIN WITH AUTOMATIC CARRIAGE RETURN-LINE FEED RING

Requirement (On Units So Equipped)


Typebox clutch disengaged. Carriage positioned two spaces before character on which automatic carriage return-line feed is to occur. Front feed pawl farthest advanced. Clearance between extension on ring and automatic carriage return-line feed bellcrank

Min 0.040 inch---Max 0.055 inch


To Adjust

Position ring with four indicated mounting screws loosened.


Note: Range of line adjustment is from 0 to 85 characters.



2.69 Positioning Mechanism (continued)




2.70 Line Feed and Platen Mechanism (continued)



To Adjust
Position collars on shaft with setscrews loosened.

Note: For sprocket feed mechanism, see 2.76.

2.71 Line Feed and Platen Mechanism (continued)



PAPER FINGER (FRICTION FEED)

Requirement

The pressure end of the paper fingers should overlap the paper from 3/8 inch to 1/2 inch.

To Adjust

Position the paper fingers by sliding them on their shaft.

PAPER FINGER SPRING (FRICTION FEED)

Requirement

Pull upward on right paper finger to start left paper finger moving from platen.

Min 3 oz---Max 6 oz

Note: For sprocket feed mechanism, see 2.80.

PRESSURE ROLLER LEVER SPRING (FRICTION FEED)

Requirement

Min 28 oz---Max 36 oz
to start each center lever moving alternately.

PAPER PRESSURE BAIL SPRING (FRICTION FEED)

Requirement

Scale hooked over pressure bail at each end of platen.
Min 7 oz---Max 20 oz
to move pressure bail from platen.

2.72 Codebar Mechanism (continued)


CODEBAR DETENT

Requirement

Front plate removed. All clutches disengaged. Suppression and shift codebars should detent equally (gauged by eye).

To Adjust

Equalize the detenting of the codebars by adding or removing shims between the casting and the codebar bracket.



CODEBAR DETENT SPRING

Note: Unless there is reason to believe that these springs are causing operating failure, do not check this requirement.

Requirement

Codebar detent bracket carefully removed and codebars removed from detent bracket. Scale applied to detent ball and pulled in direction of ball travel

Min 1-1/2 oz ---Max 3-1/2 oz

(For applicable units the no. 6 codebar

Min 4 oz ---Max 6 oz)

to start ball moving against compression of spring. Check each ball.

CODEBAR YIELD SPRING


Requirement

Selector clutch, codebar clutch, and typebox clutch disengaged. No. 1 codebar in spacing position

Min 14 oz ---Max 23 oz

to start codebar shift bar pivot moving away from codebar. Check no. 2 and common codebar shift bar in the same manner.

2.73 Spacing Mechanism (continued)

MARGIN INDICATOR LAMP**Requirement**

Operating under power, the lamp should light on the desired character.

To Adjust

Set the typebox carriage to print the desired character and position the cam disc counterclockwise on the spring drum with its three mounting screws loosened so that the switch just opens. If a line shorter than 72 characters is required, it may be necessary to remove the cam disc screws and insert them in adjacent slots in the disc, if the range of rotation in one slot is not enough. Range is from the 5th through the 85th character.

(Min 65 characters---Max 69 characters
in Bell System switched network service)

2.74 Printing Mechanism (continued)


(B) PRINT SUPPRESSION BLOCKING LEVERS

Requirement

No. 6 codebar marking. No. 7 and suppression codebars spacing. Clearance between blocking levers and blocking bail blade should be equal within 0.020 inch.

To Adjust


Position eccentric post, keeping high part of eccentric toward front of unit.



(C) PRINT SUPPRESSION BLOCKING LEVERS SPRING

Requirement

Codebars to right (spacing). Typebox clutch in stop position
Min 2-3/4 oz---Max 4 oz
to start lever moving.



(A) PRINT SUPPRESSION MECHANISM

Requirement

Blocking lever extensions fully engaged by associated codebars.

To Adjust

Position print suppression assembly, with mounting screws friction tight, so lower lever extension is equally engaged by no. 6 and no. 7 codebars as gauged by eye.

2.75 Printing Mechanism (continued)

TYPEBOX CLUTCH SUPPRESSION ARM

Requirement


Blocking bail blocked. Rotate main shaft until function clutch shoe lever is opposite function clutch trip lever.

— Min 0.003 inch clearance between typebox clutch trip arm extension and clutch trip lever.

— Min 0.006 inch clearance between function clutch shoe lever and function clutch trip lever.

To Adjust

Position suppression arm with mounting screws friction tight.



(Left Side View)

PRINT SUPPRESSION BLOCKING BAIL SPRING

Requirement

All codebars right (spacing). Typebox clutch in stop position
 — Min 1/2 oz---Max 1-1/2 oz to start bail moving.

2.76 Line Feed and Platen Mechanism (continued)


(A) PAPER FINGER SHAFT SPRING (SPROCKET FEED)

Requirement

Hold latch away from shaft extension

Min 6 oz---Max 10 oz

to move paper finger against the platen.



(Right Side View)

(B) PAPER FINGER LATCH SPRING (SPROCKET FEED)

Requirement

Hold paper finger against platen.


Min 8 oz---Max 12 oz

to start latch moving.

PLATEN DETENT BAIL SPRING

Use 2.61.

2.77 Positioning Mechanism (continued)



TYPEBOX POSITION (SPROCKET FEED)


Requirement

Typebox and spacing clutches disengaged. Typebox shifted to left hand position. Four mounting screws loosened so that space suppression ring, or automatic carriage return line feed ring, is free to rotate on drum. Clearance between left print indicator and center line of sprocket pins in right hub


Min 5/16 inch---Max 7/16 inch

To Adjust

Loosen two typebox clamp screws and two printing carriage clamp screws. Position typebox. Tighten typebox clamp screws. Leave printing carriage clamp screws friction tight until printing carriage position adjustment is made. Recheck related adjustment, CARRIAGE DRAW-WIRE ROPE (2.45).




SPACING FEED PAWL



2.78 Line Feed and Platen Mechanism (continued)

(A) LEFT MARGIN (SPROCKET FEED)



(1) Requirement

Typebox clutch disengaged. Spacing drum fully returned. Typebox shifted to left hand position. Clearance between center of left print indicator on typebox and center line of sprocket pins in left hub
 Min 5/16 inch---Max 7/16 inch

(2) Requirement

Spacing clutch disengaged. Front spacing feed pawl farthest advanced. Spacing drum fully returned. Play in spacing shaft gear (2.29) taken up clockwise. Clearance between pawl and shoulder of ratchet wheel tooth immediately ahead
 Min 0.002 inch---Max 0.015 inch

(3) Requirement

Rear pawl, when farthest advanced, should rest at bottom of indentation between ratchet wheel teeth.

To Adjust


Position carriage return ring with mounting screws loosened.

(B) PRINTING CARRIAGE POSITION (2.51)

(C) PRINTING HAMMER STOP BRACKET (2.54)

(D) RIGHT MARGIN (2.56)


(E) TYPEBOX ALIGNMENT (2.57)



Note: Following this adjustment, all screws should be tightened.

2.79 Line Feed and Platen Mechanism (continued)

(A) LINE FEED SPUR GEAR DETENT ECCENTRIC Use 2.61.



(B) PRINTED LINE (SPROCKET FEED)

Requirement

The bottom of the printed line should be $1/32$ inch \pm $1/64$ inch (plus a multiple of $1/6$ inch if required) above a horizontal line drawn even with the bottom edge of any sprocket hole.

To Adjust

Loosen screws and position left sprocket.

Note: This adjustment is dependent on the type of form, and the location of the first printed line. The tolerances are field limits therefore the adjustment is not made in the factory.

(D) SPROCKET PIN SEPARATION (SPROCKET FEED)

(1) **Requirement**

With single sheet of sprocket feed paper placed on the platen the sprocket pins should be centrally located in the feed holes of the paper.

(2) **Requirement**

Printed line should be parallel to a line drawn perpendicular to edge of paper within plus or minus $1/32$ inch.

To Adjust

Position right sprocket with clamp screw loosened.

(C) PLATEN ENDPLAY (SPROCKET FEED)



Requirement

Line feed pawls disengaged. Platen shaft should have some endplay

Max 0.010 inch


To Adjust

Position platen spur gear with clamp screw loosened.




(Front View)

SPROCKET CAM AND GEAR RETAINING SCREW



2.80 Line Feed and Platen Mechanism (continued)



PAPER FINGER (SPROCKET FEED)

(1) Requirement

Sprocket pin should be centrally located in the paper finger slot.

(2) Requirement

The gap between the platen and the paper finger should be
 Min 0.050 inch---Max 0.150 inch
 (for stapled copies)
 Min 0.020 inch---Max 0.060 inch
 (unstapled or single copy).

Note: It is desirable to have the clearance at the minimum which will pass the stationery freely. This minimum is dependent upon the type of paper, number of copies, stapling, etc.

To Adjust

With paper finger assembly in latched position, loosen both clamp screws, position assembly horizontally to meet Requirement (1). Rotate assembly to meet Requirement (2).


(3) Requirement (Not Illustrated)

Min 0.035 inch

between leading edge of paper finger and ribbon guide. Both right and left paper fingers must be parallel to the same printed line as gauged by eye.

To Adjust

Select rubout combination and rotate typebox clutch 1/2 revolution. Position paper fingers by means of elongated mounting holes. After tightening the screws recheck Requirements (1), (2), and (3).




(Right Side View)

2.81 Line Feed and Platen Mechanism (continued)

(B) SPROCKET PIN SPRING (SPROCKET FEED)**Requirement (Early Design)**

Pins to be tested aligned with slots in guide bracket.

Min 6 oz---Max 8 oz
to start depressing the pin.

**(A) PAPER GUIDE (SPROCKET FEED)****Requirement**

The clearance between the platen and the front edge of the paper guide should be

Min 0.050 inch---Max 0.150 inch
(stapled copies)

Min 0.020 inch---Max 0.060 inch
(unstapled or single copy).

To Adjust

Position the guide with its rear mounting screws loosened.

(C) RIBBON REVERSE SPUR GEAR

Use 2.58.

(D) RIBBON REVERSE DETENT

Use 2.58.

(E) LINE FEED BAR BELLCRANK SPRING (SPROCKET FEED)

Use 2.61 except

Min 28 oz---Max 38 oz
to start bar moving.

Note: It is desirable to have the clearance at the minimum which will pass the stationery freely. This minimum is dependent upon the type of paper, number of copies, stapling, etc.

2.82 Function Mechanism (continued)

STRIPPER SLIDE BAIL ARM

(1) Requirement

Clearance between top edge of stripper slide bail and lower surface of the closest line feed function pawl should be
Min 0.030 inch---Max 0.045 inch

To Check

Single-double line feed lever in double line feed position and all clutches in latched stop position. Select line feed function. Rotate main shaft until codebar clutch stop lever just touches codebar clutch shoe lever. Take up play of stripper bail cam shaft drive arm to make clearance a maximum between the stripper bail and line feed function pawl. Take up play of stripper slide bail and function pawl in downward direction.

To Adjust

Position stripper slide bail arm with its clamping screw loosened. Position arm laterally to clear stripper slide when screw is tightened.

(2) Requirement


The line feed trip lever should reset at a point over, or just past, the second stop-lug by not more than 1/3 the distance between lugs.

To Check

Single-double line feed lever in double position. Select line feed function and rotate main shaft.


To Adjust

Refine LINE FEED CLUTCH TRIP LEVER ADJUSTING SCREW (2.25), if necessary. Recheck Requirement (1) of this adjustment.




2.83 Function Mechanism (continued)

STRIPPER SLIDE SPRING




STRIPPER SLIDE BAIL TORSION SPRING

Requirement
Single-double feed lever in single position.
Select line feed function and rotate main shaft until stripper slide bail just strips line feed function pawl.
Min 1 oz---Max 1-1/2 oz to just start bail moving.



3. VARIABLE FEATURES

3.01 Vertical Tabulator Mechanism (For Bell System Switched Network Service)



(A) VERTICAL TABULATOR SLIDE RETAINER

Requirement

Clearance between vertical tab slide and retaining edge of retainer
Min some---Max 0.012 inch

To Adjust



Move retainer to extreme forward position and locate up or down to meet requirement.

(B) MOUNTING BRACKET

(1) Requirement

Select form-out code combination and rotate main shaft until form-out slide is in forwardmost position. Clearance between form-out (inside) blocking lever and form-out slide.

Min some---Max 0.020 inch when play in blocking lever is taken up to make clearance minimum.



(2) Requirement

Select vertical tab code combination and rotate main shaft until vertical tab slide is in forwardmost position. Clearance between vertical tab slide and vertical tab blocking (outer) lever

Min 0.002 inch when play in blocking lever is taken up to make clearance minimum.

To Adjust

With mounting bracket screw friction tight, position lower portion of mounting bracket to meet Requirements (1) and (2).

3.02 Vertical Tabulator Mechanism (continued)
(For Bell System Switched Network Service)

(B) INDEXING DISC

Requirement

Line feed clutch disengaged. Form-out stop plate adjacent to form-out follower. Clearance between stop plate and follower

Min 0.015 inch---Max 0.040 inch with slack taken up in idler and form start gears to make gap minimum.

To Adjust

Pull gear out of engagement with idler. Turn handwheel clockwise until a stop plate just operates follower and then engage first tooth on idler. Position disc with three mounting screws.

(C) POINTER ADJUSTMENT

Requirement

Line feed clutch disengaged. Form-out stop plate adjacent to follower. Pointer on printer side frame should line up with notch in index disc.

To Adjust

Pointer mounting screw, on printer side frame, friction tight. Position pointer so it lines up with notch on index disc, and clears any stop plate by approximately 1/16 inch.


(A) FORM START GEAR PLAY

Requirement

Barely perceptible backlash between idler gear and form start gear.

To Adjust

Position gear pivot post on bracket by nut in center of handwheel. Check in at least three position, 120 degrees apart.



3.03 Vertical Tabulator Mechanism (continued)
 (For Bell System Switched Network Service) (Transmitter Control Switch Adjustments)

(D) NORMALLY OPEN CONTACT GAP

Requirement
 Blocking levers unoperated. Gap between normally open contacts
 Min 0.008 inch---Max 0.012 inch

To Adjust
 Bend stiffener.

(H) VERTICAL TAB BLOCKING LEVER SPRING

Requirement
 Blocking lever arms resting on top of their slides. Unhook blocking lever spring from mounting bracket.
 Min 9 oz---Max 11 oz
 to pull spring to operating length. Check both blocking lever springs.


(A) TRANSFER CONTACT SPRING

Requirement
 Blocking levers unoperated.
 Min 2 oz---Max 3 oz
 to just open contacts. Bend long contact spring to meet requirement.

(B) NORMALLY OPEN CONTACT SPRING

Requirement
 Blocking levers unoperated
 Min 1 oz---Max 2 oz
 to just move short contact spring away from stiffener. Bend short contact spring to meet requirement.

(Left Side View)



(F) VERTICAL TAB BLOCKING LEVER ARM

Requirement
 Vertical tab blocking lever resting on top of slide, clearance between blocking lever arm and insulator pad
 Min some

To Adjust
 Position blocking lever arm with mounting screws friction tight.

(E) CONTACT BRACKET

Requirement
 Form-out blocking lever resting on top of form-out slide. Clearance between blocking lever and insulator tip of swinger
 Min some

To Adjust
 Position contact assembly bracket with mounting screws friction tight.

3.04 Vertical Tabulator Mechanism (continued)
 (For Bell System Switched Network Service) (Transmitter Control Switch Adjustments)

(G) NORMALLY CLOSED CONTACT GAP

(1) Requirement

Select form-out code combination. Rotate main shaft until form-out slide is in forwardmost position and form-out blocking lever drops behind slide. Clearance between normally closed contact points
 — Min 0.008 inch

To Adjust


Refine NORMALLY OPEN CONTACT GAP and CONTACT BRACKET (3.03, (D) and (E)).

(2) Requirement

Select vertical tab code combination. Rotate main shaft until vertical tab slide is in forwardmost position and vertical tab blocking lever drops behind slide. Clearance between normally closed contact points
 — Min 0.008 inch

To Adjust

Refine NORMALLY OPEN CONTACT GAP and VERTICAL TAB BLOCKING LEVER ARM (3.03, (D) and (F)).




(C) NORMALLY CLOSED CONTACT SPRING

Requirement

Blocking levers operated
 — Min 2 oz --- Max 3 oz
 to just move short contact spring away from stiffener.
 Bend short contact spring to meet requirement.

3.05 Vertical Tabulator Mechanism (continued)
 (For Bell System Switched Network Service) (Form-Out and Tabulator Stops)



Note 1: Form-Out Stop Adjustment — Form-out index plates should be placed in numbered slots corresponding to length of form to be used. Form-out device may now be synchronized with form by first positioning form so that typing unit prints in first typing line of form. (When typing unit is in stop position, top of ribbon guide lines up with bottom of printing line.) With form in this position, pull form start gear out of engagement with idler and turn it until pointer on printer side is lined up with notch in index disc. (Form start gear is held in engagement with idler by spring tension, and may be disengaged by pulling the handwheel assembly out to left.)

Note 2: Tabulation Stop Adjustment — Tabulation stops within a form may be synchronized by first positioning form so typing unit will print on first typing line of form. (Procedure is outlined in Note 1.) Next, line feed platen to desired first printing line in form. Place tab stop plate in disc slot which lines up with vertical tab follower (inner). In same manner, place tab stop plates at succeeding desired printing lines within form. Tab stop plates may be placed on their sides in disc to nullify undesired printing positions on form.

BLOCKING ARM (FORM-OUT)

Requirement

Clearance between bottom of form-out blocking lever and top of form-out slide
 Min 0.005 inch---Max 0.045 inch

To Check

Trip line feed clutch. Rotate main shaft until form-out follower is on peak of form-out stop plate.

To Adjust

Position adjustable arm at lower pry points with clamp screw loosened.

BLOCKING ARM (VERTICAL TAB)

Requirement

Clearance between bottom of vertical tab blocking lever and top of vertical tab slide
 Min 0.005 inch---Max 0.045 inch


To Check

Trip line feed clutch. Rotate main shaft until vertical tab follower is on peak of tab stop plate.

To Adjust

Position adjustable arm at upper pry points with clamp screw loosened.

3.06 Vertical Tabulator Mechanism (continued)
 (For Bell System Switched Network Service) (Off Normal Contact Adjustments)



(C) CONTACT BRACKET

Requirement

Follower lever on peak of a form-out stop plate. Clearance between contact points

Min 0.010 inch---Max 0.020 inch

To Adjust

Position contact assembly bracket with mounting screws friction tight.

(A) SHORT CONTACT SPRING

Requirement

Follower lever operated.
 Min 2 oz---Max 3 oz
 to just move short contact spring away from stiffener. Bend short contact spring to meet requirement.

(B) LONG CONTACT SPRING

Requirement

Follower lever unoperated.
 Min 2 oz---Max 3 oz
 to just open contacts. Bend long contact spring to meet requirement.

(D) FOLLOWER LEVER


Requirement

Index disc rotated to bring form-out stop plate one slot away from operating position. Clearance between follower lever and insulator tip

Min 0.010 inch---Max 0.020 inch

To Adjust

Rotate eccentric post until requirement is met.



(Left Side View)


3.07 Vertical Tabulator Mechanism (continued)
(Common to 3.01 and 3.24)

FORM-OUT PAWL SPRING

Requirement

Form-out pawl extension resting against backstop.

Min 3 oz---Max 8 oz
to move pawl away from backstop.





VERTICAL TABULATOR BAIL SPRING

Requirement

Extension of tab bail resting against backstop.

Min 3 oz---Max 8 oz
to move bail away from backstop.



FORM FEED-OUT TORSION SPRING

Requirement

Rotate main shaft until line feed clutch is in stop position. Disengage line feed clutch trip lever.

Min 2 oz---Max 6 oz
to start bail moving toward rear of unit.

3.08 Form-Out Mechanism

(A) FORM-OUT LEVER BACKSTOP

Requirement

Line feed clutch trip lever against eccentric post. Form-out lever against formed extension of mounting plate. Clearance between trip lever and form-out lever
 Min some---Max 0.010 inch

To Adjust

Loosen adjusting screw. Hold lower end of form-out lever against extension of mounting plate. Position upper end of form-out lever. Tighten screw.

(B) SOLENOID LEVER (See also 3.09.)

Requirement

When solenoid plunger is seated, form-out slide, through combined motions of nonrepeat slide, form-out lever and form-out bail, should have moved forward to permit form-out blocking lever to fall in behind it. Clearance between slide and blocking lever
 Min 0.020 inch---Max 0.030 inch


To Adjust

Rotate eccentric screw to meet requirement. Make adjustment with high point of eccentric guide upward.

(C) FORM FEED-OUT NONREPEAT SLIDE SPRING



Requirement

Typing unit upside down and form feed-out solenoid unoperated
 Min 3 oz---Max 4 oz
 to pull spring to position length.



3.09 Form-Out Mechanism (continued)

Note: This adjustment insures that nonrepeat slide is stripped out of engagement with form-out lever before solenoid plunger is fully seated. It will also reduce the Min 0.020 inch---Max 0.030 inch clearance between form-out blocking lever and form-out slide, 3.08 (B), at point of stripping. Check for at least some clearance at this point. Solenoid plunger must not bind against solenoid. Loosen mounting screws and move solenoid up or down.



NONREPEAT SLIDE

(See also 3.08 (B).)

Requirement

Solenoid plunger seated. There should be some clearance between the nonrepeat slide and the form-out lever.

To Adjust

With high point of eccentric toward front, rotate eccentric guide to meet requirement.

3.10 Low Paper and Paper Out Alarm Mechanisms

LOW PAPER AND PAPER OUT ALARM
(SPROCKET FEED)

(1) Requirement

Without paper in unit, rear ends of switch operating levers should be in lowermost position. Switch plungers should be depressed. Normally open contacts should be closed. Ends of switch levers should be within outline of typing unit frame.


(2) Requirement

Rear ends of switch operating levers lifted to height of plane of upper surface of paper guide, switch plungers should be extended.

Min some clearance between switch levers and plungers.

To Adjust

Position plate with switch mounting plate mounting screws friction tight.



(Rear Right View)


PAPER OUT ALARM SENSING LEVER SPRING
(SPROCKET FEED)

Requirement

Min 1/2 oz---Max 1 oz _____
to lift end of lever, which rides paper, to same plane as upper surface of paper guide. Measure both sensing lever springs in same manner.

3.11 Paper Out Alarm Mechanism (continued)
(Friction Type) (Later Design)

Note: Adjustment requirements for the new-style paper-out alarm.



SWITCH

Requirement

Switch in uppermost position parallel to switch bracket.

To Adjust

Position switch with switch mounting screws loose.


LEVER

Requirement

Flat side of empty paper spindle parallel with upper surface of lever extension. Lever 1/4 inch below paper spindle.

To Adjust

Position bracket with post vertically up or down with mounting screws loose. If necessary, form the lever by hand.



LEVER SPRING

Requirement


Spring scale applied in downward direction to lever near spring eye
Min 11 oz---Max 18 oz
to move switch lever clear of switch button.

3.12 Low Paper and Paper Out Alarm Mechanism (continued)

PAPER OUT ALARM BELLCRANK FOLLOWER
SPRING (FRICTION FEED) (Early Design)**Requirement**

Roll of paper removed from unit.

Min 3-1/2 oz---Max 4-1/2 oz
to move lever far enough to just clear
lower switch.

PAPER OUT ALARM ASSEMBLY (FRICTION FEED)**(1) Requirement (Early Design)**

The upper switch should operate when paper
supply is reduced to approximately

Min 10 feet---Max 15 feet
on the roll.

(2) Requirement

Paper follower bellcrank should operate upper
switch at approximately 1/4 inch from flat
side of empty paper spool.

To Adjust

Position bracket with two bracket mounting screws
friction tight.

3.13 Horizontal Tabulator Mechanism


HORIZONTAL TAB OPERATING LEVER EXTENSION LINK SPRING

Requirement

Unhook trip arm latchlever spring. Operating lever in operated position. Slide arm against blocking lever.

Min 8-3/4 oz---Max 10-3/4 oz to start link moving.

Note: On units equipped with transmitter control contacts, hold contact spring away from stud while measuring tension.



HORIZONTAL TAB OPERATING LEVER LINK

Requirement

Rotate function clutch until function pawl stripper blade is in lower position, and function reset bail roller on high part of cam. Pull horizontal tab function pawl to rear until latched on function bar. Clearance between operating lever extension link and blocking lever

Min 0.005 inch---Max 0.025 inch with play taken up to minimize clearance.

To Adjust

Position extension link on operating lever with mounting stud friction tight.


Note: When pulling function pawl to rear, if operating lever cam plate should be stripped off the tab slide arm before function pawl is latched on function bar, temporarily disable cam plate stripper bail arm by loosening its adjusting screw.

3.14 Horizontal Tabulator Mechanism (continued)

HORIZONTAL TAB INTERMEDIATE BAIL SPRING

Requirement

Trip lever arm and intermediate bail unoperated
Min 1-1/2 oz---Max 3-1/2 oz
to pull spring to installed length.



(Left Side View)

3.15 Horizontal Tabulator Mechanism (continued)

(B) HORIZONTAL TAB SPACING TRIP LEVER



Requirementment

Spacing clutch trip lever arm against its stop. Operating lever against adjusting screw. Clearance between spacing trip lever and trip lever arm

Min some---Max 0.010 inch

To Adjust

Loosen mounting screw and mounting stud friction tight. With spacing trip lever riding on clutch trip lever arm, slowly rotate operating lever adjusting plate by means of screwdriver pry slots until spacing trip lever just falls off trip lever arm.



(A) HORIZONTAL TAB OPERATING LEVER CAM PLATE

(1) Requirement

Horizontal tab slide arm unoperated. Operating lever against adjusting screw. Clearance between slide arm and cam plate

Min some

(2) Requirement

With the operating lever extension link in the operated position, it should engage at least 2/3 of the surface of the step in the blocking lever, as gauged by eye.

To Adjust

Position adjusting screw.

3.16 Horizontal Tabulator Mechanism (continued)

HORIZONTAL TAB OPERATING LEVER
CAM PLATE SPRING

Requirement

Operating lever unoperated.
Horizontal tab function pawl
unlatched.


Min 4 oz---Max 9 oz
to start stripper bail moving.

HORIZONTAL TAB SLIDE ARM SPRING

Requirement

Operating lever operated. Slide arm
unoperated.

Min 1-1/2 oz---Max 4 oz
to start slide moving.



(Left Side View)

CAM PLATE STRIPPER BAIL

Requirement

Operating lever and horizontal tab
slide arm unoperated. Rotate spacing
clutch until high of restoring cam is
opposite stripper bail. Clearance
between stripper bail and high of re-
storing cam

Min 0.010 inch---Max 0.025 inch

To Adjust

Position stripper bail on stripper
bail arm with stripper bail arm
screw friction tight.

3.17 Horizontal Tabulator Mechanism (continued)


(A) SPACING CUTOUT TRANSFER BAIL SET COLLAR

Requirement


Transfer bail should have
Min some---Max 0.008 inch
endplay.

To Adjust

Position set collar with adjusting screw
loosened.



(Bottom View)



(B) RIGHT MARGIN ADJUSTMENT

Requirement

Clearance between spacing cutout lever on
spacing drum and bail extension arm
Min 0.006 inch---Max 0.025 inch

To Check

Place typebox in position to print char-
acter on which spacing cutout is desired.
Pull forward on part of transfer bail
extending below mounting shaft until bail
is in fully operated position. Gauge
clearance.

To Adjust

Position cutout lever with clamp screws
loosened.

Note: Four screws must be loosened
to adjust cutout lever (see figure in
2.56). Do not loosen hex head screw
that clamps front ring.

(C) SPACE SUPPRESSION BYPASS SPRING

Requirement

Typing unit upside down
Min 20 oz---Max 26 oz
to start bail extension moving.

SPACE SUPPRESSION
BYPASS SPRING

SPACING CUTOUT
LEVER ON SPACING
DRUM

3.18 Horizontal Tabulator Mechanism (continued)

TABULATOR PAWL (PRELIMINARY)

Note: Prior to adjustment, check LEFT MARGIN (2.55) and SPACING GEAR PHASING (2.29) adjustments.

(1) Requirement

Beginning with 15th slot (counterclockwise from roller on slotted ring), position tab stops approximately an equal number of slots apart over remaining length of printing line.

To Adjust

To move stops, hook small spring hook in hole of stop. Pull tab stop straight out from spacing drum and slide it on garter spring while continuing to pull it straight out. Spacing drum may have to be rotated manually to facilitate locating stops in some slots.


CAUTION: CHECK THAT ALL STOPS ARE FULLY SEATED IN SLOTS, AND NOT TURNED SIDEWAYS.

(2) Requirement

All clutches disengaged. Front spacing feed pawl in lower position, pawl adjusting plate should be positioned at center of vertical and horizontal adjustments.

To Adjust

Vertically position with both right and left screws loosened. Horizontally position with only left screw loosened. (Vertical adjustment is always made first.)

**(3) Requirement**

Disengage spacing feed pawls. Let spacing drum return to maximum counterclockwise position. Keep spacing clutch disengaged manually. Advance spacing drum until first stop is immediately left of pawl.

To Adjust

Adjust horizontal position of pawl adjusting plate so tabulator stop is in line with left edge of shoulder on pawl.

(4) Requirement

With blocking lever and operating lever extension link unblocked, disengage spacing feed pawls and let spacing drum move back exactly 2 full spaces. Both spacing feed pawls should be fully engaged.

To Adjust

With extension link blocked by blocking lever, gauge clearance between slope on pawl and tab stop. Note clearance. Advance drum until next stop is just left of tab pawl. Let spacing drum move back two full spaces. With extension link blocked by blocking lever, gauge and note clearance as before. Repeat procedure for remaining three stops. Note stop that gives maximum clearance. Use this stop as reference stop for final vertical and horizontal adjustments.

3.19 Horizontal Tabulator Mechanism (continued)

TABULATOR PAWL VERTICAL ADJUSTMENT (FINAL)


Requirement

Using stop with maximum clearance (determined by preliminary adjustment), position spacing drum until tab stop is opposite shoulder on tab pawl. With operating lever extension link blocked by blocking lever

Min 0.055 inch---Max 0.075 inch
clearance between tab stop and tab pawl.

To Adjust

Position pawl adjusting plate with both screws loosened. Tighten right screw only, using wrench to hold bushing from turning.



(Front View)

HORIZONTAL TAB PAWL SPRING

Requirement

Tab pawl unoperated
Min 3 oz---Max 5 oz
to start pawl moving.

HORIZONTAL TAB BLOCKING LEVER RETURN SPRING


Requirement

Operating lever slide arm held to rear
Min 2-1/2 oz---Max 4-1/2 oz
to start lever moving.

3.20 Horizontal Tabulator Mechanism (continued)

TABULATOR PAWL HORIZONTAL ADJUSTMENT**Requirement**


All clutches disengaged. Front spacing feed pawl in lower position. Position spacing drum so tab stop with maximum clearance (as determined by preliminary adjustment) is immediately left of pawl. Operating lever extension link forward in unblocked position. Disengage feed pawls, let spacing drum move back one full space. Both feed pawls should be fully engaged. Pull back extension link to blocked position on blocking lever. Trip spacing clutch stop lever and slowly rotate main shaft and spacing clutch until blocking lever is just tripped, allowing extension link to move forward. At this point, some portion of clutch disc stop-lug should be aligned with rear surface of spacing shaft gear. Take up play in spacing shaft towards rear of unit.

**To Adjust**

Trip spacing clutch and rotate clutch until middle of stop-lug is in line with rear surface of spacing shaft gear. If blocking lever trips too soon, first adjust the pawl adjusting plate to left until blocking lever can be placed in blocked position on extension link. Slowly move adjusting plate to right, with left screw loosened, until blocking lever just trips. When adjusting for trip-off point, take care that blocking lever is cammed down by tab stop and not pulled or pushed out of blocked position when prying adjusting plate. Recheck trip-off point against position of clutch stop-lug as before.

Note: After obtaining trip-off point of blocking lever, continue rotating spacing clutch to full stop position. Tab pawl should be right of tab stop. When extension link is moved to rear, blocking lever should move to blocked position. If tip of pawl should remain on end of tab stop, readjust pawl to right until there is

Min 0.003 inch---Max 0.008 inch
clearance between right surface on tab stop and left edge on pawl tip.



3.21 Horizontal Tabulator Mechanism (continued)

(C) RIGHT MARGIN TABULATOR STOP
(WITH WIDE SHELF)

Requirement


Check right margin and tabulator pawl adjustments. Position printing carriage at right margin (spacing cutout operated). Insert stop with wide shelf in slot immediately to left of pawl. Shelf should extend to right so pawl rests on it.

(A) TABULATOR STOPS SETTING

Requirement

To move stops, hook small spring hook in hole in stop and pull straight out from drum. Slide stop on spring while continuing to pull out from drum. Position drum to facilitate moving stops.

CAUTION: CHECK TO INSURE THAT ALL STOPS ARE FULLY SEATED IN SLOTS, AND NOT TURNED SIDEWAYS.



COLUMNAR TABULATOR STOPS

Requirement

Place carriage in position to print first character in column. Insert stop in slot immediately to left of tab pawl. To facilitate installation, mark desired slot position, rotate drum to a more accessible position. For slots near left margin, count number of space operations from left margin and place stop in corresponding slot number, beginning with slot no. 1 just to right of roller.

Note: When printing forms, check stop settings with relation to columns. Corresponding stops on all machines connected in a circuit must be same number of spacing operations from left margin.

3.22 Transmitter Distributor Transfer Control Contacts

(D) CONTACT ASSEMBLY BRACKET (PRELIMINARY)

Requirement (Not Illustrated)
 Operating lever unoperated. Clearance between stud on operating lever and long contact spring
 Min 0.020 inch---Max 0.025 inch

To Adjust
 Position contact assembly bracket with mounting screws loosened. The bracket pivots about a pin at upper end of bracket.

(E) TRANSMITTER CONTROL CONTACT GAP

Requirement (Not Illustrated)
 Operating lever in operated position. Min 0.010 inch---Max 0.015 inch between normally closed contacts.

To Adjust
 Bend stiffener.

(B) NORMALLY OPEN CONTACT SPRING


Requirement
 Operating lever unoperated
 Min 1 oz---Max 2 oz to just move short contact spring away from stiffener.

To Adjust
 Bend short contact spring.

(C) NORMALLY CLOSED CONTACT SPRING

Requirement
 Operating lever operated. Min 2 oz---Max 3 oz to just move short contact spring away from stiffener.

To Adjust
 Bend short contact spring.



(F) NORMALLY OPEN CONTACT GAP

Requirement
 Operating lever unoperated. Min 0.010 inch---Max 0.015 inch between normally open contacts.

To Adjust
 Bend stiffener.

(A) TRANSFER CONTACT SPRING

Requirement
 Operating lever unoperated. Min 2-1/2 oz---Max 3-1/2 oz to just open contacts.

To Adjust
 Bend long contact spring.

(G) CONTACT ASSEMBLY BRACKET (FINAL)

Requirement
 Operating lever unoperated. There should be some clearance between stud on operating lever and long contact spring.

To Adjust
 Remake adjustments (D), (E) and (F).

3.23 Transmitter Distributor Transfer Control Contacts (Later Design)

(A) TRANSFER CONTACT SPRING

Requirement

With the operating lever in the unoperated position, hook scale over the transfer contact swinger and pull at right angle to it.

Min 2 oz---Max 3 oz
to just open the contacts.

To Adjust

Bend the contact swinger spring.

(B) NORMALLY OPEN CONTACT SPRING

Requirement

With the operating lever in the unoperated position, hook scale over the short contact spring just above the contact point and pull at right angles to it.

Min 1 oz---Max 2 oz
to just move the short contact spring away from the stiffener.

To Adjust

Bend the short contact spring.

(C) CONTACT SPRING

Requirement

With the transfer contact swinger held away from the extension of the long contact spring, hook scale over the extension and pull at right angles to it.

Min 2 oz---Max 3 oz
to separate the contact points.

To Adjust

Bend the long contact spring.

(D) CONTACT ASSEMBLY BRACKET (PRELIMINARY)

Requirement

With the operating lever in the unoperated position, there should be Min 0.020 inch---Max 0.025 inch between the stud on the operating lever and the long contact spring.

To Adjust

Position the contact assembly bracket with the mounting screw loosened. The bracket pivots about a pin at the upper end of the bracket.


(E) NORMALLY OPEN CONTACT GAP

Requirement

With the operating lever in the unoperated position, there should be Min. 0.010 inch---Max 0.015 inch between the normally open contacts.

To Adjust


Bend the stiffener.



3.24 Transmitter Distributor Transfer Control Contacts (continued)

(A) TRANSMITTER CONTROL CONTACT GAP**Requirement**

With the operating lever in the operated position, there should be
 Min 0.010 inch---Max 0.015 inch
 between the normally closed contacts.


**(B) CONTACT ASSEMBLY BRACKET (FINAL)****Requirement**

With the operating lever in the unoperated position, there should be some clearance
 between the stud on the operating lever
 and the long contact spring.

To Adjust

Remake TRANSFER CONTACT SPRING (3.23) and
TRANSMITTER CONTROL CONTACT GAP adjustments.

3.25 Keyboard Lock Mechanism



3.26 Local Backspace Mechanism

CAMMING BAIL STOP ARM



Requirement

Spacing clutch disengaged, front feed pawl in lower position, backspace bail held operated, clutch tripped and main shaft rotated until the front feed pawl tooth is opposite the peak of the first spacing drum tooth that moves down past the pawl tooth. Clearance between pawl tooth and the tooth on the spacing drum ratchet wheel

Min 0.020 inch---Max 0.035 inch

To Adjust

Position the adjusting plate on the intermediate arm in the center of its adjusting range. Then position the camming bail stop arm with its mounting screw friction tight to meet the requirement.



CAMMING BAIL SPRING

Requirement

Min 1 oz---Max 2-1/4 oz
to start bail moving.

Note: See appropriate section for related keyboard adjustments.

3.27 Vertical Tabulator Mechanism

(C) FORM START GEAR PLAY


Requirement

Barely perceptible backlash between idler gear and form start gear.

To Adjust

Position gear pivot post with nut loosened.

Note: Gears should mesh accurately when checked at 3 equal distances around circumference of gear.



(B) MOUNTING BRACKET

(1) Requirement

Clearance between form-out blocking lever (inner lever) and form-out slide
Min some---Max 0.020 inch

To Check

Select upper case Z. Rotate main shaft until form-out slide is in most forward position. Take up play in form-out blocking lever to make clearance minimum.

(2) Requirement

Clearance between vertical tab slide and vertical tab blocking lever (outer lever)
Min 0.002 inch

To Check

Select upper case J. Rotate main shaft until vertical tab slide is in most forward position. Take up play in vertical tab blocking lever to make clearance minimum.

To Adjust

Position lower portion of mounting bracket with mounting screws loosened.

(E) INDEXING DISC

Requirement

Clearance between form-out stop plate and follower should be
Min 0.020 inch---Max 0.040 inch

To Check

Line feed clutch disengaged. Stop plate adjacent to follower. Slack in gears taken up to make gap a maximum.

To Adjust

Pull gear out of engagement with idler gear. Turn hand wheel clockwise until stop plate just operates the follower, then engage first tooth on idler. Position indexing disc with three mounting screws loosened.

(D) BLOCKING LEVER

See 3.28.

(A) VERTICAL TABULATOR SLIDE RETAINER

Requirement

Clearance between vertical tab slide and retaining edge of retainer should be
Min some---Max 0.012 inch

To Adjust

Position retainer forward and locate it up or down with mounting screws loosened.

VERTICAL TAB BLOCKING BLOCKING LEVER (OUTER)

VERTICAL TAB SLIDE RETAINER

3.28 Vertical Tabulator Mechanism (continued)


(I) FORM-OUT STOP PLATE POSITION

Requirement

Place a form-out stop plate in the numbered slots on disc corresponding to length of page form to be used. Synchronize form-out device with a form by positioning form so that typing unit will print in first typing line of the form. When typing unit is in stop position, top of ribbon guide should align with bottom of printing line.

To Position

With page form in desired position, disengage form-stop gear from its idler gear. Rotate form-start gear until notch in indexing disc aligns with pointer on side of printer. Re-engage gears.



(H) POINTER
Requirement
 Line feed clutch disengaged. Index stop plate adjacent to follower. Pointer should line up with notch in indexing disc and clear any index plate approximately 1/16 inch.

To Adjust
 Position pointer on side frame with its mounting screw loosened.

(G) TRANSMITTER CONTROL SWITCH
 See 3.29.

(F) SWITCH CONTACT PRESSURE (Transmitter Control Only)

Requirement
 Contacts closed
 Min 2 oz---Max 3 oz
 to move contact swinger away from its mating contact.

To Adjust
 Bend swinger.


(D) BLOCKING LEVER (Left Side View)

Requirement
 Clearance between bottom of blocking lever and top of slide when follower is on peak of a stop plate should be
 Min 0.005 inch---Max 0.045 inch

To Adjust

Trip line feed clutch. Rotate main shaft until follower is on peak of stop plate. Position adjustable arm with mounting screws loosened. Make adjustment for each blocking lever.

3.29 Vertical Tabulator Mechanism (continued)



(J) TABULATION STOP PLATE POSITION

Requirement

With adjustment (I) met, line feed platen to desired first line of printing in that form.

To Position

Place tabulation stop plate in index disc slot to align with follower. Install additional tab stop plates at succeeding desired printing lines within the form. When tabulation at a given point is not needed, rotate tab stop plates on their sides.

(K) BLOCKING LEVER SPRING

Requirement

With spring unhooked and blocking lever on top of slide.

Min 9 oz---Max 11 oz to pull respective spring to position length.

LINE FEED CLUTCH TRIP LEVER SPRING

See 2.23.

VERTICAL TAB BAIL SPRING

See 3.07.

FORM-OUT PAWL SPRING

See 3.07.

FUNCTION CONTACT SPRING

See 2.65.

(G) TRANSMITTER CONTROL SWITCH (SINGLE CONTACT TYPE)

(1) **Requirement**

With control contacts open clearance between contacts should be Min 0.010 inch---Max 0.020 inch

To Check

Select form-out code. Rotate main shaft until form-out slide is in most forward position and form-out blocking lever drops behind its slide.

(2) **Requirement**

Same as Requirement (1)

To Check

Select vertical tab code. Rotate main shaft until vertical tab slide is in most forward position and vertical tab blocking lever drops behind its slide.

(3) **Requirement**

With transmitter control contacts closed, there should be some clearance between insulator tip of swinger and lobes of both form-out and vertical tab blocking levers. (See figure in 3.28.)

To Check

Rotate main shaft until both form-out and vertical tab blocking levers are resting on top of slides.

To Adjust

Position switch assembly at pry point with center mounting screw loosened.

3.30 Transmitter Control Contacts (Later Design)

(A) SWITCH CONTACT PRESSURE

Requirement

With the break (lower) contacts closed and the make contacts open, it should require

Min 8 grams---Max 15 grams

to move the contact swinger away from its mating break contact.

To Adjust

Bend the swinger until the requirement is met.

(B) NORMALLY OPEN CONTACT GAP


Requirement

The contact gap between the swinger and the make (upper) contact should be

Min 0.008 inch---Max 0.020 inch

To Adjust

Bend the make contact spring until the requirement is met.



(C) CONTACT BRACKET

Requirement

Rotate the main shaft until both the form-out and vertical tab blocking levers are unoperated (resting on top of the slides). The transmitter control contacts (lower set) should be closed and there should be

Min some---Max 0.015 inch

between the insulator pad of the swinger and the lobe of the bail.

To Adjust

With mounting screws friction tight, position mounting bracket. Tighten screws.

3.31 Upper Solenoid (For Applicable Units)

UPPER SOLENOID

Requirement

With the solenoid held in the energized condition, position the solenoid so that there is

Min 0.060 inch---Max 0.080 inch between the solenoid bail stop and the codebar detent housing.


Note: Take up play in bail to the left to make this clearance a maximum.

To Adjust


Loosen the two solenoid adjusting screws and position the solenoid to meet the requirement.

To Check

Apply 110 volts ac to the solenoid. If the solenoid buzzes, the suppression bar is stopped before the solenoid is in its proper energized condition. Refine above.



(Top View)



(Left Side View)

SOLENOID SPRING

Requirement

With the solenoid in the de-energized condition, unhook the front end of the spring. To pull spring to installed length

Min 2 oz---Max 3 oz

3.32 Lower Solenoid (For Applicable Units)

LOWER SOLENOID

Requirement

With the solenoid in the de-energized condition there should be
 Min 0.030 inch---Max 0.070 inch
 between the clutch suppression arm and the end of the solenoid
 lever.

To Adjust

Loosen the two solenoid adjusting screws and position the
 solenoid to the requirement.

CLUTCH SUPPRESSION ARM

SOLENOID LEVER

SOLENOID

LINK

(Top View)

SOLENOID

SOLENOID SPRING

ADJUSTING SCREWS

(Right Side View)

SOLENOID SPRING

Requirement

With the solenoid in the de-energized
 condition unhook the front end of the
 spring. Pull spring to installed
 length.

Min 2 oz---Max 3 oz

To Adjust

Replace the spring.

3.33 Print-Nonprint Solenoid Mechanism


(A) SOLENOID PLUNGER

(1) Requirement

With the solenoid plunger held against the stop inside of the solenoid, the outer edge of the end of the suppression codebar should line up with the outer edge of the end of spacing no. 2 codebar. Also, when the suppression codebar is spacing, the tines of the suppression bar should line up with the tines of the no. 2 codebar. Vertically align either point by eye.

To Adjust

Loosen the solenoid mounting screws and move the solenoid forward or backward to meet both of these requirements. Check outer edges of the bars and the tine line-up by eye. Check tines by sighting over and through stunt box at rear of unit. Recheck requirement. Tighten screws.



(2) Requirement

With 48 v dc applied to the solenoid, recheck Requirement (1); the suppression codebar should not overtravel when the solenoid is energized.

To Adjust

Same as above.

(B) SOLENOID CONTACT


Requirement

With the solenoid de-energized and the plunger in the unoperated position there should be Min 0.010 inch---Max 0.020 inch gap between the contacts.

Note: Open up the contact cover to measure gap and to facilitate the following adjustments.

To Adjust

Bend the contact springs to gain the requirement.




3.34 Print-Nonprint Solenoid Mechanism (continued)

SUPPRESSION BAR RETURN SPRING (FOR UNITS EMPLOYING THE PRINT SUPPRESS SOLENOID MECHANISM)

Requirement

With the solenoid de-energized and suppression bar moved to the left, push against the left end of the bar and parallel to the bar. All bearing points in solenoid linkage must be free of binds.
 Min 2-1/2 oz---Max 4-1/2 oz
 to start the bar moving to the right.



(Front View of Printer)

3.35 Print-Nonprint Solenoid Mechanism (continued)

SOLENOID ENERGIZED


Requirement

With the solenoid plunger held against the solenoid pole face stop, the solenoid pin should operate the contact swinger and close the contacts. It should require a force of at least

Min 2 oz _____
to separate the contacts.

To Adjust

Loosen the contact bracket mounting screws and position the bracket so that the solenoid pin strikes the contact button just before the end of the plunger travel. Tighten screws. Bend the stationary contact to meet the requirement. Recheck requirement and then close contact cover.



3.36 Print-Nonprint Solenoid Mechanism (continued)

SOLENOID DE-ENERGIZED (SUPPRESSION CODEBAR MARKING)

(1) Requirement

When the solenoid de-energizes, the plunger should travel no more than

Max 1/8 inch

away from the solenoid pole face.

To Adjust

Loosen nut and adjust stop bracket against link. Vertically align suppression codebar with other codebars by eye.

Solenoid travel should not exceed

Max 1/8 inch

Tighten nut.

(2) Requirement


All pivot points on the solenoid linkage must be free of binds. With the solenoid plunger in its unoperated position, a force of no more than

Max 1-1/4 oz

applied to the end of the plunger should move the plunger when the suppression bar return spring is removed.

To Adjust

Inspect all pivot points for binds.



(Top View)

3.37 Print-Nonprint Solenoid Mechanism (continued)


CONTACT BUTTON AND SOLENOID PIN ALIGNMENT

Requirement

The swinger contact button and the solenoid plunger pin should be aligned by eye such that the pin strikes the flat surface of the button.

To Adjust

Loosen the contact pile-up mounting screws and move the contacts left or right to gain the alignment of button and pin. Check to see that the contact points mate fully.



(Front View)

3.38 Timing Contact Mechanism (Operated by Selector)

Note 1: In this text, the letters S, B, and M are used to denote respectively the "swinger", "break" (normally closed with lever riding cam depression) and "make" (normally open; closed only with lever riding cam peak) contact springs.

Note 2: When making adjustments (F) through (H) make certain the "S" spring insulator is clear of the operating lever.

Note 3: Parts should be well aligned and free of sharp bends. Contact points misalignment should not exceed 1/4 the diameter of points.

(A) "M" CONTACT SPRINGS

Requirement

Min 4 oz
to move contact spring away from its stiffener.

To Adjust

Bend contact spring.

(B) "B" CONTACT SPRINGS

Requirement

Min 4 oz
to move contact spring away from its stiffener.

To Adjust

Bend contact spring.

(C) "S" - "B" CONTACT SPRINGS

Requirement

Min 3-1/2 oz --- Max 4-1/4 oz
to move swinger contact away from normally break contact.

To Adjust

Bend swinger contact spring.


(E) "S" - "M" CONTACT GAP

Requirement

Min 0.012 inch --- Max 0.020 inch

To Adjust

Bend stiffener.



(Right Side View)

(D) TWIN "B" CONTACT SPRINGS

(1) Requirement

Both contacts should open at the same time.

(2) Requirement

The insertion of an 0.008 inch gauge between one pair of points should not cause the other pair to separate.

To Adjust

Bend springs or slightly twist stiffener. Recheck contact pressure.

SWINGER CONTACT W/INSULATOR

(F) TWIN SPRINGS ("M" CONTACTS)


Requirement

Both make and swinger contacts should make approximately the same time (within 0.006 inch as gauged by eye).

To Adjust

Bend make contact springs or slightly twist stiffener.

CONTACT MOUNTING BRACKET



(Front View)

3.39 Timing Contact Mechanism (Operated by Selector) (continued)

(H) CONTACT ASSEMBLY POSITION

(1) Requirement

Set range scale at 50 (important).
Rotate shaft so operating lever is on lowest part of cam.

To Adjust

With mounting screws loosened position contact assembly by means of its oversize mounting holes so lever can be moved


Min 0.002 inch---Max 0.006 inch before it touches the swinger spring, and so first touch is on lower half of spring stud wearing plate.

(2) Requirement

(At higher settings, movement will be larger: disregard.) Tighten screws and recheck. Rotate shaft and note the high part of cam causes both "M" contacts to move at least

Min 0.012 inch

If this contact movement is not met at setting 60 and 90, check for insecure parts and refine contact gap between swinger and make contact. If still not met, replace range scale sector rack.




(Right Side View)

(I) OPERATING LEVER SPRING

Requirement

The spring should hold operating lever against cam with light pressure. With spring removed

Min 2 oz---Max 3 oz
to stretch spring to 5/8 inch length.



(G) ALIGNMENT OF OPERATING LEVER WITH CAM

(1) Requirement

Operating lever's full thickness should ride cam.

To Check

Take up all cam endplay toward selector to clutch drum, all operating lever endplay (at its bearing) in opposite direction. Observe lever and cam for full engagement.

(2) Requirement

Lever should not exert pressure against face of clutch disc.

To Adjust

Refine clutch drum endplay.

3.40 Timing Contact Mechanism (Operated by Selector) (continued)

(A) TIMING VERIFICATION, 11.00 UNIT CODE

Note 1: DXD means distortion test set.

Note 2: Requirements (1) or (2), below, may be omitted if the stroboscopic tests of Requirement (3) are to be made.

(1) Requirement

TP174451 Cam: With range scale at 45, manually rotate main shaft with selector armature spacing. The M contacts should close soon after, but not before, the locklever blocks the selector armature after the no. 8 selection. Continue rotation into the next cycle. With the selector armature marking, note that the M contacts again close and that they open and the B contacts close before the selector clutch slips (it may not latch because of the slow rotation).

(2) Requirement

TP174450 Cam: With range scale at 90 and the selector marking, rotate the shaft and latch the clutch. The M contacts should be closed. Trip the clutch and slowly rotate the shaft. The B contacts close after rotation starts. Repeat at range setting 45.

(3) Requirement

Stroboscopic Tests: Connect the B-S or S-M terminals (as required into a 120 v dc viewing circuit of 11.00 unit DXD or similar stroboscopic test set, 600 opm. Connect the DXD test message output or a comparable signal source in a line circuit to the selector magnets. Set distortion at zero. Synchronize the viewing scale with the transmitted signals. Observe DXD stroboscopic display of signals listed below. Ignore rhythmic shifting of a signal. This shifting occurs because of slight rotational displacement of the motor armature (and of the selector cam) as it encounters loads such as line feed, etc, from one printer cycle to the next. The shifting is exhibited as lighter colored display at the beginning or end of a signal. True readings are at the observed midpoints of shifting areas. If any shift area should be excessive, say over 18 DXD divisions total, it may be indication of binds, slippages, or wear in the machine. Signals should be clear of gaps (except see ++ below) (indicate dirt, chatter, or bounce) after the first ten DXD divisions of closure. Where only one range setting is specified, it indicates that tests at that setting are sufficient to verify performance at other settings.

3.41 Timing Contact Mechanism (Operated by Selector) (continued)

<u>Test Conditions</u>		<u>Signal Length in Viewed DXD Divisions</u>	
<u>Cam</u>	<u>Contact Pair</u>	<u>Message Stopped, Marking</u>	<u>Message Running</u>
TP174451	S-M	Dark at range 45	Min 104 at range 90. Begins after 11 of beginning of stop pulse, ends before 148 of stop pulse.
	B-S	1100 at range 45	++890-979
TP174450	S-M	1100 at range 45 & 90	++ Min 148 at range 90. Begins in stop pulse, ends before 48 of #1 pulse.
	B-2	Dark at range 45	++845-948


++ While viewing DXD, slowly move range scale from 90 to 45. If, at some setting there is within the signal a gap, it should not exceed 8 DXD divisions.

(B) CORRECTION OF TIMING

Check for the following:

- (1) Wrong cam
- (2) Range scale knob maladjusted
- (3) Contact, lever, and bracket adjustments. Refine if required.
- (4) Parts loose
- (5) Contacts dirty
- (6) Improper test connections
- (7) Improper synchronism of sending and stroboscopic portions of test set. Note that test message is to be sent direct to selector magnets. Introduction of a line relay, contact protection network, or any other condition affecting magnet release time will displace the viewed signals produced by the modification kits.

3.42 Two Color Ribbon Mechanism



(Left Side View)

RIBBON LEVERS

Requirement

Lever extensions fully engaged by codebars no. 6 and 7, as gauged by eye.

To Adjust

Position contact assembly with mounting screws friction tight.

CONTACT ACTIVATING LEVER


Requirement

With codebars no. 6 and 7 in same condition (marking or spacing), the clearance between the contact swinger pad and its respective lever should be

Min 0.010 inch

To Adjust

Position eccentric post; keep high part of eccentric toward left of unit.



(Top View)

3.43 Two Color Ribbon Mechanism (continued)


CONTACT SPRING

Requirement

To separate the normally closed contacts, it should require
Min 1-1/2 oz---Max 2-1/2 oz

To Adjust

Bend stationary contact spring.



CONTACT GAP

Requirement

With no. 6 and 7 codebars in opposite conditions (one marking and one spacing), there should be a gap between the contact points
Min 0.020 inch

To Adjust


Refine CONTACT ACTIVATING LEVER (3.42).

(Top View)


3.44 Universal Function Bar

CODING

FUNCTION BAR
CODING FOR 8-LEVEL ASA DATA INTERCHANGE CODE (1966-1967) (ASCII CODE)



Coding for row A is as shown.
For coding of rows B, C, and D see
Notes below.



■ INDICATES TINE
□ INDICATES TINE REMOVED

Notes:

1. To operate function bars on symbols and numbers in row B, number 6 tine is left on the marking side and, number 7 tine is left on the spacing side.
2. To operate function bars on nonprinting functions in row C, number 6 and number 7 tines are left on the spacing side.
3. Suppression tine can be coded marking, spacing, or both to control the function bar. In selective calling systems and systems using the stunt shift solenoid, code as follows:
 - a. To sense suppression bar in mark (nonselect or nonprint), break off the spacing tine.
 - b. To sense suppression bar in space (solenoid operated, select or print), break off the marking tine.
 - c. To sense in either condition break off both tines.
 - d. In TWX and other systems not using a stunt shift solenoid, the suppression codebar is held by a clip in the spacing position. Break off marking tine.

4. To operate function bar on code in row D, number 6 and number 7 tines are left on the marking side.
5. The number 8 codebar is omitted from the printer since the number 8 code bit is not used for printing.
- *6. These characters in row C have no associated keytop on Model 35 keyboards.
7. Bell system uses the 1966 ASCII code as shown on the above illustration except for the following:

ASCII CODE	BELL SYSTEM USAGE	ASCII CODE	BELL SYSTEM USAGE
ENQ	WRU	DC1	XON
BEL	BELL	DC2	TAPE
HT	TAB	DC3	XOFF
LF	LINE FEED	DC4	TAPE
CR	RETURN	DEL	RUB OUT

8. Refer to appropriate parts section for additional cross reference information pertaining to function bars and codes.

35 KEYBOARD FOR AUTOMATIC SEND-RECEIVE SETS
 ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	2	Keyboard Mechanism	
GOLD-PLATED SIGNAL CONTACTS . . .	3	Ball wedgelock, ball endplay, and universal bail latch (final)	12
2. BASIC UNIT	4	Ball wedgelock and ball track clearance (preliminary)	12
Codebar Assembly		Code lever spring	19
Clutch tripbar spring	31	Keytop guide spacing	15
Codebar and code lever clearance	9	Lock ball channel	10
Codebar bail	11	Lock ball endplay (preliminary)	12
Codebar bail and nonrepeat lever clearance	11	Local carriage return function bail spring	19
Codebar bail latch spring	11	Local line feed trip link spring	14
Codebar bail spring	14	Signal Generator Mechanism	
Codebar guide clearance	4	Clutch latchlever spring	6
Codebars, shift and control lockbar, counter and counter return bar springs	31	Clutch shoe lever	5
Code lever universal bail spring	4	Clutch shoe lever spring	7
Function bail levers and code lever clearance	10	Clutch shoe spring	7
Inversion bar latching bail spring (later design)	17	Clutch stop lever	6
Inversion codebar latch (early design)	16	Clutch stop lever spring	6
Inversion codebar latch (later design)	17	Signal contact clearance	8
Inversion latch spring tension (early design)	16	Signal contact drive link	8
Nonrepeat lever spring	11	Signal contact spring	8
Spacebar bail pivot	4	Signaling code contact (strobing)	18
Transfer lever locking bail spring	20	Transfer bail detent latch spring	8
Transfer lever spring	20	Transfer bail detent plate	8
Universal bail extension	13	3. VARIABLE FEATURES	23
Universal bail latchlever (preliminary)	13	Auxiliary Contact Mechanism	
Universal bail latchlever spring	13	Auxiliary contact refinement (strobing)	44
Universal bail - rear blade	13	Contact gap	38
Interrelated Features		Character Counter Mechanism	
Intermediate gear assembly	22	Antibounce spring	35
Margin indicator spring	20	Character counter scale	35
Mounting reperforator unit on keyboard	22	Character counter stroke	37
Mounting typing unit on keyboard	21	End-of-line switch	36
Signal generator frame	21	Ratchet drum assembly return spring	36
		Reset latchlever and drive lever spring	37
		Reset lever extension spring	37
		Stop lever	35

CONTENTS	PAGE
Codebar Arrangement for Even Parity	
No. 5 and no. 8 inversion bar spring	31
Transition bar spring	31
Code Reading Contact Mechanism	
Adjusting code reading contacts	40
Backstop - normally closed contact	39
Code reading contact refinement (strobing)	43
Contact swinger spring	39
Drive arm extension spring	42
Intermediate lever spring	41
Latchlever spring.	41
Marking contact gap	41
Normally closed contact spring. . . .	39
Normally open contact gap.	39
Reset bail	42
Reset bail spring	42
Keyboard Universal Contact Mechanism	
Contact gap.	33
Local Backspace Mechanism	
Transfer bail adjusting lever	29
Transfer bail spring.	29
Trip link horizontal spring.	29
Trip link vertical spring	29
Local Single Line Feed Mechanism	
Trip link front spring	32
Trip link horizontal rear spring	32
Trip link vertical spring	32
Receive-Break Switch Mechanism	
Receive-break switch	30
Receive-break switch tension.	30
Reperforator Backspace Actuating Switch Mechanism	
Operating pad gap.	33
Strobing Requirements	
Code reading and timing contacts . . .	45
Signal generator contacts.	45
Tape Alarm	
Tape alarm switch	34
Tape arm spring	34

CONTENTS	PAGE
Timing Contact Mechanism (Early Design)	
Cam follower spring	24
Contact stiffener	24
Contact swinger	24
Timing contact.	23
Timing contact (strobing).	28
Timing Contact Mechanism (Later Design)	
Cam follower spring.	26
Timing contact.	25
Timing contact swinger spring	27

1. GENERAL

1.01 This section is reissued to add recent engineering changes and strobing requirements. Since this is a general revision, marginal arrows, used to indicate changes, have been omitted.

1.02 The adjustments of each unit are arranged in a sequence that should be followed if a complete readjustment of the unit were undertaken. The tools and spring scales required to perform these adjustments are listed in the applicable section. After an adjustment is completed, be sure to tighten any nuts or screws that are loosened. The adjusting illustrations indicate tolerances, positions of moving parts, spring tensions, and the angles at which scales should be applied when measuring spring tensions. If a part that is mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that the same number is replaced when the part is remounted.

1.03 The spring tensions given in this bulletin are indicated values and should be checked with proper spring scales in the positions indicated. Replace springs that do not meet requirements, unless otherwise indicated.

1.04 References made to left or right, up or down, front or rear, etc, apply to the unit in its normal operating position as viewed from the front.

1.05 When a requirement calls for a clutch to be disengaged, the clutch shoe lever must be fully latched between its trip lever and latch-lever so that the clutch shoes (Par. 2.04) release their tension on the clutch drum. When engaged, the clutch shoe lever is unlatched and the clutch shoes are wedged firmly against the clutch drum.

1.06 All electrical contact points should meet squarely. Contacts with the same diameter should not be out of alignment more than 25 percent of the contact diameter. Check contacts for pitting and corrosion and clean or bur-nish them before making specified adjustment or tolerance measurement. Avoid sharp kinks or bends in the contact springs.

Note: Keep all electrical contacts free of oil and grease.

GOLD-PLATED SIGNAL CONTACTS

1.07 All units now being manufactured have signal contacts made of gold-plated tungsten. Older units may have unplated tungsten contacts. If in doubt as to the type of contacts, remove signal generator cover and inspect contacts for gold plating.

(a) Servicing: For standard applications including those with data sets, observe standard maintenance intervals. For special low current applications, see below.

(b) Cleaning

- (1) Use twill jean cloth (KS2423) to clean gold-plated contacts.
- (2) Open contacts. Drop strip of twill jean between them.
- (3) Close contacts. Draw twill jean part way through. Open contacts and withdraw twill jean.
- (4) This procedure prevents small fibers at edges of twill jean strip from becoming lodged between contacts.
- (5) Clean unplated tungsten contacts in accordance with standard procedures.

(c) Special Low Voltage Applications

Note: Following does not apply to standard applications.

(1) The recommended cleaning interval for gold-plated contacts in special low level applications (less than 250 micro-watts) having an average weekly use of 60 hours should not exceed 90 days. This interval may be reduced, dependent on the circuit configuration, usage, and environment. Contacts should be cleaned as described in 1.07 (b).


Note 1: Applying operating voltage of standard Distortion Test Set directly to contacts may damage gold plating and impair low voltage operation. When electrically adjusting or testing contacts (Par. 2.17), use an intermediate device, keyed by the contacts, to interrupt current to stroboscopic lamp of test set. This intermediate device must be capable of being keyed by a 3- to 20-volt change at maximum of 20 milliamperes.

Note 2: Normally for low voltage applications, contacts should be used in circuits operating between 3 and 20 volts dc at a current level not to exceed 60 milliamperes. Between 20 and 70 volts dc, the current should be adjusted so that it does not exceed a 120 milliwatt power level. The contacts are not normally intended for use on voltages above 70 volts dc. Exceeding these levels for an appreciable length of time may result in damage to the gold plating and make them unfit for low voltage applications.

2. BASIC UNIT

2.01 Codebar Assembly

(B) CODE LEVER UNIVERSAL BAIL SPRING




(A) CODEBAR GUIDE CLEARANCE

Requirement

Clearance between the top of no. 1 and no. 8 codebars should be
Min some---Max 0.006 inch
All codebars should move freely.

To Adjust

With mounting screws for either the left or right codebar guides friction tight, position guides. Tighten screws.



(C) SPACEBAR BAIL PIVOT


Requirement

Min some endplay---Max 0.010 inch
Spacebar free from bind.

To Adjust

Position spacebar with pivot screws.

2.02 Signal Generator Mechanism

CLUTCH SHOE LEVER**Requirement**

Clearance when clutch is disengaged should be
 Min 0.055 inch---Max 0.085 inch
 less than when clutch is engaged.

To Check

Latch clutch in disengaged position and measure clearance. Rotate gear until oil hole is upward. Engage clutch and measure clearance.

To Adjust


Loosen the two adjusting disc clampscrews to position disc.

2.03 Signal Generator Mechanism (continued)

(B) CLUTCH STOP LEVER SPRING

Requirement

Clutch engaged and rotated 1/4 turn.
 Min 2 oz---Max 3 oz
 to start lever moving.




(A) CLUTCH STOP LEVER

Requirement

Should fully engage clutch shoe lever.
 During rotation, the lever should not touch the clutch drum at any point.

To Adjust

Position stop lever with its clamp-screw loosened.



(C) CLUTCH LATCHLEVER SPRING

Requirement

Clutch latchlever resting on the highest point of clutch disc.
 Min 2 oz---Max 3 oz
 to start latchlever moving.



2.04 Signal Generator Mechanism (continued)

CLUTCH SHOE LEVER SPRING

Requirement

Clutch engaged. Cam disc held to prevent turning.

Min 15 oz---Max 20 oz _____
to move shoe lever in contact with stop-lug.



CLUTCH SHOE SPRING

Note: In order to check this spring tension, it is necessary to remove the clutch from the main signal generator drive shaft. Therefore, it should not be checked unless there is good reason to believe that it does not meet its requirement.

Requirement


Clutch drum removed.

Min 3 oz---Max 5 oz _____
To start primary shoe moving away from secondary shoe at point of contact.

2.05 Signal Generator Mechanism (continued)

TRANSFER BAIL DETENT LATCH SPRING

(B) TRANSFER BAIL DETENT LATCH SPRING



Requirement

Min 2-3/4 oz---Max 4-1/4 oz to start latch moving. Hold transfer bail to left.

(A) TRANSFER BAIL DETENT PLATE

Requirement

Equal left hand and right hand clearance within 0.002 inch when transfer bail is at extreme left hand or right hand position as these occur in a character between start and no. 1 pulses only.

To Adjust

Rotate detent plate right or left by means of screwdriver with detent plate mounting screws loosened.

(C) SIGNAL CONTACT CLEARANCE

Requirement

Marking and spacing gaps should be equal within 0.001 inch.


To Check

Depress Y keylever and rotate signal generator cam sleeve until each contact has fully opened.

To Adjust

Loosen mounting screws and move contact box by means of eccentric.

Note: Check by means of signal checking device where possible, and carefully refine the adjustment to eliminate all bias from the signals by equalizing the current-on and current-off intervals (Par. 2.17).



Note: For servicing instructions on gold-plated contacts, see 1.07 on page 3.

(D) SIGNAL CONTACT DRIVE LINK

Requirement

With main shaft in stop position and transfer bail detent latch spring unhooked, move latches away from transfer bail extension. Hold the toggle firmly against contacts.

Min 6 oz---Max 9 oz to start transfer bail extension moving.


(E) SIGNAL CONTACT SPRING

Requirement

Remove drive link spring transfer bail held clear of drive link.

Min 2 oz---Max 3 oz to start link moving.

2.06 Codebar Assembly (continued)

**CODEBAR AND CODE LEVER CLEARANCE****Requirement**

Permutation must be such that highest level is spacing and located furthest right. While key is held down and cam cycled to stop position, gap between left hand side of key code lever and codebar blocked.

Min 0.006 inch---Max 0.017 inch

To Adjust

Position guide by adjusting slot with four mounting screws loosened.

2.07 Codebar Assembly (continued)


(A) FUNCTION BAIL LEVERS AND CODE LEVER CLEARANCE

Requirement

Function bails should operate within their guides without binding.

To Adjust

Position function bail assembly with two mounting studs loosened, one at each end.



2.08 Keyboard Mechanism

Note: This adjustment should not be made unless the lock ball channel has been disassembled.

(B) LOCK BALL CHANNEL


Requirement

There should be

Min Some---Max 0.006 inch clearance between end of lock ball channel and adjusting screw when most of the code levers are centrally located in the lock ball channel slots.

To Check


Remove the lock ball retainer. Remove a wedge from each end and one from the center in order to view the position of the code lever.



To Adjust

Loosen the lock ball channel mounting screws. Back off lateral adjusting screws and position channel. Turn one adjusting screw in against the end of the channel and lock it. Turn the other adjusting screw in to the end of the channel and back it off 1/4 turn. Lock the screw. Replace the wedges and check their position with respect to the balls. Pull channel assembly downward until all code levers strike their upstop without wedges jumping out of position. Replace lock ball retainer. Back off ball endplay adjusting screw.

2.09 Codebar Assembly (continued)



(A) CODEBAR BAIL LATCH SPRING

Requirement
Min 1/2 oz---Max 1-1/2 oz
to start codebar bail latch moving.


(B) CODEBAR BAIL

Requirement
Cam eccentric and arm which hold the
bail in extreme reset position to the
left.
Min some---Max 0.006 inch
between codebar bail roller and code-
bar bail latch.

(C) NONREPEAT LEVER SPRING

Requirement
Clutch disengaged, any keylever depressed
Min 2-1/4 oz---Max 3-1/4 oz
to start nonrepeat lever moving downward.

To Adjust
With locknut loosened, adjust eccentric
stud so that high point is in upper half
of arc.



(D) CODEBAR BAIL AND NONREPEAT LEVER CLEARANCE

Requirement
Mechanism in initial trip off position, any key depressed, no power.
Min some---Max 0.010 inch
between roller of reset bail and nonrepeat lever pickup step.

To Adjust
Loosen locknut and shoulder screw and move mechanism left or right.

Note: Do not permit clutch to rotate when tripping off.

2.10 Keyboard Mechanism (continued)

Note: Remove keyboard hood in order to make this adjustment. See disassembly and reassembly.

(A) BALL WEDGELOCK AND BALL TRACK CLEARANCE (PRELIMINARY)**Requirement**

Clearance between tip of wedge and the track should be
Min 0.005 inch---Max 0.015 inch and equal within 0.005 inch.

To Check

Depress Q and P keylevers alternately with 32 oz pressure and measure clearance in each instance. There should be no clearance between lower edge of code lever extensions and bottom of slots in wedges.

To Adjust

Position ball track up or down with the two mounting screws loosened.

(B) LOCK BALL ENDPLAY (PRELIMINARY)**Requirement**

Clearance between balls should be minimum.


To Check

With ball endplay adjustment screw backed off, depress key at extreme right end of the A row with 32 oz pressure.

To Adjust

Maintain 32 oz pressure and rotate adjusting screw with fingers until a slight resistance is felt. Tighten locknut.

Note: A total of 53 balls are required in the ball track assembly.

**(C) BALL WEDGELOCK, BALL ENDPLAY, AND UNIVERSAL BAIL LATCH (FINAL)**

Note: Perform this adjustment following (C) in Par. 2.11.


Requirement (Under Power)

- (1) Trip off pressure of any key in row A should be
Min 2 oz---Max 6 oz
- (2) Apply 6-1/2 oz pressure perpendicular to A key, depress each key in that row. The A key should trip each time a key is released.
- (3) Repeat (2) with the 6-1/2 oz pressure on extreme right key in that row.
- (4) The clutch should not trip when two keys are depressed simultaneously.

To Adjust

If necessary, refine BALL WEDGELOCK AND BALL TRACK CLEARANCE (PRELIMINARY) Par. 2.10, LOCK BALL ENDPLAY (PRELIMINARY) Par. 2.10, UNIVERSAL BAIL LATCH-LEVER (PRELIMINARY) Par. 2.11, and UNIVERSAL BAIL EXTENSION Par. 2.11 adjustments.

2.11 Codebar Assembly (continued)



(B) UNIVERSAL BAIL LATCHLEVER SPRING

Requirement

Clutch disengaged, universal bail held away from latchlever. Nonrepeat lever bellcrank held down against its stop post.
 Min 7-1/2 oz---Max 11 oz
 to start latchlever moving.

(A) UNIVERSAL BAIL LATCHLEVER (PRELIMINARY)

Requirement

Clearance between universal bail latchlever and roller on universal bail extension should be
 Min 0.015 inch---Max 0.025 inch

To Check

Depress G key slowly with 32 oz pressure. Manually rotate universal bail backwards and release quickly.

To Adjust

Rotate eccentric. Keep high part of eccentric up.

Note: It will be necessary to remake UNIVERSAL BAIL - REAR BLADE Par. 2.11 adjustment.

(C) UNIVERSAL BAIL EXTENSION

Requirement (Power Off)

Universal bail extension roller resting against end of universal bail latchlever
 Min 0.050 inch---Max 0.080 inch
 between extension and nonrepeat lever


To Check

Depress rubout keylever and release it. Check clearance.

To Adjust

Position the extension with its clamp-screw loosened.

(E) BALL WEDGELOCK, BALL ENDPLAY, AND UNIVERSAL BAIL LATCH (FINAL)
 see Par. 2.10



(D) UNIVERSAL BAIL - REAR BLADE

Requirement

Unit in initial trip off condition, no key depressed, no power, extension post of universal bail resting against the end of latch
 Min Some---Max 0.025 inch
 between universal bail rear blade and any code lever.

To Adjust


Position rear blade with mounting screws loosened.

2.12 Keyboard Mechanism (continued)

LOCAL LINE FEED TRIP LINK SPRING

Requirement

Min 5 oz---Max 10 oz
to start link moving.




2.13 Codebar Assembly (continued)

CODEBAR BAIL SPRING

Requirement

Clutch disengaged. Spring unhooked
from arm

Min 9 oz---Max 11 oz
to pull to installed length.



2.14 Keyboard Mechanism (continued)

KEYTOP GUIDE SPACING


Requirement

Gap between frame and left and right mounting bracket should be

Min 0.141 inch---Max 0.171 inch



To Adjust

Tighten or loosen as required the four frame mounting screws.



2.15 Codebar Assembly (continued)

(A) INVERSION LATCH SPRING TENSION (EARLY DESIGN)



(B) INVERSION CODEBAR LATCH (EARLY DESIGN)


Requirement

- Signal generator disengaged
- Min 0.002 inch---Max 0.012 inch gap between inversion codebar and its latch.
- Latch should align with inversion codebar.

To Adjust

- With screw on inversion bail friction tight, move adjustable extension to obtain clearance.

2.16 Codebar Assembly (continued)



CODEBAR

ADJUSTING SCREW

LATCHING BAIL

INVERSION BAR LATCHING BAIL SPRING
(LATER DESIGN)

(1) Requirement

Min 2-1/2 oz---Max 3-1/2 oz
to move no. 5 inversion bail.

(2) Requirement

Min 1-1/2 oz---Max 2-1/2 oz
to move no. 8 inversion bail.

INVERSION CODEBAR LATCH
(LATER DESIGN)

Requirement


Signal generator clutch disengaged.

Min 0.002 inch---Max 0.012 inch

Gap between number 5 and 8 inversion codebars and their respective latches. Check clearance at both the number 5 and 8 inversion codebars and adjust to whichever is closest.

To Adjust

With respective screws on inversion bail latch friction tight, move adjustable extension to obtain clearance. Tighten screws and recheck clearance.




CODEBAR

ADJUSTING SCREW

LATCHING BAIL

2.17 Signal Generator Mechanism (continued)

Note: On units equipped with signal regenerators, remove regenerator circuit card before applying test set probes to contact access terminals.

SIGNALING CODE CONTACT (STROBING)

Procedure

- (1) Disconnect arc suppressor or RF filter. Reconnect signal generator contacts so current to stroboscope lamp of DXD test set is interrupted. Synchronize signal generator with DXD so end of stop pulse image is in line with "0" mark or start pulse on DXD scale when transmission is continuous and both units are operating at 100 wpm (600 rpm).

Note: If end of stop pulse varies, adjust the scale so the variation extends equally to either side of "0" mark of start pulse on scale. Numbers in parenthesis () are for units using timing contacts.

- (2) Nominal length of intelligence pulses is 100 divisions. If adjustment to feeler gauges does not permit pulse lengths within tolerance, refine SIGNAL CONTACT CLEARANCE Par. 2.05 adjustment. Favor intelligence pulses by using up to ± 8 divisions tolerance on beginning of stop pulse, so each is near as possible to 100 divisions in length.

Requirement


- (1) Each marking code pulse to begin not later than 8 (12) mark and no earlier than 92 (88) mark of previous pulse.
- (2) Each marking code pulse to end not earlier than 92 (88) mark or later than 8 (12) mark in pulse following one being observed.
- (3) Marking code pulses may have break not more than 3 divisions wide and occurs only at end of code pulse image between the 92 (88) mark and end of image.
- (4) Stop image should not change in length or position more than 1 division while changing from R to Y selection (or equivalent permutations for other codes).

Note: If necessary, reposition stabilizer mechanism so end of stop image coincides with "0" mark of start pulse on scale. (Do not remove scale.)

- (5) DXD strobing should yield allowable spacing signal distortion of $\pm 12\%$.

To Adjust

Loosen mounting screws and move contact box by means of eccentric.




ECCENTRIC

2.18 Keyboard Mechanism (continued)


(A) CODE LEVER SPRING

- (1) Requirement
Min 1 oz---Max 2 oz
to start code lever moving downward.
- (2) Requirement
Power on generator clutch disengaged.
Min 3 oz---Max 5 oz
to operate keylever or spacebar.



(B) LOCAL CARRIAGE RETURN FUNCTION BAIL SPRING
(COMBINED CODE LEVER AND BAIL SPRING)

- Requirement
Min 1 oz---Max 3 oz
to move keylever downward.



2.19 Codebar Assembly (continued)

(B) TRANSFER LEVER LOCKING BAIL SPRING


Requirement

Spring unhooked from post
Min 5 oz---Max 7 oz
to pull to installed length.

(A) TRANSFER LEVER SPRING

Requirement

Clutch disengaged
Min 1-1/2 oz---Max 2-1/2 oz
to start each of 10 levers moving.




2.20 Interrelated Features


MARGIN INDICATOR SPRING

Requirement

Min 7 oz---Max 11 oz
to move lever up free of pin.



2.21 Interrelated Features (continued)



MOUNTING TYPING UNIT ON KEYBOARD

Requirement

When placing the typing unit on the base, hold it tilted slightly to the right. Lower the right end into engagement with the right locating stud. While easing the left end downward, rotate the motor by hand to properly mesh the gears. Secure by four mounting screws. Rotate the motor by hand to insure proper meshing of gears.


SIGNAL GENERATOR FRAME

Requirement

With typing unit mounted in position, there should be a perceptible amount of backlash between the signal generator driven gear and the signal generator driving gear at the point where backlash is the least.

To Adjust

Remove the signal generator frame rear mounting screw and loosen the shim screw. Add or subtract shims as required.




2.22 Interrelated Features (continued)

INTERMEDIATE GEAR ASSEMBLY**Requirement**

Backlash between motor pinion and its driven gear, and between typing unit main shaft gear and its driving gear
 Min 0.004 inch---Max 0.008 inch
 as gauged by feel.

To Adjust

Loosen intermediate gear assembly mounting screws (4). Loosen two locknuts which lock adjusting bushings at rear of assembly. Loosen nut plate mounting screw just in front of gear bracket. Move assembly backward or forward and adjust height at rear by means of adjusting bushing nearest motor (back out other bushing for clearance after correct adjustment is obtained). Lock adjusting bushing nut, turn other bushing with fingers until it touches base, and tighten locknut.

MOUNTING REPERFORATOR UNIT ON KEYBOARD (NOT ILLUSTRATED)**Requirement**

The reperforator should be mounted so that the jack shaft is in alignment with rear bearing bracket shaft end and is perpendicular to rear motor shaft.

To Adjust

Loosen setscrews in flexible coupling and slide coupling out of engagement with rear bearing bracket shaft. Loosen two screws on alignment bracket. Loosen four reperforator mounting screws. Align reperforator jack shaft with rear bearing bracket shaft and tighten reperforator mounting screws. Snub alignment bracket against reperforator casting and tighten two screws. If the shafts are not in alignment at this point, adjust rear bearing bracket to left or right until shafts are in alignment. Position and fasten flexible coupling.

3. VARIABLE FEATURES

3.01 Timing Contact Mechanism (Early Design)

TIMING CONTACT

(1) Requirement


Contacts should be closed when nylon pad is raised 0.007 inch.
Contacts should be open when nylon pad is raised 0.015 inch.

To Check

Identification mark viewed on top side of hex and
follower on low part of cam.

(2) Requirement

Min 0.003 inch gap between contacts with the follower on any peak of cam.
Min 0.0015 inch gap on units prior to serial #88,800.



To Adjust

Loosen two timing contact bracket posts. With screwdriver
between bracket upright and rear plate, adjust gap
Min some---Max 0.010 inch
adjust eccentric screw to meet requirements.

Note: Use signal checking device to refine this adjustment.

3.02 Timing Contact Mechanism (Early Design) (continued)

(A) CONTACT SWINGER

Requirement

Contacts closed
 Min 2 oz---Max 3-1/2 oz
 to just open contacts.


To Adjust

Use TP110455 spring bender.

(B) CAM FOLLOWER SPRING

Requirement

Signal generator latched. Contact
 spring held back
 Min 6 oz
 to start cam follower moving.



(C) CONTACT STIFFENER

Requirement

Contact open
 Min 5 oz---Max 8 oz
 to move contact.

To Adjust

Remove transparent contact guard. Remove contact assembly from unit by removing two posts securing it to rear plate. Loosen two screws holding contact pile-up to contact bracket. Bend contact using TP110445 spring bender.

Note: Check CONTACT SWINGER Par. 3.02 and refine if necessary. Remake Par. 3.01 if necessary.

3.03 Timing Contact Mechanism (Later Design)

TIMING CONTACT

(1) Requirement

With unit in the stop position, there should be a gap between contact points

Min 0.008 inch---Max 0.011 inch


(2) Requirement

With the cam follower on the low part of the cam, and the clearance taken up between the plunger and the cam follower, there should be some clearance between plunger and contact point.


To Adjust

Loosen the two posts holding the timing contact bracket to friction tightness. Position the bracket in order to meet (1) and (2) Requirements. Tighten the posts and recheck the adjustment.

Note: If available, use a signal checking device to refine the adjustment.



3.04 Timing Contact Mechanism (Later Design) (continued)



CAM FOLLOWER SPRING

To Check

Timing contact assembly must be moved out of contact with the cam follower, and spring post must be tightened to check this requirement and TIMING CONTACT SWINGER SPRING adjustment.

Requirement

With the signal generator in the latched position, apply the pull end of the scale to the cam follower.

Min 6 oz---Max 9 oz
to start cam follower moving.

3.05 Timing Contact Mechanism (Later Design) (continued)



TIMING CONTACT SWINGER SPRING

(1) Requirement

Contact points should be in line and the head of the plunger should be centered in its hole in the spring as gauged by eye.

To Adjust

Position contact springs with screws friction tight. Tighten screws.



(2) Requirement

With plunger depressed flush with its bushing, contact cap should be
 Min 0.045 inch---Max 0.065 inch

To Adjust

Bend spring.


(3) Requirement

With contacts closed
 Min 3-1/2 oz---Max 4-1/2 oz
 to just open contacts.

To Adjust

Bend spring. Recheck timing contact adjustment.

3.06 Timing Contact Mechanism (continued)



TIMING CONTACT (STROBING)

- (1) Zero the test set as described in procedure (1) of Par. 2.17.
- (2) The light image of the timing contacts should meet the following requirements for speeds up to and including 100 words per minute.
 - (A) Open for a minimum of 20 divisions between the 25 division and 75 division points of each 100 division pulse.
 - (B) Open for a minimum of 120 divisions between the 25 division and 175 division points of the stop pulse.
 - (C) The close to open transitions should be in multiples of 100 divisions ± 5 divisions of the start pulse.
 - (D) There should be no contact break between the zero division point and the close to open transition point, and no contact break between the 75 division point and the 100 division point of each pulse. There should be no contact break between the 175 division point and the 200 division point of the stop pulse.

To Adjust

Check and refine, if necessary, adjustment in Par. 3.01.


Note: The timing contacts should be open when the clutch is disengaged.

3.07 Local Backspace Mechanism

TRANSFER BAIL ADJUSTING LEVER

Requirement

Downward pressure on backspace key
 Min 16 oz---Max 28 oz
 to operate backspace lever.



TRANSFER BAIL
 ADJUSTING LEVER

To Adjust

Position transfer bail adjusting lever with its mounting screw loosened. If unit is forward spacing, the adjusting lever must be raised until proper backspacing is accomplished.


Note 1: This adjustment may require remaking when a different typing unit is used.

Note 2: The camming bail should return to its unoperated position when the key-lever is released. Refine adjustment if necessary.

TRIP LINK HORIZONTAL SPRING

Requirement

Unhook spring
 Min 1-3/4 oz---Max 3 oz
 to pull spring to installed length.



TRIP LINK VERTICAL SPRING

Requirement

Unhook spring
 Min 1-1/2 oz---Max 3 oz
 to pull spring to installed length.

TRANSFER BAIL SPRING

Requirement

Unhook spring
 Min 1/2 oz---Max 1 oz
 to pull spring to installed length.

3.08 Receive-Break Switch Mechanism

RECEIVE-BREAK SWITCH

Requirement

The bail should operate the contact pile-up with some overtravel.

To Check

Keyboard lock plunger in downward position. Function bail latched.

To Adjust

Loosen lock nut on adjusting screw and position screw. Recheck for overtravel.

RECEIVE-BREAK SWITCH TENSION


Requirement

Normally open contacts should close and normally closed contacts should open

Min 10 oz---Max 16 oz

To Adjust

Bend leaves carefully to meet requirements.



3.09 Codebar Arrangement for Even Parity

CLUTCH TRIPBAR SPRING

Requirement

Clutch disengaged. Power off.
Min 8 oz---Max 12 oz
to move bar.


CODEBARS, SHIFT AND CONTROL LOCKBAR, COUNTER AND RETURN BAR SPRINGS

Requirement

Depress rubout or delete key.
Power off. Transfer levers held right

Min 5 oz---Max 7-1/2 oz
(no. 4, 5, 7, and 8 codebars)


Min 2 oz---Max 4 oz
(all remaining bars)
to start bar moving.



NO. 5 AND NO. 8 INVERSION BAR SPRING

Requirement

Codebar in latched position.
Unhook spring at guide
Min 6 oz---Max 8 oz
to pull to installed length.



TRANSITION BAR SPRING

Requirement

Unhook spring at guide
Min 1/2 oz---Max 1-1/2 oz
to pull to installed length.


3.10 Local Single Line Feed Mechanism

TRIP LINK VERTICAL SPRING

Requirement

Unhook spring

Min 4 oz---Max 5 oz
to pull spring to installed length.



(Left View)

TRIP LINK HORIZONTAL REAR SPRING

Requirement

Unhook spring

Min 1-1/2 oz---Max 3-1/2 oz
to pull spring to installed length.

TRIP LINK FRONT SPRING

Requirement

Unhook spring


Min 1-1/2 oz---Max 2-1/2 oz
to pull spring to installed length.

3.11 Reperforator Backspace Actuating Switch Mechanism

OPERATING PAD GAP

Requirement

Depressing LOC BSP key should close normally open reperforator backspace actuating switch.




To Adjust

Check with ohmmeter, shift switch assembly on mounting holes.

Note: Ideal condition exists when printer and reperforator backspace simultaneously. To achieve, adjust by trial and error with printer and reperforator mounted. If reperforator backsplaces before printer, increase gap between contact operating pad and backspace operating bail. If printer backsplaces first, decrease gap.

3.12 Keyboard Universal Contact Mechanism



CONTACT GAP

Requirement

With clutch latched
Min 0.010 inch---Max 0.020 inch
contact gap.

To Adjust

Carefully bend contact spring to meet requirement.

3.13 Tape Alarm

TAPE ALARM SWITCH

Requirement

Switch should operate when roll of tape is reduced in diameter
Min 2-3/8 inch---Max 2-1/2 inch


To Adjust

With switch assembly mounting screws loosened, position assembly
in tape container to meet requirement. Bend tape arm if necessary.

TAPE ARM SPRING


Requirement

Hook spring scale over tape lever and pull in line with spring
Min 6 oz---Max 10 oz
to release spring.



3.14 Character Counter Mechanism

Note: Character counter adjustments may be facilitated by removing the assembly from the keyboard except for Par. 3.16, character counter stroke.




3.15 Character Counter Mechanism (continued)

(A) RATCHET DRUM ASSEMBLY RETURN SPRING

Requirement

- Min 1/2 oz---Max 1-1/2 oz
when indicator points to 35 on the scale.
- Min 1-1/2 oz---Max 2-1/2 oz
when indicator points to 70 on the scale.



(B) END-OF-LINE SWITCH

(1) Requirement

Switch leaves should be approximately parallel to switch mounting bracket as gauged by eye. Upper switch leaf should clear low part of cam
Min some---Max 0.025 inch
at closest point.

To Adjust

Loosen switch bracket mounting screws and position assembly.

(2) Requirement

Clearance between contacts of switch leaves should be
Min 0.005 inch---Max 0.020 inch

To Adjust

Bend lower leaf of switch.

(3) Requirement

Switch should close at a preset number of characters with a small amount of overtravel by both contact leaves.

To Adjust

Set indicator to count desired. Loosen clampscrews and adjust cam until switch just closes. Tighten screws. Check operation and refine 1, 2, and 3 if necessary.

3.16 Character Counter Mechanism (continued)

(A) CHARACTER COUNTER STROKE

Requirement - Mount Assembly on Keyboard

When character and REPEAT keys are depressed, the counter should operate consistently in T or K-T position. When CARRIAGE RETURN key is depressed, the counter should reset without binding. The mechanism should count the first character on a restart after reset condition.

Min 0.006---Max 0.015 inch
between drive lever and ratchet tooth, when counter is set near midpoint of its range.


To Adjust

Loosen mounting screws. With keyboard in T position, start motor and strike CARRIAGE RETURN key, and then E key. Turn off motor. Depress E key. Position character counter frame for clearance. Turn control knob to K-T position and recheck. Refine if necessary.

(B) RESET LATCHLEVER AND DRIVE LEVER SPRING

Requirement


Min 1/2 oz---Max 1 oz
to move either lever.



(C) RESET LEVER EXTENSION SPRING

Requirement

With the codebars latched
Min 1/2 oz---Max 1-1/4 oz
to start lever moving.



3.17 Auxiliary Contact Mechanism

CONTACT GAP

Requirement


Clutch latched, cam follower on high part of cam.

Contact gap should be

Min 0.005 inch---Max 0.015 inch

To Adjust

Loosen posts that hold contact bracket. Position bracket by use of screwdriver placed between bracket upright and rear plate.



See Par. 3.02 for requirements of:

- (A) CONTACT SWINGER
- (B) CAM FOLLOWER SPRING
- (C) CONTACT STIFFENER

See Par. 3.23 for AUXILIARY CONTACT REFINEMENT (STROBING).

3.18 Code Reading Contact Mechanism

Note 1: Adjustments on this page should be made with the contact assembly removed from the keyboard.

Note 2: Each adjustment should start with the contact pile-up farthest from the handle of the bending tool. See Par. 3.19.

(A) BACKSTOP - NORMALLY CLOSED CONTACT

Requirement

Normally closed contact leaf should be parallel to mounting plate and align with each other by 0.010 inch.

To Adjust

Bend backstop.

(D) NORMALLY OPEN CONTACT GAP

Requirement

Min 0.018 inch---Max 0.030 inch normally open gap.

To Adjust

Bend backstop.

(C) CONTACT SWINGER SPRING

Requirement

Min 30 grams---Max 40 grams to open the closed contact.

To Adjust

Bend swinger.



(B) NORMALLY CLOSED CONTACT SPRING

Requirement

Min 2 oz---Max 6 oz to move contact spring away from backstop. Hold swinger away from closed contact.

To Adjust


Bend spring. To increase tension against backstop, bend backstop away from spring leaf and form leaf toward backstop, then reposition backstop per BACKSTOP - NORMALLY CLOSED CONTACT Par. 3.18.




3.19 Code Reading Contact Mechanism (continued)

ADJUSTING CODE READING CONTACTS

- (1) The contact assembly should be removed from the keyboard to perform the adjustments of Par. 3.18. It is not necessary to remove the wires from the assembly.



- (2) Each adjustment should start with the contact pile-up farthest from the handle of the bending tool.



- (3) After adjusting contact pile-ups 4, 5I, 3, 2, and 1, insert the bending tool in the opposite side of the assembly and adjust contact pile-ups 5, 6, 7, and 8 in the order given.

3.20 Code Reading Contact Mechanism (continued)

Note: Perform LATCHLEVER SPRING. Then install contact assembly on the keyboard for the remaining code reading contact adjustments.

(B) MARKING CONTACT GAP


Requirement

With the clutch latched
 Min 0.005 inch---Max 0.015 inch
 contact gap.

To Adjust

Loosen four contact mounting bracket screws.
 Position contact adjustment mounting bracket.

CAUTION: DO NOT APPLY FORCE TO CONTACT PILE-UP.



(C) INTERMEDIATE LEVER SPRING

Requirement

With the clutch latched
 Min 1 oz---Max 2 oz
 to pull spring to installed length.

(A) LATCHLEVER SPRING

Requirement

With the clutch latched
 Min 2 oz---Max 4 oz
 to pull spring to installed length.

3.21 Code Reading Contact Mechanism (continued)

RESET BAIL

Requirement


Gap between any one latch and its intermediate lever should be
Min 0.010---Max 0.030 inch

To Check

Clutch unlatched and keyboard eccentric drive arm extension to extreme left.

To Adjust

Loosen four mounting plate screws and position assembly.



DRIVE ARM EXTENSION SPRING


Requirement

Clutch latched
Min 4 oz---Max 5 oz
to pull spring to installed length.

RESET BAIL SPRING

Requirement

Clutch latched
Min 1/2 oz---Max 1-1/2 oz
to pull spring to installed length.



3.22 Code Reading Contact Mechanism (continued)

Note 1: The following tests should be performed after the contact assembly has been installed and all adjustments have been made.

Note 2: Minimum signal lengths apply to time between latest start and earliest end of all contact traces.

CODE READING CONTACT REFINEMENT (STROBING)**(1) Requirement**

Zero the strobe unit (DXD) as follows:

- (A) Connect strobe neon trace to code reading contact no. 1. Send rubout combination from keyboard. Note latest point at which trace begins.
- (B) Repeat step (A) for all code reading contacts.
- (C) Choose trace that starts latest and set START-ZERO mark of strobe scale to this point.
- (D) Record earliest end of neon traces for future adjustment references.

(2) Requirement

Connect neon trace lamp to marking contact (contact that is normally open when keyboard is idle) of code reading contact assembly.

- (A) Send rubout combination from keyboard.
- (B) Combined code reading contact traces should have minimum signal length of 500 divisions (length between latest start and earliest end) and all bounce should end within 20 divisions of latest start of a contact trace. See Par. 3.23 for figure of strobe trace.
- (C) Repeat (A) and (B) for each code reading contact.

To Adjust

Refine Par. 3.18(A).

Refine Par. 3.18(B) and (C) if there is excessive bounce.

3.23 Auxiliary Contact Mechanism (continued)

AUXILIARY CONTACT REFINEMENT (STROBING)

Requirement (See Notes 1 and 2 in Par. 3.22)

Zero the strobe unit (DXD) as explained in (1) Requirement of Par. 3.22.


Connect strobe neon trace to auxiliary contacts.

(A) Send rubout combination from keyboard.

(B) End of neon trace should occur at a minimum of 22 divisions before earliest end of code read contact traces (including any bounce). Start of trace should begin at a minimum of 143 divisions after the strobe START-ZERO mark. The pulse must be at least 250 divisions long.


To Adjust

Refine adjustment in Par. 3.17.




3.24 Strobing Requirements

SIGNAL GENERATOR CONTACTS



CODE READING AND TIMING CONTACTS



Note 1: For units equipped with signal regenerators, remove regenerator circuit card before applying test set probes to signal contacts.

Note 2: Applying operating voltage of signal distortion test set directly to gold-plated signal contacts may make them unsuitable for low-voltage applications. See Par. 1.07 for servicing instructions.

35 TAPE READER*BASES (FOR ASR SETS)

ADJUSTMENTS AND LUBRICATION

CONTENTS	PAGE
1. GENERAL	1
2. ADJUSTMENTS	1
General	1
Single reader bases (low speed motor)	2
Double reader bases (low speed motor)	3
Single reader bases (high speed motor)	5
Double reader bases (high speed motor)	7
3. LUBRICATION	7
1. GENERAL	

1.01 This section is reissued to include information pertinent to new models, and to rearrange text. Lubrication procedures,

formerly covered in section 574-223-701 have been included in this section.

1.02 The primary concern of this section is the description, adjustment and lubrication of the bases which mount 35 tape readers and answer-back or distributor units in ASR sets. For information regarding principles of operation and description, refer to other related 574-223-series sections.

2. ADJUSTMENTS

2.01 General. Gear arrangements vary from base to base depending upon the type of drive motor and the number and types of equipment mounted on the base. The gear adjustments following treat the bases in four major groups; single reader (low speed motor), double reader (low speed motor), single reader (high speed motor), and double reader (high speed motor).

* "Tape reader" is a general term applying to units often referred to as transmitters or transmitter distributors.




Figure 1 - 35 Tape Reader Base (Typical)

2.02 Single Reader Bases (Low Speed Motor)

Note: The procedure following is for a complete adjustment. Removal of a single component (motor, reader, or answer-back) will not normally require a complete re-adjustment. Perform adjustment in order given ((A), (B), (C), etc). Loosen reader, motor, and answer-back mounting screws before beginning a complete adjustment.


(A) TAPE READER

Requirement

Tape reader should be positioned midway between left and right adjustment extremes.

To Adjust

Position reader to meet requirement.
Tighten reader mounting screws.



(C) ANSWER-BACK IDLER GEAR

Requirement

With all play in answer-back mounting holes taken up in the direction toward the motor. There should be

Min 0.004 inch---Max 0.008 inch backlash between idler gear and answer-back mainshaft gear and between idler gear and answer-back drive pinion, at the point of minimum clearance.

To Adjust

Loosen answer-back idler gear bracket. Take up adjustment play toward motor and tighten answer-back mounting screws. Position idler gear to meet requirement and tighten bracket locking screws.

(B) READER DRIVE PINION

Requirement

There should be a
Min 0.004 inch---Max 0.008 inch backlash between the reader drive pinion and reader gear at the point of minimum clearance.

To Adjust

Position motor to meet requirement.
Tighten motor mounting screws.

2.03 Double Reader Bases (Low Speed Motor)

(A) READER IDLER GEARS


Requirement

Reader idler gear shaft should be positioned midway between left and right extremes.

To Adjust

Position the shaft brackets at their mid-adjustment position and tighten bracket mounting screws.

Note: The procedure following is for a complete adjustment. Removal of a single component (motor, reader, or answer-back) will not normally require a complete readjustment. Perform adjustment in order given ((A), (B), (C), etc). Loosen reader, idler gear shaft, motor, and answer-back mounting screws before beginning complete adjustment.



(B) TAPE READER GEARS

Requirement

There should be a
 Min 0.004 inch---Max 0.008 inch backlash
 between the reader idler gear and its associated reader gear at the point of minimum clearance.

To Adjust

Position each reader to meet requirement and tighten reader mounting screws.

2.03 Double Reader Bases (Low Speed Motor) (Continued)

(C) READER DRIVE PINION


Requirement

There should be

Min 0.004 inch---Max 0.008 inch backlash between the rear reader gear and the reader drive pinion at the point of minimum backlash.

To Adjust

Position the motor to meet requirements.
Tighten motor mounting screws.



(D) ANSWER- BACK IDLER GEAR

Requirement

With all play in answer-back mounting holes taken up in the direction toward the motor, there should be

Min 0.004 inch---Max 0.008 inch backlash between idler gear and answer-back mainshaft gear and between idler gear and answer-back drive pinion measured at point of minimum clearance.

To Adjust

Loosen answer-back idler gear bracket locking screw. Take up play and tighten mounting screws. Position idler gear to meet requirements and tighten locking screw.

2.04 Single Reader Bases (High Speed Motor)

Note: The procedure following is for a complete adjustment. Removal of a single component (motor, reader, or answer-back, or distributor) will not normally require a complete readjustment. Perform adjustments in the order given ((A), (B), (C), etc). Loosen reader, connector bracket (if so equipped), drive shaft bracket, motor, and answer-back or distributor unit mounting screws before beginning a complete adjustment.

(A) DRIVE GEAR SHAFT

Requirement

The drive gear shaft should be positioned midway between left and right mounting extremes.

To Adjust

Position the shaft brackets at their mid-adjustment position and tighten bracket mounting screws.

(C) CONNECTOR BRACKET ADJUSTMENT


(For those bases on which the reader mating connector is rigidly fixed)

Requirement

The connector should mate with the connector on the bottom of the reader and be fully engaged.

To Adjust

Position connector bracket to meet requirements and tighten mounting screws.



(B) TAPE READER GEAR

Requirement

There should be
Min 0.004 inch---Max 0.008 inch backlash
between the reader gear and reader drive
gear at the point of minimum clearance.

To Adjust

Position reader to meet requirement and
tighten reader mounting screws.

2.04 Single Reader Bases (High Speed Motor) (Continued)

(D) MOTOR PINION

Requirement

There should be

Min 0.004 inch---Max 0.008 inch backlash between the reader gear and motor pinion at the point of minimum clearance.

To Adjust

Position motor to meet requirements and tighten motor mounting screws.

(E) DISTRIBUTOR MAINSHAFT GEAR

(Applies only to bases which mount distributor units)

Requirement

There should be

Min 0.004 inch---Max 0.008 inch backlash between answer-back/distributor drive gear and distributor mainshaft gear at the point of minimum clearance.

To Adjust

Position distributor unit to meet requirements and tighten mounting screws.

(F) ANSWER-BACK IDLER GEAR

(Applies only to bases which mount answer-back units)

Requirement

With all play in answer-back mounting holes taken up in the direction toward the motor, there should be

Min 0.004 inch---Max 0.008 inch backlash between idler gear and answer-back/distributor drive gear measured at the point of minimum clearance.

To Adjust

Loosen answer-back idler gear bracket locking screw. Take up play and tighten unit mounting screws. Position idler gear to meet requirement and tighten locking screws.

ANSWER-BACK DISTRIBUTOR DRIVE GEAR

ANSWER-BACK IDLER OR DISTRIBUTOR MAINSHAFT GEAR

ANSWER-BACK OR DISTRIBUTOR UNIT

MOTOR (3600 RPM)

ANSWER-BACK MAINSHAFT GEAR


MOTOR PINION

SPEED CHANGE GEAR

READER GEAR


READER UNIT

READER DRIVE GEAR



2.05 Double Reader Bases (High Speed Motor)

Adjustment of gears on double reader bases (below) is the same as for single unit bases (2.04) except that one additional reader must be positioned.



3. LUBRICATION

3.01 The tape reader base should be lubricated just prior to placing the unit in service. Thereafter, lubricate every 1500 hours of operation or every six months, whichever occurs first.

3.02 Apply a thin film of KS7471 grease to the surface of all gears EXCEPT THE ANSWER-BACK DRIVE GEAR (OR PINION),

THE ANSWER-BACK IDLER GEAR, AND THE ANSWER-BACK MAIN SHAFT GEAR (see adjustment illustrations). On those bases which mount a distributor unit rather than an answer-back, both the distributor drive gear and main-shaft gear should be lubricated along with all other gears.

3.03 Apply a few drops of KS7470 oil to the oiler holes at each end of the motor.

35 NON-TYPING REPERFORATOR

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	1-4	Range finder knob phasing	15
2. ADJUSTMENTS	4-38	Release downstop bracket	18
Adjusting arm torsion spring	19	Reset arm	17
Armature bail spring (bksp.)	38	Reset bail trip lever	24
Armature hinge (bksp.)	33	Rocker bail	20
Armature up-stop (bksp.)	33	Rocker bail guide bracket	20
Bell crank spring (bksp.)	38	Selector armature	8
Clutch shoe lever	5	Selector armature downstop bracket	8
Clutch shoe lever spring	6	Selector armature spring (final) . . .	10
Clutch shoe spring	6	Selector armature spring (
Detent lever spring	30	units employing selector arma- ture with single anti-freeze	
Drive link (bksp.)	34	button only)	9
Feed hole spacing	27	Selector armature spring (For	
Feed hole spacing (final)	27	units employing selector arma- ture with two anti-freeze	
Feed hole spacing (preliminary) . . .	27	buttons only)	10
Feed pawl	25	Selector cam lubricator	7
Feed pawl clearance (bksp.)	32	Selector clutch drum	13
Feed pawl (preliminary (bksp.) . . .	32	Selector clutch latch lever spring . .	14
Feed pawl spring	30	Selector clutch stop arm	15
Feed pawl spring (bksp.)	38	Selector lever spring	13
Final power or manual (bksp.)	35	Selector magnet bracket	11
Follower lever	19	Selector oil shield	7
Function clutch drum end play	5	Selector push lever spring	13
Function clutch latch lever spring . .	6	Selector receiving margin	16
Function clutch release spring	18	Spacing lock lever spring	14
Function clutch trip lever	17	Start lever spring	16
Latch (bksp.)	36	Tape depressor slide spring	31
Latch extension (bksp.)	35	Tape guide	31
Latch extension spring (bksp.)	38	Tape guide spring (punch block) . . .	29
Latch lever clearance	25	Tape guide spring (tape chute)	29
Lateral and front to rear feed wheel position (early design)	26	Tape shoe torsion spring	31
Lateral and front to rear feed wheel position (latest design)	28	Toggle bail eccentric (preliminary) .	22
Main trip lever spring	19	Toggle operating arm	22
Marking lock lever spring	12	Trip cam follower lever	19
Non-repeat latch (bksp.)	37		
Perforator drive link spring	22	1. GENERAL	
Perforator position (final)	21	1.01 This section is reissued to:	
Perforator position (preliminary) . .	21	(a) Include recent engineering changes.	
Punch pin penetration	23	(b) Include armature with two anti-freeze buttons.	
Punch slide downstop position	23		
Punch slide guide	23		
Punch and feed slide latch springs . .	19		
Punch slide spring	29		
Push lever reset bail spring	14		




Figure 1 - 35 Non-Typing Reperforator (Right Front View)

- (c) Include lateral and front to rear feed wheel adjustment (early design).

1.02 This section contains specific requirements and adjustments for the 35 Non-Typing Reperforator (Fig. 1). The basic equipment includes selector mechanism, fully perforating punch mechanism and power driven backspace mechanism. The unit is designed for adaptation either by a single shaft or by a main shaft and jack shaft to power supplied from a base mounted motor. Where there are differences in the adjustment procedures for single shaft and double shaft units, these are noted in the adjustment text and illustrations. Motors and bases are covered in the applicable sections.

1.03 Reference to left or right, front or rear and up or down refer to the apparatus in its normal operating position, as viewed from the front with the selector mechanism to the right and the punch mechanism to the left. It is assumed that the elements depicted in illustrations in this section are being viewed from a position in front of the equipment, unless the illustrations are specifically labeled otherwise. In the illustrations, pivot points are shown by circles or ellipses that are solid black to indicate fixed points and cross-hatched to indicate floating points.

1.04 Tools required to make the adjustments and test the spring tensions are listed in the appropriate section. Spring tensions given in this section are indications, not exact values, and should be checked with the correct scale applied in the positions shown in the drawings.

1.05 The unit is in its unoperated, or stop, condition when it is not under power. It is in its idling condition when it is under power and clutches are disengaged (steady marking condition of signal line).

CAUTION: APPARATUS SHOULD NOT BE SEPARATED FROM ITS PROTECTIVE HOUSING UNLESS POWER IS DISCONNECTED. WHERE OPERATION OF THE EQUIPMENT IS REQUIRED AFTER IT HAS BEEN SEPARATED FROM ITS PROTECTIVE HOUSING, APPROPRIATE PRECAUTIONARY MEASURES SHOULD BE TAKEN TO PREVENT ACCIDENTS.

1.06 When a requirement calls for a clutch to be DISENGAGED, the clutch shoe lever must be fully latched between its trip lever (or stop arm) and latch lever. The main shaft will then turn freely without the clutch shoes dragging. When the clutch is ENGAGED, the shoe lever and cam disk stop lug are moved apart, and the clutch shoes are wedged against the drum so that the clutch turns with the shaft.

Note: If the shaft is turned by hand, the clutch will not fully disengage upon reaching its stop position. Where a procedure calls for disengagement, rotate the clutch to its stop position, apply a screwdriver to the cam disk stop lug and turn the disk in the normal direction of shaft rotation until the latch lever seats in its notch in the disk.

1.07 To manually operate the 35 Non-Typing Reperforator, proceed as follows:

(a) Attach the armature clip to the selector magnet armature by carefully putting the flat formed end of the armature clip over the top of the armature between the pole pieces and then hooking the projection under the edge of the armature. The spring tension of the armature clip will hold the selector armature in the marking (attracted) position.

(b) While holding the selector magnet attracted by means of the armature clip, manually rotate the main shaft in a counterclockwise direction until all the clutches are brought to their disengaged position.

(c) Fully disengage the clutches in accordance with 1.06, Note.

(d) Release the selector magnet armature momentarily to permit the selector clutch to engage.

(e) Rotate the main shaft slowly until all the push levers have fallen to the left of their selecting levers.

(f) Strip the push levers from their selector levers if they are spacing in the code combination of the character or function that is being selected. Allow the push levers to

move to the right. The push levers and selector levers move in succession, starting with the inner lever No. 1, to the outer lever No. 8.

(g) Continue to rotate the main shaft until all operations initiated by the selector action clear through the unit.

1.08 Parts dismantled to facilitate checking or readjustment should be reassembled after the operation is completed. If a part mounted on shims is to be dismantled, the number of shims used at each mounting screw should be noted so that the same shim pile-ups can be replaced when the part is remounted. When parts removed are replaced, related adjustments which may have been affected should be checked.

1.09 Parts that are worn to the extent that they can no longer be made to meet the specified requirements by authorized adjustments or which are worn to the extent that it seems probable that early further wear might cause a loss of adjustment should be replaced by new parts. Springs which do not meet the

requirements and for which there are no adjusting procedures should be discarded and replaced by new springs.

1.10 All contact points should meet squarely. Smaller points should fall wholly within the circumference of larger mating points. Points that are the same size should not be out of alignment more than 25 per cent of the point diameter. Avoid sharp kinks or bends in the contact springs.

Note: Keep all electrical contacts free of oil and grease.

2. ADJUSTMENTS

2.01 The following figures show the adjusting tolerances, position of parts and spring tensions. The illustrations are arranged so that the adjustments are in the sequence that would be followed if a complete readjustment of the apparatus were being made. In some cases, where an illustration shows interrelated parts, the sequence that should be followed in checking the requirements and making the adjustments is indicated by the letters (A), (B), (C), etc.

2.02 Selector and Function Mechanisms

CLUTCH SHOE LEVER (BOTH CLUTCHES)REQUIREMENT

GAP BETWEEN CLUTCH SHOE LEVER AND ITS STOP LUG SHOULD BE 0.055 INCH TO 0.085 INCH GREATER WHEN CLUTCH IS ENGAGED THAN WHEN CLUTCH IS DISENGAGED.

TO CHECK


DISENGAGE CLUTCH AND MEASURE GAP. ALIGN HEAD OF DRUM MOUNTING SCREW WITH STOP LUG. ENGAGE CLUTCH. MANUALLY PRESS SHOE LEVER AGAINST STOP LUG AND ALLOW TO SNAP APART. MEASURE GAP WITH CLUTCH ENGAGED.

TO ADJUST

ENGAGE WRENCH OR SCREWDRIVER WITH LUG ON ADJUSTING DISK. ROTATE DISK WITH CLAMP SCREWS LOOSENED.

NOTE

AFTER MAKING ADJUSTMENT, DISENGAGE CLUTCH. REMOVE DRUM MOUNTING SCREW. ROTATE DRUM IN NORMAL DIRECTION AND CHECK TO SEE IF IT DRAGS ON SHOE. IF IT DOES, REFINE ADJUSTMENT.

FUNCTION CLUTCH DRUM END PLAY (FOR UNITS EQUIPPED WITH TWO SHAFTS)REQUIREMENT


FUNCTION CLUTCH DISENGAGED. SOME END PLAY BETWEEN CAM SLEEVE AND COLLAR

MAX. 0.015 INCH

WHEN PLAY IS TAKEN UP TO MAKE CLEARANCE A MAXIMUM.

TO ADJUST

POSITION COLLAR WITH MOUNTING SCREW LOOSENED.

FUNCTION CLUTCH DRUM END PLAYREQUIREMENT

WITH FUNCTION CLUTCH DISENGAGED

MIN. SOME----MAX. 0.015 INCH

WHEN PLAY IS TAKEN UP TO MAKE CLEARANCE MAX.

TO ADJUST

WITH ITS MOUNTING SCREW LOOSENED, MOVE DRUM TO EXTREME FRONT POSITION. TIGHTEN DRUM MOUNTING SCREW. POSITION COLLAR WITH MOUNTING SCREW LOOSENED.

2.03 Selector and Function Mechanisms (Cont.)

CLUTCH SHOE LEVER SPRING TENSION REQUIREMENT

CLUTCH ENGAGED. CAM DISK HELD TO PREVENT TURNING. SPRING SCALE PULLED AT TANGENT TO CLUTCH.

MIN. 16 OZS.
MAX. 22 OZS.

TO MOVE SHOE LEVER IN CONTACT WITH STOP LUG.

CLUTCH SHOE LEVER SPRING
CLUTCH SHOE SPRING

CLUTCH SHOE SPRING TENSION

NOTE



IN ORDER TO CHECK THIS SPRING TENSION, IT IS NECESSARY TO REMOVE CLUTCH FROM MAIN SHAFT. THEREFORE, IT SHOULD NOT BE CHECKED UNLESS THERE IS GOOD REASON TO BELIEVE THAT IT DOES NOT MEET ITS REQUIREMENT.

REQUIREMENT

CLUTCH DRUM REMOVED. SPRING SCALE APPLIED TO PRIMARY SHOE AT TANGENT TO FRICTION SURFACE.

MIN. 3 OZS.
MAX. 5 OZS.

TO START SHOE MOVING AWAY FROM SECONDARY SHOE AT POINT OF CONTACT.



FUNCTION CLUTCH LATCH LEVER SPRING


REQUIREMENT

FUNCTION CLUTCH IN STOP POSITION BUT LATCH LEVER UNLATCHED.

MIN. 12 OZS.
MAX. 15 OZS.

TO START LATCH LEVER MOVING


2.04 Selector Mechanism



OIL SHIELD (IF PRESENT)

REQUIREMENT


- (1) MAGNET DE-ENERGIZED. STOP ARM BAIL ON LOW PART OF ITS CAM. CLEARANCE BETWEEN START LEVER AND OIL SHIELD.
 MIN. 0.020 INCH
 MAX. 0.030 INCH



- (2) MAGNET ENERGIZED. STOP ARM BAIL ON HIGH PART OF ITS CAM. CLEARANCE BETWEEN END OF ARMATURE AND OIL SHIELD.
 MIN. 0.010 INCH

TO ADJUST

POSITION SHIELD WITH MOUNTING SCREW LOOSENED. MAKE SURE OIL SHIELD MOUNTING STUD IS SECURE BEFORE MAKING ADJUSTMENT.



SELECTOR CAM LUBRICATOR

REQUIREMENT

HIGH PART OF SELECTOR LEVER CAMS SHOULD CONTACT LEATHER WICK BUT SHOULD NOT DEFLECT MORE THAN 1/32 INCH GAUGED VISUALLY.


TO ADJUST

POSITION LUBRICATOR ASSEMBLY AROUND LOWER SCREW WITH MOUNTING SCREWS LOOSENED.

2.05 Selector Mechanism (Cont.)

NOTE

TO FACILITATE MAKING THE FOLLOWING ADJUSTMENTS, REMOVE THE RANGE FINDER ASSEMBLY AND SELECTOR MAGNET ASSEMBLY. TO INSURE BETTER OPERATION, PULL A PIECE OF BOND PAPER BETWEEN THE ARMATURE AND THE POLE PIECES TO REMOVE ANY OIL OR FOREIGN MATTER THAT MAY BE PRESENT. MAKE CERTAIN THAT NO LINT OR PIECES OF PAPER REMAIN BETWEEN THE POLE PIECES AND THE ARMATURE.



SELECTOR ARMATURE

NOTE


THESE REQUIREMENTS NEED NOT BE MADE NOR CHECKED IF THE SELECTOR MAGNET BRACKET AND RECEIVING MARGIN REQUIREMENTS ARE MET.

- (1) REQUIREMENT
CLEARANCE
MIN. 0.025 INCH
MAX. 0.045 INCH
BETWEEN ARMATURE CLAMP STRIP AND
MAGNET BRACKET CASTING.

- (2) REQUIREMENT
OUTER EDGE OF ARMATURE SHOULD BE FLUSH WITHIN 0.015 INCH
WITH OUTER EDGE OF POLE PIECES.

- (3) REQUIREMENT
START LEVER SHALL DROP FREELY INTO ARMATURE EXTENSION SLOT.
TO ADJUST

POSITION ARMATURE SPRING ADJUSTING NUT TO HOLD ARMATURE FIRMLY AGAINST PIVOT EDGE OF CASTING. POSITION ARMATURE WITH MOUNTING SCREWS LOOSENED.



SELECTOR ARMATURE DOWNSTOP BRACKET

REQUIREMENT

REMOVE OIL SHIELD. WITH MAGNET DE-ENERGIZED, LOCK LEVERS ON HIGH PART OF THEIR CAM, AND ARMATURE RESTING AGAINST ITS DOWNSTOP, CLEARANCE BETWEEN END OF ARMATURE AND LEFT EDGE OF LEFT POLE PIECE
MIN. 0.025 INCH MAX. 0.030 INCH.

TO ADJUST

POSITION DOWNSTOP BRACKET WITH MOUNTING SCREW LOOSENED. REPLACE OIL SHIELD AND CHECK OIL SHIELD ADJUSTMENT.

2.06 Selector Mechanism (Cont.)

SELECTOR ARMATURE SPRING

(FOR UNITS EMPLOYING SELECTOR ARMATURE WITH SINGLE ANTI-FREEZE BUTTON ONLY).

REQUIREMENT (PRELIMINARY)


WITH LOCKING LEVERS AND START LEVER ON HIGH PART OF THEIR CAMS, SCALE APPLIED AS NEARLY VERTICAL AS POSSIBLE UNDER END OF ARMATURE EXTENSION. IT SHALL REQUIRE THE FOLLOWING TENSIONS TO MOVE ARMATURE TO MARKING POSITION:

- 0.060 AMPERE - MIN. 2-1/2 OZS. --- MAX. 3 OZS.
- 0.030 AMPERE - MIN. 1-1/2 OZS. --- MAX. 2 OZS.
- 0.500 AMPERE - MIN. 4-1/2 OZS. --- MAX. 5-1/2 OZS.

NOTE

THIS SPRING CAN BE ADJUSTED FOR MAXIMUM SELECTOR PERFORMANCE ONLY WHEN PRINTER IS CONNECTED TO THE SPECIFIC CIRCUIT OVER WHICH IT IS TO OPERATE UNDER SERVICE CONDITIONS. SINCE THERE ARE SEVERAL OPERATING SPEEDS AND SINCE CIRCUITS VARY WIDELY, IT IS IMPOSSIBLE TO ADJUST SPRING FOR MAXIMUM PERFORMANCE AT THE FACTORY. THE FOREGOING SPRING TENSION REQUIREMENT IS GIVEN TO PERMIT OPERATION PRIOR TO MEASUREMENT OF RECEIVING MARGINS. READJUSTMENT MADE TO OBTAIN SATISFACTORY RECEIVING MARGIN SHOULD NOT BE DISTURBED IN ORDER TO MEET REQUIREMENTS OF THIS ADJUSTMENT.

TO ADJUST
POSITION ADJUSTING NUT.



REQUIREMENT (FINAL)

SEE SELECTOR RECEIVING MARGIN ADJUSTMENT (PARAGRAPH 2-13)


2.07 Selector Mechanism (Cont.)

SELECTOR ARMATURE SPRING

(FOR UNITS EMPLOYING SELECTOR ARMATURE WITH TWO ANTI-FREEZE BUTTONS ONLY).

REQUIREMENT (PRELIMINARY)


WITH LOCKING LEVERS AND START LEVER ON HIGH PART OF THEIR CAMS, SCALE APPLIED AS NEARLY VERTICAL AS POSSIBLE UNDER END OF ARMATURE EXTENSION. IT SHALL REQUIRE APPROXIMATELY THE FOLLOWING TENSIONS TO MOVE THE REAR ANTI-FREEZE BUTTON AGAINST THE MAGNET CORE:



(SEE SELECTOR RECEIVING MARGIN ADJUSTMENT)

SELECTOR ARMATURE SPRINGREQUIREMENT (FINAL)


WHEN A DISTORTION TEST SET IS AVAILABLE, THE SELECTOR ARMATURE SPRING TENSION SHOULD BE REFINED, IF NECESSARY, TO OBTAIN SATISFACTORY RECEIVING MARGINS. THE FRONT ANTI-FREEZE BUTTON MUST CONTACT THE MAGNET CORE WHEN THE MAGNET COILS ARE ENERGIZED.

REQUIREMENT (FINAL)

SEE SELECTOR RECEIVING MARGIN ADJUSTMENT (PARAGRAPH 2-13)

2.08 Selector Mechanism (Cont.)

NOTE
THE APPROPRIATE PRELIMINARY SELECTOR
ARMATURE SPRING TENSION ADJUSTMENT
MUST BE MADE PRIOR TO THIS
ADJUSTMENT.



SELECTOR MAGNET BRACKET

(1) REQUIREMENT

SPACING LOCK LEVER ON HIGH PART OF
CAM. ARMATURE IN CONTACT WITH POLE
PIECE. CLEARANCE BETWEEN END OF
ARMATURE EXTENSION AND SHOULDER
ON SPACING LOCK LEVER
MIN. 0.020 INCH
MAX. 0.035 INCH

TO ADJUST

LOOSEN TWO MAGNET BRACKET
MOUNTING SCREWS AND ADJUSTING
LINK CLAMP SCREW. POSITION MAG-
NET BRACKET BY MEANS OF ADJUST-
ING LINK AND TIGHTEN LINK CLAMP
SCREW ONLY.

(2) REQUIREMENT

SPACING LOCK LEVER ON HIGH PART OF
CAM. ARMATURE IN CONTACT WITH POLE
PIECE. SOME CLEARANCE BETWEEN UPPER
SURFACE OF ARMATURE EXTENSION AND
LOWER SURFACE OF UPPER STEP OF SPACING
LOCK LEVER WHEN LOCK LEVER IS HELD
DOWNWARD.
MAX. 0.003 INCH



TO ADJUST

POSITION UPPER END OF MAGNET BRACKET.
TIGHTEN TWO MAGNET BRACKET MOUNTING
SCREWS. RECHECK REQUIREMENT (1).


NOTE

SEE FOLLOWING PAGE
FOR REQUIREMENT (3).

2.09 Selector Mechanism (Cont.)



2.10 Selector Mechanism (Cont.)



SELECTOR PUSH LEVER SPRING

REQUIREMENT

PUSH LEVER IN SPACING POSITION

MIN. 1 OZ.


MAX. 2 OZ.

TO MOVE PUSH LEVERS FROM SELECTOR LEVERS ON ALL PUSH LEVERS EXCEPT THAT ONE WHICH IS FIRST IN SEQUENCE OF SELECTION.

MIN. 2 OZS.

MAX. 3 OZS.

TO MOVE THIS PUSH LEVER AWAY FROM ITS SELECTOR LEVER. THIS SPRING IS DISTINGUISHED BY ITS COPPER COLOR.



SELECTOR LEVER SPRING


REQUIREMENT

TYPING UNIT UPSIDE DOWN, RESET BAIL ON PEAK OF ITS CAM.

MIN. 1-1/4 OZS.

MAX. 1-1/2 OZS.

TO START EACH LEVER MOVING CHECK EIGHT SPRINGS. IF NECESSARY, UNHOOK START LEVER SPRING TO CHECK NO. 4 SELECTOR LEVER SPRING.



SELECTOR CLUTCH DRUM


REQUIREMENT

CLUTCH LATCHED IN STOP POSITION, CLUTCH DRUM AGAINST SHOULDER ON MAIN SHAFT. CAM-CLUTCH ASSEMBLY SHOULD HAVE SOME END PLAY MAX. 0.010 INCH


TO ADJUST

POSITION CLUTCH DRUM WITH MOUNTING SCREW LOOSENED.

2.11 Selector Mechanism (Cont.)



PUSH LEVER RESET BAIL ON LOW PART OF CAM. 32 OZ. SCALE APPLIED TO RESET BAIL.
 MIN. 4 OZS.
 MAX. 8 OZS.
 TO MOVE BAIL FROM CAM.



LATCH RESTING ON LOW PART OF ITS CAM DISK.
 MIN. 2 OZS.
 MAX. 3-1/2 OZS.
 TO START LATCH MOVING.




SELECTOR ARMATURE RELEASED. SPACING LOCK LEVER ON LOW PART OF ITS CAM. SPRING SCALE APPLIED TO LOWER END OF SPACING LOCK LEVER.
 MIN. 3 OZS.
 MAX. 6 OZS.
 TO MOVE SPACING LOCK LEVER FROM ITS PIVOT SHAFT.

2.12 Selector Mechanism (Cont.)


(A) RANGE FINDER KNOB PHASING

REQUIREMENT

WITH RANGE FINDER KNOB TURNED TO EITHER END OF RACK, ZERO MARK ON SCALE SHOULD BE IN LINE WITH SCRIBED LINE ON RANGE FINDER PLATE ± 3 POINTS.



NOTE: REPLACE RANGE FINDER AND SELECTOR MAGNET ASSEMBLY BEFORE CHECKING THESE ADJUSTMENTS.




(B) SELECTOR CLUTCH STOP ARM
REQUIREMENT

RANGE SCALE SET AT 60. SELECTOR CLUTCH DISENGAGED. ARMATURE IN MARKING POSITION. CLUTCH STOP ARM SHOULD ENGAGE CLUTCH SHOE LEVER BY APPROXIMATELY FULL THICKNESS OF SHOE LEVER.

TO ADJUST

POSITION STOP ARM ON STOP ARM BAIL WITH CLAMP SCREW LOOSENED.

2.13 Selector Mechanism (Cont.)



START LEVER SPRING REQUIREMENT

LATCH LEVER SPRING UNHOOKED. STOP ARM BAIL IN INDENT OF ITS CAM. RANGE SCALE SET AT 60.
 MIN. 2-1/2 OZS.
 MAX. 4-1/2 OZS.
 TO START STOP ARM MOVING.

SELECTOR RECEIVING MARGIN

REQUIREMENT (FOR UNITS EMPLOYING ARMATURE WITH ONE ANTI-FREEZE BUTTON)
 WHEN A SIGNAL DISTORTION TEST SET IS USED FOR DETERMINING THE RECEIVING MARGINS OF THE SELECTOR, AND WHERE THE CONDITION OF THE COMPONENTS IS EQUIVALENT TO THAT OF NEW EQUIPMENT, THE RANGE AND DISTORTION TOLERANCES BELOW SHOULD BE MET.


REQUIREMENT (FOR UNITS EMPLOYING ARMATURE WITH TWO ANTI-FREEZE BUTTONS)
 WHEN A DISTORTION TEST SET IS AVAILABLE, THE SELECTOR ARMATURE SPRING TENSION SHOULD BE REFINED, IF NECESSARY, TO OBTAIN SATISFACTORY RECEIVING MARGINS. THE FRONT ANTI-FREEZE BUTTON MUST CONTACT THE MAGNET CORE WHEN THE MAGNET COILS ARE ENERGIZED.

TO ADJUST: REFINE THE SELECTOR ARMATURE SPRING (PARAGRAPH 2.06 OR 2.07)

SELECTOR RECEIVING MARGIN MINIMUM REQUIREMENTS

CURRENT	SPEED IN W.P.M.	POINTS RANGE WITH ZERO DISTORTION	PERCENTAGE OF MARKING AND SPACING BIAS	END DISTORTION TOLERATED WITH SCALE AT BIAS OPTIMUM SETTING
0.060 AMP (WINDINGS PARALLEL)	100	65	35	30
0.500 AMP (WINDINGS PARALLEL)	100	72	38	35

2.14 Function Mechanism



(A)

FUNCTION CLUTCH TRIP LEVER

REQUIREMENT

- (1) WITH RELEASE RESTING ON MAIN TRIP LEVER (SEE BELOW), FUNCTION CLUTCH TRIP LEVER SHOULD ENGAGE FULL THICKNESS OF SHOE LEVER.
- (2) MIN. SOME----MAX. 0.006 INCH END PLAY IN TRIP LEVER.

TO ADJUST POSITION TRIP LEVER ON ITS SHAFT WITH CLAMP SCREW LOOSENED.

FUNCTION CLUTCH TRIP LEVER

(RIGHT SIDE VIEWS)

(B)


RESET ARM
TO CHECK

TRIP FUNCTION CLUTCH AND POSITION MAIN SHAFT SO THAT RESET ARM IS HELD IN ITS HIGHEST POSITION BY CAM PIN.

REQUIREMENT

- (1) CLEARANCE BETWEEN RELEASE AND MAIN TRIP LEVER:
MIN. 0.010 INCH----MAX. 0.030 INCH
- (2) LATCH LEVER END PLAY:
MIN. SOME----MAX. 0.010 INCH


TO ADJUST POSITION RESET ARM WITH CLAMP SCREW LOOSENED.



2.15 Function Mechanism (Cont.)

(A) FUNCTION CLUTCH RELEASE SPRING REQUIREMENT

TRIP FUNCTION CLUTCH. ROTATE MAIN SHAFT UNTIL RELEASE IS RESET ON MAIN TRIP LEVER.
 MIN. 5 OZS. --- MAX. 8 OZS. TO START RELEASE MOVING.




(B) RELEASE DOWNSTOP BRACKET REQUIREMENT

WITH FUNCTION CLUTCH TRIPPED, ROTATE SHAFT UNTIL CLEARANCE BETWEEN FUNCTION CLUTCH DISK STOP LUG AND CLUTCH STOP LEVER IS AT A MINIMUM. RELEASE RESTING AGAINST DOWNSTOP BRACKET. CLEARANCE BETWEEN FUNCTION CLUTCH DISK STOP LUG AND STOP LEVER:
 MIN. 0.002 INCH --- MAX. 0.045 INCH

TO ADJUST

REMOVE TAPE GUIDE. WITH DOWNSTOP BRACKET MOUNTING SCREWS FRICTION TIGHT POSITION BRACKET.



2.16 Function Clutch Trip Mechanism

(A) FOLLOWER LEVER
REQUIREMENT

(1) WITH FOLLOWER LEVER ON HIGH PART OF CAM, CLEARANCE BETWEEN RELEASE AND MAIN TRIP LEVER:

MIN. 0.010 INCH --- MAX. 0.030 INCH

(2) SOME CLEARANCE BETWEEN MAIN TRIP LEVER AND DOWNSTOP BRACKET.

TO ADJUST

BY MEANS OF PRY POINT, POSITION ADJUSTING ARM ON FOLLOWER LEVER WITH LOCK NUT LOOSENED.

(C) MAIN TRIP LEVER SPRING
REQUIREMENT

TRIP RESET BAIL TRIP LEVER
EXTENSION

MIN. 2-1/2 OZS.

MAX. 4 OZS.

TO START LEVER MOVING.


(B) ADJUSTING ARM TORSION SPRING
REQUIREMENT

WITH FOLLOWER LEVER ON LOW PART
OF TRIP CAM AND MAIN TRIP LEVER HELD
AWAY FROM ADJUSTING ARM


MIN. 1 OZ.

MAX. 4 OZS.

TO START ADJUSTING LEVER MOVING.



NOTE
IT MAY BE NECESSARY TO REMOVE
RIBBON FEED MECHANISM WHEN
CHECKING THIS TENSION.



(D) PUNCH AND FEED SLIDE LATCH SPRINGS
TO CHECK

SELECT RUBOUT CODE COMBINATION
(12345678). POSITION ROCKER BAIL TO
EXTREME LEFT. STRIP PUSH LEVERS
FROM SELECTING LEVERS.

REQUIREMENT

MIN. 1 OZ.

MAX. 3 OZS.

TO START LATCH MOVING.

TO CHECK (TWO SHAFT UNITS)
RANGE SCALE AT 60. SELECT
RUBOUT COMBINATION. CLUTCHES
DISENGAGED AND LATCHED.

REQUIREMENT

MIN. 3/4 OZ. ----MAX. 1-3/4 OZS.

TO START LATCH MOVING.

2.17 Rocker Bail Mechanism

(A)


ROCKER BAIL LOWER ROLLER

REQUIREMENT

WITH ROCKER BAIL POSITIONED TO ITS EXTREME LEFT AND UPPER ROLLER IN CONTACT WITH FUNCTION CAM:
 MIN. SOME----MAX. 0.003 INCH
 CLEARANCE BETWEEN CAM AND LOWER ROLLER AT POINT OF LEAST CLEARANCE.

TO ADJUST

POSITION LOWER ROLLER MOUNTING SCREW IN ELONGATED SLOT WITH LOCK NUT LOOSENED. CHECK THROUGHOUT A COMPLETE REVOLUTION FOR BINDS.



(B)


ROCKER BAIL GUIDE BRACKET

REQUIREMENT

ROCKER BAIL ROLLERS SHOULD ENGAGE FULL THICKNESS OF FUNCTION CAM.

TO ADJUST

POSITION ROCKER BAIL AND GUIDE BRACKET WITH GUIDE BRACKET MOUNTING SCREWS LOOSENED.



2.18 Punch Mechanism

PERFORATOR POSITION (PRELIMINARY)REQUIREMENT


THE PERFORATOR MECHANISM MOUNTING SCREW BENEATH PUNCH BLOCK AND MOUNTING SCREW AT LOWER EDGE OF PERFORATOR MECHANISM BACKPLATE SHALL BE LOCATED CENTRALLY WITHIN THEIR RESPECTIVE MOUNTING HOLES.

NOTE

THE MOUNTING HOLES ARE OVERSIZE TO FACILITATE USE OF PERFORATOR MECHANISM ON THE TYPING REPERFORATOR.

TO ADJUST

REMOVE MOUNTING SCREW AT THE LOWER EDGE OF PERFORATOR MECHANISM BACKPLATE, WITH THE TWO REMAINING BACKPLATE MOUNTING SCREWS AND MOUNTING BRACKET SCREW FRICTION TIGHT, POSITION PERFORATOR MECHANISM SO THAT THE TAPPED HOLE OF THE FRAME IS CENTRALLY LOCATED (AS GAUGED BY EYE) WITHIN LARGE BODY HOLE OF PUNCH MECHANISM BACKPLATE. TIGHTEN THE TWO BACKPLATE MOUNTING SCREWS AND RECHECK TO SEE THAT REQUIREMENT IS MET. REPLACE AND TIGHTEN THE LOWER BACKPLATE MOUNTING SCREW. TIGHTEN THE BRACKET MOUNTING SCREW.

PERFORATOR POSITION (FINAL)REQUIREMENT

WITH RUBOUT CODE COMBINATION SELECTED AND THE PUSH LEVERS IN THEIR EXTREME LEFT HAND POSITION.

MIN. 0.015 INCH --- MAX. 0.045 INCH
CLEARANCE BETWEEN THE CLOSEST LATCH LEVER AND ASSOCIATED PUNCH SLIDE.


TO ADJUST

WITH THE REAR FRAME MOUNTING SCREWS AND FRONT FRAME MOUNTING BRACKET SCREWS FRICTION TIGHT. PLACE TIP OF SCREWDRIVER BETWEEN HEXAGON HEAD SCREW AND ITS CLEARANCE HOLE RIM AND PRY UP OR DOWN TO MEET REQUIREMENTS.

2.19 Punch Mechanism (Cont.)

NOTE

BEFORE PROCEEDING WITH THE PUNCH MECHANISM ADJUSTMENTS, CHECK THE ROCKER BAIL CAM FOLLOWER ROLLER ADJUSTMENT AND LOOSEN THE PUNCH SLIDE DOWNSTOP MOUNTING NUT AND GUIDE MOUNTING STUD.




2.20 Punch Mechanism (Cont.)

(A) PUNCH PIN PENETRATION
REQUIREMENT

- (1) WITH THE RUBOUT COMBINATION SELECTED, FUNCTION CLUTCH ENGAGED. ROTATE MAIN SHAFT UNTIL ALL PUNCH PINS ARE INTO OR ABOVE THE TAPE APERTURE IN PUNCH BLOCK. WITH THE TP159926 GAUGE IN POSITION
MIN. 0.050 INCH
CLEARANCE BETWEEN FEED PAWL STUD AND THE GAUGE.
- (2) WITH RUBOUT COMBINATION SELECTED, FUNCTION CLUTCH ENGAGED. ROTATE MAIN SHAFT UNTIL ALL PUNCH PINS HAVE CLEARED THE PUNCH BLOCK. WITH THE TP159926 GAUGE IN POSITION
MAX. 0.080 INCH
CLEARANCE BETWEEN FEED PAWL STUD AND GAUGE.

TO ADJUST


REFINE THE TOGGLE BAIL ECCENTRIC ADJUSTMENT KEEPING THE INDENT TO THE RIGHT OF A VERTICAL CENTERLINE THROUGH THE SHAFT.

**(B) PUNCH SLIDE GUIDE**
REQUIREMENT

THE PUNCH SLIDES SHOULD ALIGN WITH THEIR CORRESPONDING PUNCH PINS AND BE FREE OF BINDS AFTER TIGHTENING THE GUIDE MOUNTING STUDS. EACH PUNCH SLIDE SHOULD RETURN FREELY AFTER BEING PUSHED IN NOT MORE THAN 1/16 INCH.

TO ADJUST

POSITION THE GUIDE WITH ITS MOUNTING STUDS FRICTION TIGHT.




2.21 Punch Mechanism (Cont.)

RESET BAIL TRIP LEVER
REQUIREMENT

- (1) MANUALLY SELECT AN ALL SPACING COMBINATION. MANUALLY ROTATE RESET BAIL TRIP LEVER. THE PUNCH SLIDE RESET BAIL SHALL TRIP BEFORE THE FUNCTION CLUTCH IS TRIPPED.
- (2) WITH FUNCTION AND SELECTOR CLUTCHES DIS-ENGAGED AND LATCHED, THE PUNCH SLIDE RESET BAIL SHALL FULLY ENGAGE THE PUNCH SLIDE LATCHING SURFACE WHEN PLAY IN PARTS IS TAKEN UP IN DIRECTION TO MAKE THE ENGAGEMENT THE LEAST.

TO ADJUST

- (1) WITH TRIP LEVER EXTENSION LOCK SCREW FRICTION TIGHT AND DELETE (RUBOUT) COMBINATION SELECTED, POSITION RESET BAIL AGAINST PUNCH SLIDES. TAKE UP PLAY BETWEEN RESET BAIL AND TRIP LEVER IN A COUNTER CLOCKWISE DIRECTION. POSITION TRIP LEVER BY MEANS OF ITS PRY POINT.
- (2) RECHECK REQUIREMENT (1) ABOVE AND REFINE ADJUSTMENT IF NECESSARY.



2.22 Punch Mechanism (Cont.)

(A) LATCH LEVER CLEARANCE


MANUALLY SELECT AN ALL SPACING COMBINATION, WITH FUNCTION CLUTCH DISENGAGED AND LATCHED. CLEARANCE BETWEEN PUNCH SLIDE AND ITS ASSOCIATED LATCH LEVER.

MIN. 0.015 INCH --- MAX. 0.025 INCH

FOR THE SLIDE HAVING THE LEAST CLEARANCE.

TO ADJUST

ROTATE THE RESET BAIL ECCENTRIC SHAFT WITH ITS LOCK NUT LOOSENED. KEEP THE INDENTATION IN THE ECCENTRIC ABOVE CENTER OF SHAFT.

(B) FEED PAWL

NOTE


THIS ADJUSTMENT AND LATERAL FEED WHEEL ADJUSTMENT ARE INTER-RELATED AND SHALL BE PERFORMED TOGETHER.

REQUIREMENT

FUNCTION CLUTCH DISENGAGED AND LATCHED. THE INDENT OF THE DETENT LEVER ECCENTRIC AT RIGHT ANGLE TO CENTER LINE OF DETENT ARM. DETENT ROLLER IN ENGAGEMENT WITH FEED WHEEL RATCHET, AND HIGH SIDE OF FEED PAWL ECCENTRIC TO RIGHT OF ITS LOCKING SCREW. THE FEED PAWL SHALL ENGAGE THE FIRST TOOTH BELOW HORIZONTAL CENTER LINE OF RATCHET WHEEL WITH NO PERCEPTIBLE CLEARANCE.

TO ADJUST

ROTATE THE FEED PAWL ECCENTRIC WITH LOCK SCREW LOOSENED.



2.23 Punch Mechanism (Cont.)

(FOR LATEST DESIGN SEE PARAGRAPH 2-25)


LATERAL AND FRONT TO REAR FEED WHEEL POSITION (EARLY DESIGN)

REQUIREMENT


WITH THE REPERFORATOR OPERATING UNDER POWER, OBTAIN A TAPE SAMPLE CONSISTING OF A SERIES OF "SPACE" PERFORATIONS, BY A VISUAL INSPECTION OF THE PERFORATED FEED HOLES, LATERALLY AND FRONT TO REAR, THE INDENTATIONS OF THE FEED WHEEL SHALL BE FULLY PUNCHED OUT.

TO ADJUST

- (1) TO MEET THE LATERAL REQUIREMENT. LOOSEN THE DETENT ECCENTRIC STUD LOCK NUT AND ROTATE THE DETENT ECCENTRIC CLOCKWISE TO MOVE THE FEED WHEEL PERFORATIONS TOWARDS THE LEAD EDGE OF THE FEED HOLE AND ROTATE THE DETENT ECCENTRIC COUNTER CLOCKWISE TO MOVE THE FEED WHEEL PERFORATION TOWARDS THE TRAILING EDGE OF THE FEED HOLE. REFINE THE FEED PAWL ADJUSTMENT.
- (2) TO ADJUST TO MEET THE FRONT TO REAR REQUIREMENT WITH RESPECT TO THE REFERENCE EDGE OF THE TAPE, LOOSEN THE ADJUSTING SCREW LOCK NUT AND POSITION THE ADJUSTING SCREW. TO MOVE THE INDENTATIONS IN THE TAPE AWAY FROM THE REFERENCE EDGE OF THE TAPE, MOVE THE FEED WHEEL TOWARDS THE FRONT PLATE OF THE PUNCH MECHANISM BY ROTATING THE ADJUSTING SCREW COUNTER CLOCKWISE. TO MOVE THE INDENTATIONS IN THE TAPE TOWARDS THE REFERENCE EDGE OF THE TAPE, MOVE THE FEED WHEEL TOWARDS THE BACKPLATE OF THE PUNCH MECHANISM BY ROTATING THE ADJUSTING SCREW CLOCKWISE. REFINE THE DETENT ADJUSTMENT TO ALIGN THE LATERAL INDENTATIONS OF THE FEED WHEEL IF REQUIRED.



2.24 Punch Mechanism (Cont.)



FEED HOLE SPACING----PRELIMINARY REQUIREMENT

INDENT OF DIE WHEEL ECCENTRIC STUD POINTING DOWNWARD.

TO ADJUST

POSITION DIE WHEEL ECCENTRIC STUD WITH LOCK NUT LOOSENED.


NOTE 1: BEFORE PROCEEDING WITH THE FOLLOWING ADJUSTMENTS, CHECK BOTH TAPE GUIDE SPRING TENSIONS

FEED HOLE SPACING----FINAL (1) REQUIREMENT

WITH TAPE SHOE BLOCKED AWAY FROM FEED WHEEL, FEED PAWL AND DETENT DISENGAGED, AND TAPE REMOVED, FEED WHEEL SHOULD ROTATE FREELY. CHECK THROUGH 3 OR 4 REVOLUTIONS OF FEED WHEEL.

NOTE 2: BEFORE PROCEEDING WITH THE FOLLOWING ADJUSTMENT CHECK BOTH TAPE GUIDE SPRING TENSIONS

TP156011 TAPE GAUGE



FEED HOLE SPACING

(1) REQUIREMENT

WITH A PIECE OF TAPE PERFORATED WITH SIX SERIES OF 9 SPACE CODE COMBINATIONS FOLLOWED BY A RUBOUT COMBINATION PLACED OVER THE SMOOTH SIDE OF THE TP156011 TAPE GAUGE SO THE CIRCULAR PORTION OF THE FIRST NUMBER 2 CODE HOLE IN THE TAPE IS CONCENTRIC WITH THE FIRST HOLE OF THE TAPE GAUGE. THE NEXT FOUR HOLES IN THE TAPE GAUGE SHOULD BE VISIBLE THROUGH THE NUMBER 2 CODE HOLES IN THE TAPE AND THE CIRCULAR PORTION OF THE LAST (SIXTH) NUMBER 2 CODE HOLE IN THE TAPE SHALL BE ENTIRELY WITHIN THE 0.086 DIAMETER HOLE OF THE TAPE GAUGE.

(2) REQUIREMENT

WITH TAPE SHOE HELD AWAY FROM FEED WHEEL, FEED PAWL AND DETENT DISENGAGED AND TAPE REMOVED, FEED WHEEL SHOULD ROTATE FREELY.


TO ADJUST

WITH TAPE REMOVED FROM THE PUNCH MECHANISM, LOOSEN THE ECCENTRIC LOCK NUT AND ROTATE THE DIE WHEEL ECCENTRIC SHAFT UNTIL IT BINDS AGAINST THE FEED WHEEL. BACK OFF THE ECCENTRIC UNTIL THE DIE WHEEL IS JUST FREE. KEEP THE INDENT OF THE ECCENTRIC BELOW THE HORIZONTAL CENTERLINE OF THE STUD. REFINE ADJUSTMENT FOR REQUIREMENT (1), IF NECESSARY, BY MOVING THE DIE WHEEL TOWARD THE FEED WHEEL TO DECREASE THE CHARACTER SPACING AND AWAY FROM THE FEED WHEEL TO INCREASE THE CHARACTER SPACING.

CAUTION: WITH TAPE REMOVED. MAKE SURE FEED WHEEL AND DIE WHEEL DO NOT BIND. RECHECK REQUIREMENT (1), IF NECESSARY, REFINE.

NOTE 3: FIRST THROUGH FIFTH HOLES IN GAUGE ARE SAME SIZE AS CODE HOLES IN TAPE (0.072 INCH DIAMETER). SIXTH HOLE IN GAUGE IS LARGER (0.086 INCH). THIS ARRANGEMENT ALLOWS ± 0.007 INCH VARIATION IN 5 INCHES.

2.25 Punch Mechanism (Cont.)



(FOR EARLY DESIGN SEE PARAGRAPH 2.23)

LATERAL AND FRONT TO REAR FEED WHEEL POSITION (LATEST DESIGN)

REQUIREMENT

THE INDENTATIONS PUNCHED BY THE FEED WHEEL SHOULD BE CENTRALLY LOCATED BETWEEN THE PUNCHED FEED HOLES (GAUGED BY EYE) AND ON SAME HORIZONTAL CENTERLINE. THE UNIT MUST BACKSPACE THE TAPE AT LEAST 30 CHARACTERS WITHOUT LOSING ITS POINT OF REGISTRATION.

TO CHECK


PERFORATE 6 INCHES OF RY TAPE. BACK SPACE 30 CHARACTERS. REPERFORATE WITH RUBOUT CHARACTER: CODE HOLES MUST COINCIDE EXCEPT FOR FIRST TWO CHARACTERS WHICH MAY BE ELONGATED ± 0.010 IN

TO ADJUST (LATERALLY)


ROTATE THE DETENT ECCENTRIC CLOCKWISE TO MOVE THE FEED WHEEL PERFORATION TOWARD THE LEADING EDGE OF THE FEED HOLE AND ROTATE THE ECCENTRIC COUNTER-CLOCKWISE TO MOVE THE PERFORATION TOWARD THE TRAILING EDGE OF THE FEED HOLE. TIGHTEN THE LOCK NUT. REFINE THE FEED PAWL ADJUSTMENT IF NECESSARY.

TO ADJUST (FRONT TO REAR)

LOOSEN THE LOCK NUT ON THE ADJUSTING SCREW AND ROTATE THE SCREW COUNTER-CLOCKWISE TO MOVE THE INDENTATIONS IN THE TAPE AWAY FROM THE REFERENCE EDGE (REAR) OF THE TAPE. TO MOVE THE INDENTATIONS IN THE TAPE TOWARD THE REFERENCE EDGE OF THE TAPE, ROTATE THE ADJUSTING SCREW CLOCKWISE. REFINE THE DETENT ADJUSTMENT IF NECESSARY.



2.26 Punch Mechanism (Cont.)



PUNCH SLIDE SPRING REQUIREMENT

RUBOUT COMBINATION SET UP, AND PUNCH SLIDES IN SELECTED POSITION.
 MIN. 2-1/4 OZS.
 MAX. 3-1/4 OZS.
 TO START EACH SLIDE MOVING.

TAPE GUIDE SPRING (TAPE CHUTE) REQUIREMENT

WITH SELECTOR AND FUNCTION CLUTCHES DISENGAGED AND LATCHED, TAPE THREADED THROUGH PUNCH MECHANISM, IT SHOULD REQUIRE
 MIN. 1-1/4 OZS.
 MAX. 2-1/4 OZS.
 TO JUST MOVE THE SPRING AWAY FROM THE TAPE.
 TO ADJUST BEND THE SPRING.

NOTE

IT IS NECESSARY TO REMOVE SEVERAL PARTS, ON UNITS EQUIPPED WITH BACK SPACE MECHANISM, IN ORDER TO CHECK THIS SPRING TENSION. IT SHOULD NOT BE CHECKED UNLESS THERE IS GOOD REASON TO BELIEVE THAT REQUIREMENTS ARE NOT MET.

TAPE GUIDE SPRING (PUNCH BLOCK)

(1) REQUIREMENT


WITH TAPE REMOVED FROM THE PUNCH BLOCK THE TAPE GUIDE SPRING SHOULD REST AGAINST THE CLEARANCE SLOT IN THE BLOCK IN A SYMETRICAL MANNER.

(2) REQUIREMENT



WITH TAPE IN THE PUNCH BLOCK AND THE REPERFORATOR OPERATING UNDER POWER, THE SPRING SHOULD NOT DISTORT THE EDGE OF THE TAPE.

TO ADJUST



BEND THE SPRING AND POSITION IT WITH ITS MOUNTING SCREW LOOSENED.



PUNCH BLOCK



2.27 Punch Mechanism (Cont.)



2.28 Punch Mechanism (Cont.)


TAPE GUIDE
REQUIREMENT

ROTATE FEED WHEEL UNTIL OIL HOLE IS UP. CENTER TAPE SHOE AND TAPE GUIDE, HOLD TAPE GUIDE DOWNWARD. CLEARANCE BETWEEN ADJUSTING PLATE EXTENSION AND BACKSTOP POST SHALL BE

MIN. 0.002 INCH
MAX. 0.008 INCH

TO ADJUST

LOOSEN ADJUSTING PLATE CLAMP SCREW FRICTION TIGHT AND MOVE ADJUSTING PLATE UP OR DOWN. TIGHTEN SCREW.



TAPE DEPRESSOR SLIDE SPRING

REQUIREMENT


ROCKER BAIL IN ITS EXTREME LEFT POSITION

MIN. 1 OZ.

MAX. 2 OZS.

TO START DEPRESSOR SLIDE MOVING

DEPRESSOR SLIDE SPRING




TAPE SHOE TORSION SPRING

REQUIREMENT


MIN. 13 OZS.

MAX. 18 OZS.

TO MOVE TAPE SHOE FROM FEED WHEEL.



2.25 Power Drive Backspace Mechanism



FEED PAWL CLEARANCE REQUIREMENT (PRELIMINARY)

- (1) WITH BACKSPACE BELL CRANK ROTATED CLOCKWISE, BACKSPACE FEED PAWL SHOULD MISS FIRST TOOTH BY A CLEARANCE OF:
MIN. 0.006 INCH
MAX. 0.040 INCH

REQUIREMENT (FINAL)

- (2) BACKSPACE FEED PAWL SHOULD MISS FIRST TOOTH AND ENGAGE SECOND TOOTH BY AT LEAST 1/2 OF RIGHT ENGAGING SURFACE OF FEED PAWL (AS GAUGED BY EYE) WHEN THE FEED PAWL FIRST CONTACTS RATCHET TOOTH.


TO ADJUST POSITION ADJUSTING PLATE WITH MOUNTING SCREW FRICTION TIGHT.

(CHECK WITH FEED WHEEL SHAFT OIL HOLE IN THE UPPERMOST POSITION AND RECHECK EACH 90 DEGREES ABOUT PERIPHERY OF FEED WHEEL.)

(B) FEED PAWL (PRELIMINARY WHEN POWER DRIVE IS USED) REQUIREMENT

BACKSPACE MECHANISM IN OPERATED POSITION, FEED WHEEL RATCHET IN DETENTED POSITION. CLEARANCE BETWEEN FEED WHEEL RATCHET TOOTH AND FEED PAWL:
MIN. SOME
MAX. 0.003

TO ADJUST BY MEANS OF 0.060" ALLEN WRENCH, ROTATE ECCENTRIC WITH NUT POST FRICTION TIGHT.



2.30 Power Drive Backspace Mechanism (Cont.)


(A) ARMATURE HINGE REQUIREMENT

WITH ARMATURE HELD AGAINST POLE FACE (ARMATURE BAIL SPRING UNHOOKED)

MIN. SOME --- MAX. 0.004 INCH
BETWEEN ARMATURE AND MAGNET MOUNTING BRACKET WITH PLAY TAKEN UP FOR MINIMUM.

TO ADJUST

WITH MOUNTING SCREWS LOOSENED, POSITION HINGE. WHILE ADJUSTMENT IS BEING MADE, ARMATURE SHOULD TOUCH FRONT AND REAR OF POLE FACE.




NOTE

FOR "DC" OPERATION, THE BACKSPACE MAGNET ARMATURE SHALL BE POSITIONED SO THAT THE SIDE MARKED "C" SHALL FACE THE POLE FACE OF THE MAGNET CORE. FOR "AC" OPERATION, THE UNMARKED SIDE OF THE MAGNET ARMATURE SHALL FACE THE POLE OF THE MAGNET CORE.

*NOTE

THIS ADJUSTMENT IS MADE AT FACTORY AND SHOULD NOT BE DISTURBED UNLESS A REASSEMBLY OF THE UNIT IS UNDERTAKEN. IF NECESSARY TO MAKE THIS ADJUSTMENT, THE PUNCH UNIT SHOULD BE REMOVED. SEE DISASSEMBLY AND REASSEMBLY. REMAKE PUNCH UNIT POSITION ADJUSTMENT.



(B) ARMATURE UP-STOP* REQUIREMENT

ARMATURE IN UNOPERATED POSITION. GAP BETWEEN ARMATURE AND POLE FACE

MIN. 0.025 INCH.


MAX. 0.030 INCH.

AT CLOSEST POINT.

TO ADJUST

ROTATE ECCENTRIC WITH MOUNTING NUT LOOSENED. KEEP HIGH PART OF ECCENTRIC TO LEFT.

2.31 Power Drive Backspace Mechanism (Cont.)



(A) DRIVE LINK
REQUIREMENT

BACKSPACE MECHANISM IN OPERATED POSITION. FEED WHEEL RATCHET IN DETENTED POSITION. LATCH ENGAGED WITH ECCENTRIC LINK. HIGH PART OF ECCENTRIC TO RIGHT. CLEARANCE BETWEEN FEED PAWL AND FEED WHEEL

RATCHET TOOTH:


MIN. SOME

MAX. 0.003 INCH

TO ADJUST

BY MEANS OF PRY POINT, POSITION ADJUSTING LINK WITH DRIVE LINK SCREW FRICTION TIGHT.

2.32 Power Drive Backspace Mechanism (Cont.)



(A) LATCH EXTENSION *

REQUIREMENT
 BACKSPACE MECHANISM IN UNOPERATED POSITION. HIGH PART OF ECCENTRIC TO LEFT. ARMATURE AGAINST POLE FACE. LATCH RESTING ON ECCENTRIC ARM NOTCH. CLEARANCE BETWEEN TOP OF ARMATURE BAIL EXTENSION AND LATCH EXTENSION:
 MIN. 0.005 INCH
 MAX. 0.020 INCH

TO ADJUST
 SWING MAGNET CLOCKWISE OR COUNTER-CLOCKWISE, AS NECESSARY, WITH MOUNTING SCREWS FRICTION TIGHT.


(C) FINAL POWER OR MANUAL REQUIREMENT

OPERATE UNDER POWER, TAPE IN PUNCH UNIT FEED WHEEL SHAFT OIL HOLE IN UPPERMOST POSITION, OPERATE BACKSPACE MECHANISM ONCE. RATCHET WHEEL SHOULD BE BACKED ONE SPACE TO FULLY DETENTED POSITION.

NOTE
 A FULLY DETENTED POSITION IS DEFINED AS: "WITH DETENT ROLLER IN CONTACT WITH RATCHET WHEEL, PUNCH UNIT FEED PAWL SHOULD ENGAGE FIRST TOOTH BELOW HORIZONTAL CENTER LINE OF RATCHET FEED WHEEL WITH NO PERCEPTIBLE CLEARANCE."

TO ADJUST
 REFINE FEED PAWL ADJUSTMENTS.

2.33 Power Drive Backspace Mechanism (Cont.)



LATCH
REQUIREMENT


BACKSPACE MECHANISM IN UNOPERATED POSITION. ARMATURE OFF POLE FACE (DE-ENERGIZED). LATCH EXTENSION AGAINST END OF ARMATURE BAIL EXTENSION. ECCENTRIC LINK AT ITS CLOSEST POINT TO UNDERSIDE OF LATCH. CLEARANCE BETWEEN LATCH AND ECCENTRIC LINK:

MIN. 0.005 INCH
MAX. 0.025 INCH

TO ADJUST

POSITION LATCH WITH LATCH EXTENSION SCREW LOOSENED.

2.34 Power Drive Backspace Mechanism (Cont.)



NON-REPEAT LATCH
REQUIREMENT

BACKSPACE MECHANISM IN UNOPERATED POSITION. CLEAR-
ANCE BETWEEN TOP SURFACE OF NON-REPEAT LATCH AND
LOWEST POINT OF LATCH EXTENSION:

MIN. 0.002 INCH

MAX. 0.010 INCH

TO ADJUST

WITH LATCH SCREW FRICTION TIGHT POSITION
ADJUSTING PLATE.

2.35 Power Drive Backspace Mechanism (Cont.)

(A) FEED PAWL SPRING
REQUIREMENT


BACKSPACE MECHANISM IN UNOPERATED POSITION.
MIN. 8 OZS.
MAX. 15 OZS.
TO START FEED PAWL MOVING.

(B) BELL CRANK SPRING
REQUIREMENT

MIN. 19 OZS.
MAX. 23 OZS.
TO PULL TO INSTALLED LENGTH.

(C) ARMATURE BAIL SPRING
REQUIREMENT

WITH LATCH EXTENSION
SPRING UNHOOKED:
MIN. 3-1/2 OZS. -----MAX. 6-1/2 OZS.
TO START ARMATURE MOVING.



35 TRANSMITTER DISTRIBUTOR (LXD)

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	2	Signal Contact Assembly	
2. ADJUSTMENTS	4	Signal contact	20
Clutch Mechanism		Signal contact link spring.	20
Clutch shoe lever spring	5	Signal contact spring.	20
Clutch shoe spring	5	Signal Pulse Refinement (Strobe).	24
Clutch Trip Magnet Assembly		Start-Stop Switch Assembly	
Armature bail spring	21	Start-stop switch bracket.	14
Clutch magnet	21	Tight-tape intermediate arm	14
Main bail latch spring.	21	Tight-tape intermediate arm spring.	14
Clutch Trip Mechanism		Tight-tape start-stop contact spring	14
Clutch latchlever spring	6	Tape Guide Mounting Plate	
Clutch shoe lever	6	Replacing and positioning tape guide plate	9
Clutch trip lever	6	Tape Guideplate	
Clutch trip lever spring.	6	Tape lid	7
Code Sensing Fingers		Tape guide	8
Feed wheel detent.	16	Tape Lid Assembly	
Sensing finger spring	16	Coverplate detent spring	22
Cover Assemblies	4	Tape lid release button spring.	22
Feed Pawl Mechanism		Tape lid spring	22
Feed pawl.	17	Tape-Out Contact Mechanism	
Feed pawl spring	17	Tape-out contact assembly.	12
Transfer lever spring.	17	Tape-out contact bracket.	12
Gold Plated Signals Contacts	26	Tape-out sensing pin spring.	12
Main Bail Assembly		Tape-Out Sensing Pin Mechanism	
Control lever detent spring	15	Depressor bail torsion spring.	13
Feed ratchet detent spring.	15	Intermediate tape-out bail spring	13
Main bail spring.	15	Tape-out sensing pin.	13
Main bail trip lever	15	Top Plate and Coverplate Mounting	
Main Bail Trip Assembly		Replacing and positioning top plate	10
Locking bail spring.	18	Replacing and positioning cover- plate	11
Main bail	18		

SECTION 574-225-700TC

CONTENTS	PAGE
Transfer Bail Stabilizer Mechanism	
Stabilizer spring	19
Transfer bail stabilizer.	19
Transmitter Distributor Gear	
Transmitter distributor gear	23
3. VARIABLE FEATURES	26
Auxiliary No. 1 Contact Assembly	
Initial Adjustments	
Normally open contact spring.	37
Normally open contact stiffener	37
Swinger	37
Secondary Adjustment	
Contact bracket	38
Contact assembly	38
Operating bail spring	38
Final Adjustment (Strobing)	
Contact bracket	39
Auxiliary No. 2 Contact Assembly	
Initial Adjustment	
Break-make contact spring	40
Make contact spring	40
Make contact stiffener.	40
Secondary Adjustments	
Cam follower spring	41
Contact assembly	41
Contact bracket	41
Final Adjustment (Strobing)	
Contact bracket	42
Code Reading Contacts	
Initial Adjustments	
Normally closed contact — backstop.	33
Normally closed contacts — spring tension.	33
Normally open contacts — backstop.	33
Normally open contacts — spring tension.	33
Secondary Adjustments	
Contact assembly	34

CONTENTS	PAGE
Contact bracket	34
Eccentric up stop.	35
Sensing arm spring.	35
Split bail eccentric	35
Final Adjustments (Strobing)	
Contact bracket	36
Rubout Sensing Mechanism	
Rubout sensing mechanism.	32
Timing bail spring	32
Timing Contact Mechanism (Late Design)	
Cam follower spring	30
Timing contact alignment.	30
Timing contact bracket (preliminary).	31
Timing contact gap.	30
Timing contact spring.	31
Timing Contact Refinement	
Timing contact requirements (strobe)	28
Timing Contact Mechanism (Early Design)	
Cam follower spring.	27
Timing contact bracket	27
Timing contact spring.	27
Timing contact swinger.	27

1. GENERAL

1.01 This section is revised to update format, add recent engineering changes, include additional information on timing contact mechanism, code reading contacts, and auxiliary contact assembly. Since this is a general revision, marginal arrows used to indicate changes have been omitted.


1.02 This section contains the requirements and adjusting procedures for the maintenance of the 35 transmitter distributor.

1.03 The adjustment of the 35 transmitter distributor is arranged in a sequence that would be followed if a complete readjustment of the unit were undertaken.

- 1.04 When an adjustment is completed, tighten loosened nuts or screws.
- 1.05 The covers may be removed for inspection and minor repair of the unit; however, when more extensive maintenance is undertaken, disconnect the unit from its power source as a safety precaution.
- 1.06 The adjusting illustrations indicate adjusting tolerances, positions of moving parts, spring tensions, and angle at which to apply the scale when measuring spring tensions.
- 1.07 If a part mounted on shims is removed, the number of shims used at each of its mounting screws should be noted so that shim pile-up may be replaced when part is remounted.
- 1.08 If parts or assemblies are removed for readjustment and subsequently replaced, recheck any adjustment that may have been affected by removal of these parts or assemblies.
- 1.09 The spring tensions given in this section are indications (not exact values) and should be checked with proper spring scales in

the position indicated. Replace springs which do not meet the requirements and for which no adjusting procedure is given.

- 1.10 References made to left or right, up or down, front or rear, etc, apply to the unit in its normal operating position as viewed from the operator's position.
- 1.11 Where reference is made to a letters combination, select the rubout code. If reference is made to a blanks combination, select the space code.
- 1.12 When a requirement calls for the clutch to be disengaged, the clutch shoe lever must be fully latched between its trip lever and latchlever so that the clutch shoes release their tension on the clutch drum. To accomplish this, rotate the main shaft by hand until the clutch reaches its stop position, then apply a screwdriver to the cam disc stop-lug and push the disc in its normal direction of shaft rotation until the latchlever seats in its notch in the disc.



(Right Front View)

Figure 1 - 35 Transmitter Distributor

2. ADJUSTMENTS

2.01 Cover Assemblies

(A) REMOVING FRONT PANEL

Pull outward on lower right and left rear corner of front panel and slide panel toward the front. Replace in reverse order.

(B) REMOVING COVERPLATE

Lift left end of coverplate to disengage detents then slide plate toward the left to disengage spring plate. Replace in reverse order.

(C) REMOVING TOP PLATE


With front and rear mounting screws loosened (do not disturb mounting nuts) and tape lid raised, lift plate upward. Refer to 2.04 when replacing the plate.

(D) REMOVING TAPE GUIDEPLATE

With front and rear mounting screws loosened (do not disturb mounting nuts) and tape lid raised, lift plate upward. Refer to 2.05 when replacing the plate.

(E) REMOVING TRANSMITTER DISTRIBUTOR ASSEMBLY

Remove right and left mounting screws attached to base and lift assembly upward to disengage main shaft gear. Transmitter is equipped with plug that mates with connector in base. After unit is plugged in, insert mounting screws (3). Check alignment of main shaft gear with driving gear.




2.02 Clutch Mechanism

Note 1: Requirements (A) and (B) are adjusted at the factory and should not be disturbed unless associated mechanisms have been removed for servicing or there is reason to believe that the requirements are not met.


Note 2: Remove transmitter distributor from its base prior to adjustment. See 2.01 (E).

CLUTCH SHOE LEVER SPRING



Requirement
 With clutch engaged, hold cam disc to prevent turning.
 Min 15 oz ---Max 20 oz
 to move shoe lever in contact with stop-lug.


To Measure
 Invert unit. Rotate main shaft until clutch shoe lever and stop-lug are up.



CLUTCH SHOE SPRING

Requirement
 With clutch drum removed, hook spring scale as shown
 Min 3 oz ---Max 5 oz
 to start primary shoe moving away from secondary shoe at point of contact.

2.03 Clutch Trip Mechanism



(B) CLUTCH SHOE LEVER

Requirement

Clearance as shown should be
 Min 0.055 inch---Max 0.085 inch
 greater with clutch engaged* than with clutch disengaged.
 * (Pull shoe lever with force of 32 oz and release slowly to
 engage clutch shoes.)

To Adjust

With clutch disc clampscrews loosened, place wrench
 over stop-lug and move disc.

**CAUTION: MAKE SURE THAT DRUM DOES NOT DRAG ON SHOES WHEN CLUTCH IS
 DISENGAGED AND DRUM IS ROTATED IN ITS NORMAL DIRECTION. REFINE ABOVE
 ADJUSTMENT TO CORRECT SHOE DRAG.**

(A) CLUTCH TRIP LEVER

(1) Requirement

(Remove coverplate, 2.01),
 With clutch disc stop-lug opposite
 clutch trip lever, clearance between
 inner surface of lug and lever, play
 taken up to make clearance maximum
 Min 0.012 inch---Max 0.025 inch

To Adjust


Loosen clamp nut on clutch trip bail
 eccentric (friction tight) and rotate
 eccentric to its lowest point. Posi-
 tion eccentric to meet requirement.

(2) Requirement

Play taken up to make clearance
 minimum
 Some clearance

To Adjust

Refine (1) Requirement.



Note: Remove transmitter distributor from its
 base prior to adjustment. See 2.01 (E).

(C) CLUTCH LATCHLEVER SPRING

Requirement

Clutch engaged and rotated until latch-
 lever is on low part of disc
 Min 3 oz---Max 5-1/2 oz
 to start latch moving.

(D) CLUTCH TRIP LEVER SPRING

Requirement

With clutch engaged
 Min 7 oz---Max 10-1/2oz
 to start clutch trip lever moving.

2.04 Tape Guideplate

(A) TAPE LID

Note 1: Remove top and tape guideplates, lubricate prior to adjustment.

(1) Requirement (Preliminary)

With tape lid held against notch in top guideplate

- (a) Feed wheel groove in tape lid should align with slot in plate.
- (b) Hole in tape lid for tape-out pin should align with hole in plate. (Gauge by eye.)
- (c) Clearance between pivot shoulder and tape lid
Min some---Max 0.010 inch

To Adjust

With tape lid bracket mounting nuts (2) loosened, insert tip of TP170283 gauge through slot and into groove of lid; position tape lid bracket. Retighten nuts.

(2) Requirement

Tape lid front bearing surface, A, should touch tape guideplate. Clearance, B, measured at fin of tape lid which is in line with rear tape guide. (See Note 3.)

- Min 0.010 inch---Max 0.018 inch For fixed width tape guides
- Min 0.015 inch---Max 0.018 inch For variable width tape guides

Note 2: When both plates are assembled on unit, left edge of lid may touch top plate and some change in this clearance may be expected.

To Adjust


With tape lid bearing bracket mounting screws friction tight and tape lid pressed against tape guideplate, position bearing bracket. Recheck (1) Requirement.

(3) Requirement

Release button should have some endplay when lid is latched against tape guideplate.

To Adjust

With eccentric mounting post locknut friction tight and tape lid raised, rotate high part of eccentric toward tape guideplate. Close lid and rotate eccentric toward bracket until latch just falls under flat on post. Recheck by depressing button. With lid held down, tip of latch should clear post as button is operated.



2.05 Tape Guideplate (continued)

(B) TAPE GUIDE

(1) Requirement

With tape gauge positioned as shown, clearance between right and left tape guide and gauge



Min some---Max 0.003 inch

(2) Requirement


Edge of wear plate should be flush with edge of tape guideplate.

To Adjust

With each tape guide mounting nut friction tight, move wear plate upward until it overhangs edge of tape guideplate. Place gauge in position and move gauge and wear plate downward until both studs engage edge of tape guideplate to align common edge. Hold gauge and wear plate and position each guide. (Gauge may touch but not bind.) The tape should not ride on the side of either tape guide.



2.06 Tape Guide Mounting Plate

REPLACING AND POSITIONING TAPE GUIDEPLATE

Note: Position tape-out sensing pin stop arm (2.10) in its lowest position and hold start stop bail extension from ratchet wheel.

- (1) Requirement
Shoulder of feed wheel post should not interfere with top plate or tape guideplate mounting brackets.
- To Adjust
See Note. With feed wheel bearing post clamp nut friction tight, position the post.
- (2) Requirement
Tape guideplate should rest firmly against at least three projections of front and rear plate.
- To Adjust
See Note. With clamp nut that secures tape guideplate mounting bracket (front and rear) friction tight, trip clutch, and rotate shaft until sensing pins are in their uppermost position. With tape lid raised and start-stop lever in run position, press guideplate into position while guiding mounting screws into notch of front and rear plate. Engage tip of tape-out pin with hole in tape guideplate.
- (3) Requirement
Outer edge of front and rear mounting bracket should be located flush with shoulder of mounting stud so that edge of tape guideplate projects over front and rear plate by an equal amount. Gauge by eye. See 2.19.
- To Adjust
Move tape guideplate toward the front or rear. Tighten nuts only after top plate (2.07) is adjusted.

2.07 Top Plate and Coverplate Mounting

REPLACING AND POSITIONING TOP PLATE

To Check

Loosen nuts (friction tight) that secure mounting screws to plate. Press top plate into position while guiding top plate mounting screws into notch of front and rear plate. Position each sensing pin in its slot. Make sure that top plate seats firmly against projections of front and rear plate (3 projections should engage) and tight-tape arm extension is under top plate.

(1) Requirement

Mating edge of top plate should be flush to 0.003 under flush with edge of tape guideplate (within area of tape lid) when plate engages at least 5 projections.

To Adjust

Position top plate, tighten mounting screws, and then tighten nuts that secure tape guideplate mounting brackets (2.06).

(2) Requirement

Feed wheel slot should align with slot in tape guideplate so that feed wheel rotates freely with detents and feed pawl disengaged (freewheeling).

To Adjust

Position top plate toward front or rear to align slot.


(3) Requirement

Clearance between projection of tape lid and top plate (tape lid latched)

Min 0.010 inch---Max 0.020 inch at curved portion	} For fixed width tape guides
Min 0.010 inch---Max 0.018 inch at flat portion	
Min 0.015 inch---Max 0.018 inch at flat portion	

To Adjust

If necessary, loosen tape lid bearing bracket mounting screw (2.04) and position tape lid. Retighten screws and recheck requirements in 2.04.




2.08 Top Plate and Coverplate Mounting (continued)

REPLACING AND POSITIONING COVERPLATE

- (1) Requirement
Right edge of coverplate should be held flush against left edge of top plate by the coverplate detents.
- (2) Requirement
Coverplate should rest against at least three of the four projections (front and rear plate).
- (3) Requirement
Front edge of coverplate and top plate should align.

To Adjust

With detenting nut clampscrew (front and rear plate) friction tight, move clampscrews to their extreme lower right position then tighten screws. Loosen detent bracket and spring plate mounting nuts. Place cover on unit and position horizontally to meet the requirements. Retighten mounting nuts.



2.09 Tape-Out Contact Mechanism

TAPE-OUT CONTACT ASSEMBLY

(1) Requirement

Coverplate and top plate removed; start-stop switch in stop position; removal of tape guideplate optional. With tape-out spring bracket friction tight, move bracket downward until tape-out pin extension clears insulated portion of contact swinger. With gram scale applied as shown

Min 8 grams---Max 15 grams
to separate normally closed contacts.

To Adjust

Remove bail spring and contact assembly. Form the contact swinger with the TP110445 spring bender.

(2) Requirement


Clearance between normally closed contacts

Min 0.008 inch---Max 0.015 inch

To Adjust

Form upper contact spring using the TP110445 spring bender.

Note: Replace contact assembly with swinger over tape-out pin extension. Place spring bracket shoulder bushing on upper hole and the washer on lower mounting hole.



TAPE-OUT CONTACT BRACKET

Requirement

With tape-out pin depressed by tape under tape lid, clearance between tape-out pin extension and insulator on swinger contact

Min 0.006 inch---Max 0.020inch

To Adjust

Position switch bracket with its mounting screws loosened.

TAPE-OUT SENSING PIN SPRING

Requirement

With start-stop lever in run position

Min 38 grams---Max 45 grams
to move pin to a position flush with tape guideplate.

To Adjust

With contact bracket lower mounting screw loosened position the spring bracket.

2.10 Tape-Out Sensing Pin Mechanism

TAPE-OUT SENSING PIN

(1) Requirement

With start-stop lever in free wheeling or stop position, tip of tape-out pin should be flush to 0.010 inch under flush below top surface of tape guideplate.

To Adjust

Place start-stop lever in stop position. With stop arm clampscrew friction tight, position the stop arm.

(2) Requirement

With start-stop lever in run position, clearance as shown should be at least 0.055 inch.

To Adjust

Place start-stop lever in run position and loosen tape-out bail clampscrew. Position extension arm with tommy wrench or similar tool. Recheck (1) Requirement.

STOP ARM
CLAMPSCREW

DEPRESSOR BAIL
TORSION SPRING

INTERMEDIATE
TAPE-OUT BAIL

TAPE-OUT PIN
DEPRESSOR BAIL

DEPRESSOR BAIL TORSION SPRING

Requirement

Tape-out bail spring unhooked. Start-stop lever in stop position
Min 2-3/4 oz ---Max 5-1/2 oz
to start intermediate tape-out bail moving away from tape-out pin depressor bail.

TAPE-OUT BAIL
SPRING

INTERMEDIATE
TAPE-OUT BAIL

STOP ARM
CLAMPSCREW

SENSING PIN
STOP ARM

TAPE-OUT PIN
DEPRESSOR BAIL


TAPE-OUT
SENSING PIN

INTERMEDIATE TAPE-OUT
BAIL SPRING

Requirement

With start-stop lever in its run position, hook spring scale in loop.

Min 3 oz ---Max 5 oz
to pull spring to its installed length.



2.11 Start-Stop Switch Assembly

(A) START-STOP SWITCH BRACKET

(1) Requirement


With start-stop lever in run position and clutch in its disengaged position, clearance between start-stop bail extension and insulator on start-stop switch swinger
 Min 0.006 inch---Max 0.015 inch

To Adjust
 With switch bracket mounting screws loosened, position the bracket.

(2) Requirement

Start-stop bail extension should fully engage insulated portion of switch swinger.

To Adjust
 Loosen contact pile-up mounting screws and align contact assembly.



(B) TIGHT-TAPE START-STOP CONTACT SPRING

Requirement

With start-stop lever in run position
 Min 3 oz---Max 4 oz
 to separate contacts.

To Adjust
 Form swinger with TP110445 spring bender.

Note: Recheck Adjustments (A) and (C).

START-STOP TIGHT-TAPE SWITCH

(C) TIGHT-TAPE INTERMEDIATE ARM

Requirement

With start-stop lever in run position, tight tape start-stop contacts should function as follows:


- (a) Remain closed when tight tape bail is raised 0.045 inch.
- (b) Open as bail is raised to height of 0.075 inch.

To Adjust
 With tight-tape intermediate arm clamp-screw loosened, position the arm at its adjusting slot.

(D) TIGHT-TAPE INTERMEDIATE ARM SPRING

Requirement


With start-stop lever in run position,
 Min 20 grams (3/4 oz)---Max 40 grams (1-1/2 oz)
 to start intermediate arm moving away from its yield arm.



2.12 Main Bail Assembly

(C) CONTROL LEVER DETENT SPRING
(Not on relay controlled unit)

Requirement
Control lever in run position
— Min 14 oz ---Max 22 oz
to start detent bail moving away from control lever detent.




(D) MAIN BAIL TRIP LEVER

Requirement (Replace top plate)
Unit in stop position, clearance between tip of highest sensing pin and top surface of tape guideplate should be flush to 0.005 inch below.

To Adjust
Loosen front and rear transfer lever guide post nuts and rotate post so that its eccentric positions trip lever.

(B) FEED RATCHET DETENT SPRING

Requirement
With main shaft in stop position and feed pawl held away from its ratchet
— Min 8 oz ---Max 13 oz
to start roller moving away from ratchet.



(A) MAIN BAIL SPRING

Requirement (Top plate removed)
Clutch disengaged, unit on its back. Spring unhooked from main bail
— Min 6 oz ---Max 10 oz
to pull spring to installed length.


2.13 Code Sensing Fingers

(A) SENSING FINGER SPRING

Requirement

Unit in upright position, sensing fingers in their uppermost position, and rubout deleter bail held away from the sensing finger


Min 2 oz ---Max 3 oz
to move a sensing finger to a position flush with the tape guideplate.



(B) FEED WHEEL DETENT

Requirement

With tape lid raised, sensing fingers down, high part of feed wheel detent eccentric toward the right, rubout perforated tape between tape guides, and play in tape taken lightly toward the right. Tip of each sensing finger should be centrally located in the code holes.



To Adjust

Hold feed pawl away and rotate the feed wheel detent eccentric screw. See figure on page 15.

2.14 Feed Pawl Mechanism

(A) FEED PAWL

Requirement (Top plate removed)

With high part of eccentric toward the right and sensing fingers in their lowermost position, clearance between feed pawl and ratchet tooth just engaged.

Min some---Max 0.003 inch

To Adjust


With eccentric screw locknut loosened, position the screw. Recheck requirement at four positions of ratchet approximately 90 degrees apart.

(B) FEED PAWL SPRING

Requirement

With unit tilted toward the left and main shaft in its stop position

Min 2 oz---Max 3-1/2 oz to start pawl moving.



(C) TRANSFER LEVER SPRING

Requirement

With unit resting on its rear plate and main shaft in its stop position

Min 1/2 oz---Max 1-1/2 oz to start each lever moving.

2.15 Main Bail Trip Assembly

(A) MAIN BAIL

(1) Requirement (Replace top plate)


Main bail in lowest position, horizontal clearance between main bail arm and main bail trip lever should be
 Min some---Max 0.015 inch

(2) Requirement

Main bail in lowest position and clutch magnet operated, clearance between vertical surfaces should be
 Min 0.005 inch

To Adjust

Position main bail eccentric with nut on eccentric screw loosened. Check and refine, if necessary, MAIN BAIL TRIP LEVER (2.12).



(B) LOCKING BAIL SPRING

Requirement
 With unit tilted toward the left and in stop position
 Min 10 oz---Max 14 oz
 to start bail moving.

2.16 Transfer Bail Stabilizer Mechanism


(A) TRANSFER BAIL STABILIZER**Requirement**

- (a) With a rubout combination selected, rotate main shaft until no. 3 transfer lever is on high part of its cam. Check clearance between side of transfer bail extension and its latch.
- (b) Repeat above procedure with a space combination selected and check the clearance on other latch. Clearance in marking and spacing position should be equal within 0.002 inch.

To Adjust

With stabilizer assembly mounting screws friction tight, position the assembly.

Note: Latches should drop in place as other transfer levers cam the transfer bail. Where possible, use a signal checking device to refine this adjustment following SIGNAL CONTACT ADJUSTMENT (2.17).

**(B) STABILIZER SPRING****Requirement**

With unit upright and main shaft in stop position

Min 2-1/2 oz---Max 5 oz

to start stabilizer latch moving.

2.17 Signal Contact Assembly

(A) SIGNAL CONTACT


Requirement (Coverplate and contact box cover removed)

Contact gap in the marking position and the spacing position should be equal when clearance between respective contacts is maximum. (Engage clutch and rotate main shaft slowly.)

To Adjust

With contact box mounting screws friction tight, position box with its eccentric.

Note: Use test set such as DXD where possible to refine adjustment. Refer to 2.21.



(B) SIGNAL CONTACT SPRING

Requirement

With main shaft in stop position and cover of contact box removed, unhook toggle link spring and move transfer bail to spacing position (right)

Min 2 oz ---Max 3-1/2 oz
to open spacing contacts (left).

(C) SIGNAL CONTACT LINK SPRING

Requirement

With main shaft in stop position and stabilizer spring unhooked, move latches away from transfer bail extension (2.16). Hold toggle firmly against contacts.

Min 6 oz ---Max 12 oz
to start transfer bail extension moving.

2.18 Clutch Trip Magnet Assembly

(A) CLUTCH MAGNET


(1) Requirement

With armature in its energized position, the armature should contact the core of the magnet farthest away from the armature hinge. Clearance between armature and core nearest armature hinge

Min 0.004 inch---Max 0.007 inch
at point of least clearance.

To Adjust

With magnet assembly mounting screws removed, lift assembly from unit. Invert assembly, loosen hinge bracket mounting screws and position bracket.



(2) Requirement

With armature in its energized position and high part of backstop eccentric upward, clearance between armature bail and backstop

Min 0.045 inch---Max 0.055 inch

To Adjust

Loosen backstop clamp nut and position the eccentric.

(B) ARMATURE BAIL SPRING

Requirement

With armature in de-energized position and main bail latchlever held away

Min 2 oz---Max 2-3/4 oz
to start armature moving.

(3) Requirement


With magnet assembly replaced and clutch disengaged, clearance between end of armature bail extension and main bail latch

Min 0.007 inch---Max 0.015 inch

To Adjust

With bracket mounting screws friction tight, move assembly to its lowermost position then position bracket by its adjusting slot. Refine requirements if necessary.

BACKSTOP
(ECCENTRIC)
CLAMP NUT



(C) MAIN BAIL LATCH SPRING

Requirement

With unit inverted and main bail latch released

Min 3/4 oz---Max 2 oz
to start main bail latch moving.

2.19 Tape Lid Assembly


(A) COVERPLATE DETENT SPRING

Requirement

With spring scale applied to center of one detent

Min 28 oz---Max 40 oz
to start plunger moving.

Note: Outer edge of each mounting bracket should be approximately in line with shoulder of its mounting stud. Replace tape guideplate, tape-out tension spring, top plate, and coverplate.



(B) TAPE LID RELEASE BUTTON SPRING

Requirement

With tape guideplate held horizontally and tape lid unlatched


Min 28 oz---Max 48 oz
to start tape lid bail moving.

(C) TAPE LID SPRING

Requirement

With tape lid release button held fully depressed and tape guideplate in horizontal position

Min 2-1/2 oz---Max 4-1/2 oz
to move open end of tape lid against the guideplate.



2.20 Transmitter Distributor Gear


TRANSMITTER DISTRIBUTOR GEAR

Requirement


There should be only a perceptible amount of backlash between the intermediate drive gear and transmitter distributor gear

To Adjust

With transmitter distributor mounting screws (3) loosened, position the unit on base.



2.21 Signal Pulse Refinement



CAUTION: ON ALL UNITS EQUIPPED WITH A SIGNAL REGENERATOR CIRCUIT, REMOVE THE SIGNAL REGENERATOR CARD BEFORE APPLYING DXD TIMING PROBES TO CONTACT ACCESS TERMINALS.

SIGNAL PULSE REFINEMENT — FINAL ADJUSTMENT WITH DXD OR STROBE (if available)
 (11.0 Unit Code - Speeds up to and including 100 wpm)

Procedure

Plug signal distortion test set into signal line to view pulse image generated by the marking and spacing contacts. Synchronize signal generator with DXD so that end of stop pulse image aligns with the 200 mark on DXD scale when both units are operated at same speed and transmission is continuous.

Note 1: Figures appearing in () in 2.21 and 2.22 are relaxed requirements for transmitter distributor sets used in circuits that employ a signal regenerator.

Note 2: End of stop pulse image should not vary from the 200 mark by more than one scale division. If a greater variation occurs, move the scale until the variations extend equally on either side of the 200 mark.

(1) Requirement

- (a) Each marking code pulse should start no later than the 8th (12th) mark of the pulse under observation and start no earlier than 92nd (88th) mark of the previous pulse.
- (b) Each marking code pulse should end no earlier than the 92nd (88th) mark of the pulse under observation and no later than the 8th (12th) mark of the following pulse.
- (c) Each marking code pulse may have one break provided the break is not over three divisions wide and provided the break occurs only at the end of the code pulse image between the 92nd (88th) mark and the end of the image.
- (d) The stop pulse should start no earlier than the 92nd (88th) mark of the last intelligence pulse and start no later than the 8th (12th) mark of the stop position.
- (e) The stop image should not change in length or position, when viewed on DXD, to exceed one division while changing from R to Y selection (or equivalent codes). If necessary, reorient 200 mark on stop scale with end of stop pulse image.

2.22 Signal Pulse Refinement (continued)**To Adjust**

With signal contact box mounting screws friction tight, rotate the eccentric (right or left). Tighten mounting screws and recheck adjustment.

(2) Requirement

When the spacing contact of the signal generator is wired the spacing contact should meet the following requirements:

- (a) Each spacing code pulse should start no later than the 8th (12th) mark of the pulse under observation and start no earlier than the 92nd (88th) mark of the previous pulse.
- (b) Each spacing pulse should end no earlier than the 92nd (88th) mark of the pulse under observation and end no later than the 8th (12th) mark of the following pulse.
- (c) Each spacing pulse may have one break provided the break is not over three divisions wide and provided the break occurs only at the end of the code pulse image between the 92nd (88th) mark and the end of the image.
- (d) The start pulse should start no earlier than the 192nd (188th) mark of the stop pulse and start no later than the 8th (12th) mark of the start pulse. The start pulse should end no earlier than the 92nd (88th) mark of the start pulse and end no later than the 8th (12th) mark of the number one pulse.

To Adjust

Same as above. Recheck marking contact if a spacing adjustment is made.

Note 3: If the signal requirements cannot be met, refine TRANSMITTER DISTRIBUTOR GEAR (2.20) and TRANSFER BAIL STABILIZER (2.16) with signal viewed on DXD.

2.23 Gold-Plated Signal Contacts

(A) Units may have signal contacts made of either unplated or gold-plated tungsten. If in doubt as to the type of contacts, remove signal generator cover and inspect contacts for gold plating.

(B) Cleaning

- (1) Use twill jean cloth (KS2423, TP107162) to clean gold-plated contacts.
- (2) Open contacts. Drop strip of twill jean between them. Close contacts. Draw twill jean part way through. Open contacts and withdraw twill jean.
- (3) This procedure prevents small fibres at edges of twill jean strip from becoming lodged between contacts.
- (4) Clean unplated tungsten contacts in accordance with standard procedures.

(C) Servicing for Low-Voltage Applications

- (1) For standard applications including those with data sets, observe standard maintenance procedures and intervals. Low-voltage applications are covered below.
- (2) The recommended cleaning interval for gold plated contacts in special low level applications (less than 250 microwatts) having an average weekly use of 60 hours should not exceed 90 days. This interval may be reduced, dependent on the signal circuit configuration, usage, and environment. Contacts should be cleaned as described in (B) Cleaning, above.

Note 1: Applying operating voltage of standard Distortion Test Set directly to contacts may damage gold plating and impair low-voltage operation. When electrically adjusting or testing contacts (2.17) use an intermediate device, keyed by the contacts, to interrupt current to stroboscopic lamp of test set. This intermediate device must be capable of being keyed by a 3- to 20-volt change at maximum of 20 milliamperes.

Note 2: Normally for low-voltage applications contacts should be used in circuits operating between 3 and 20 volts dc at a current level not to exceed 60 milliamperes. Between 20 and 70 volts dc the current should be adjusted so as not to exceed a 120 milliwatt power level. The contacts are not normally intended for use on voltages above 70 volts dc. Exceeding this level for an appreciable length of time may result in damage to gold plating and make them unfit for low-voltage applications.

Note 3: The above information also applies to 2.17, 2.21, and 2.22 of this section.

3. VARIABLE FEATURES

3.01 Timing Contact Mechanism (Early Design)

(C) TIMING CONTACT SPRING

Requirement

Min 5 oz ---Max 8 oz
to move spring from stiffener.


To Adjust

Remove contact bracket assembly, loosen contact pile-up mounting screws and bend contact spring with bender (TP110445). Retighten pile-up mounting screws and check. Replace contact bracket assembly. Refine adjustments (A) and (B), if necessary.

(D) CAM FOLLOWER SPRING

Requirement

With unit in stop position and timing:
contact swinger spring held away
Min 2 oz ---Max 4 oz
to start cam follower moving.



(A) TIMING CONTACT BRACKET

(1) Requirement

With follower on low part of cam contacts should be closed when nylon pad is raised 0.006 inch and open when pad is raised 0.010 inch.

(2) Requirement

With follower on any peak of cam, contact gap should be
Min 0.003 inch
on units prior to serial No. 42200
Min 0.015 inch

(B) TIMING CONTACT SWINGER

Requirement

With contact closed
Min 2 oz ---Max 3 oz
to just separate contacts


To Adjust

Bend swinger with spring bender TP110445.

To Adjust

Place unit in stop position. Adjust contact bracket by means of screwdriver lug, visible through hole in rear plate, with bracket mounting screws loosened.

3.02 Timing Contact Refinement

**TIMING CONTACT REQUIREMENTS (STROBE) (Using Distortion Test Set (DXD)**

- (1) Zero the test set as previously described (2.21), if available).
- (2) The light image of the timing contacts should meet the following requirements for speeds up to and including 100 wpm.
 - (a) Open for a minimum of 20 divisions between the 25 division and 75 division points of each 100 division pulse.
 - Open for a minimum of 120 divisions between the 25 division and 175 division points of the stop pulse.
 - (b) The close to open transitions should be in multiples of 100 divisions ± 5 divisions from the close to open transition of the start pulse.
 - (c) There should be no contact break between the 0 division point and the close to open transition point and no contact break between the 75 division point and 100 division point of each pulse. There should be no contact break between 175 division point and the 200 division point of the stop pulse.

3.03 Timing Contact Refinement (continued)

- (d) Check and refine, if necessary, **TIMING CONTACT BRACKET (3.01)** for early design, or **TIMING CONTACT BRACKET-PRELIMINARY (3.05)** for later design.
- (e) The timing contacts should be open in the rest position of the transmitter distributor.

To adjust, loosen the two timing contact bracket mounting screws until they are friction tight. Position the timing contact assembly by means of the screwdriver lug on the bracket visible through a hole in the rear plate so that the requirements are met. Tighten the screws and recheck the image on the DXD stroboscope.


3.04 Timing Contact Mechanism (Late Design)

Note: The timing contact assembly must be removed to check the following requirements.

(A) CAM FOLLOWER SPRING

Requirement

With the unit upright and in the stop position, it should require
Min 2 oz ---Max 4 oz
to start the cam follower moving.




(B) TIMING CONTACT ALIGNMENT

Requirement

The contact points should be in line and the head of the plunger should be centered in the hole in the lower contact spring as gauged by eye.

To Adjust

With the contact assembly mounting screws friction tight, position the contact springs. Tighten screws firmly.



(C) TIMING CONTACT GAP

Requirement

With the plunger depressed flush with the bushing, the contact gap should be
Min 0.045 inch ---Max 0.065 inch

To Adjust

Bend the lower contact spring.

(Rear View)

3.05 Timing Contact Mechanism (Late Design)

TIMING CONTACT SPRING


Requirement

Min 3-1/2 oz --- Max 4-1/2 oz
to open the normally closed contacts.

To Adjust

Bend the contact swinger.

Note: Replace the timing contact assembly at this time.



(Rear View)

TIMING CONTACT BRACKET — PRELIMINARY

(1) Requirement


With the unit in the stop position

Min 0.008 inch --- Max 0.011 inch
gap between the contacts.


(2) Requirement

With cam follower on each low part of cam and clearance taken up between plunger and cam follower.

Min some --- clearance between
plunger and contact swinger.



(Rear View)



(Rear View)

To Adjust

With unit in the indicated position and the timing contact bracket mounting screw and contact adjusting clamp nut friction tight, position the contact assembly by means of the eccentric to meet Requirements (1) and (2). Tighten the mounting screw and eccentric clamp nut and recheck the adjustments.

Related Adjustment

TIMING CONTACT REQUIREMENTS (3.02)

3.06 Rubout Sensing Mechanism

(A) RUBOUT SENSING MECHANISM

Requirement


With DELETE (rubout) selection set up and timing bail on low part of its cam, the start-stop contact gap should be

---Min 0.018 inch---Max 0.025 inch

Use light thumb pressure to hold bail against its cam when checking gap.

To Adjust

Position the timing arm on the yield arm with its clampscrew friction tight.



(B) TIMING BAIL SPRING

Requirement

Min 5-1/2 oz ---Max 8 oz
to start the bail moving.

3.07 Code Reading Contacts

Initial Adjustments

Note: Initial adjustments should be made with the code reading contact assembly removed from the transmitter unit.



(A) NORMALLY CLOSED CONTACTS — BACKSTOP

Requirement

The lower contact leaves for all levels should be parallel to the mounting plate and in line with one another.

To Adjust

Bend backstop to meet requirement.



(B) NORMALLY CLOSED CONTACTS — SPRING TENSION

(1) Requirement

With swinger held away
— Min 2 oz---Max 6 oz
to move lower contact leaf away from backstop.

To Adjust

Bend lower leaf. If it is necessary to bend backstop to obtain required tension, reposition backstop to meet NORMALLY CLOSED CONTACTS — BACKSTOP adjustment.

(2) Requirement

— Min 30 grams---Max 40 grams
to open normally closed contacts.

To Adjust

Bend swinger.

(C) NORMALLY OPEN CONTACTS — BACKSTOP

Requirement

— Min 0.010 inch---Max 0.015 inch
gap between normally open contacts.

To Adjust

Bend associated backstop to meet requirement.



(D) NORMALLY OPEN CONTACTS — SPRING TENSION

Requirement

— Min 30 grams---Max 40 grams
to move normally open contacts away from backstop.

To Adjust

Bend upper contact leaf. If it is necessary to bend backstop to obtain required tension, reposition backstop to meet NORMALLY OPEN CONTACTS — BACKSTOP adjustment.



3.08 Code Reading Contacts (continued)

Secondary Adjustments

Note: The secondary adjustments should be made with the code reading contact assembly installed in the transmitter, and with the contact assembly bracket approximately centered in its adjustment range.


(A) CONTACT ASSEMBLY

Requirement

The swinger of each contact pile-up should be aligned with its associated sensing arm, as gauged by eye.

To Adjust

Loosen the screws which mount the contact assembly to the contact bracket, and position the assembly to meet requirement.




(B) CONTACT BRACKET

Requirement

With the null combination selected and the upstop post out of the way
 Min 0.015 inch---Max 0.025 inch
 gap between contact assembly swingers and insulator on contact sensing arm.

To Adjust

Loosen the contact bracket mounting screws ((A) CONTACT ASSEMBLY) and position the bracket to meet requirements.



3.09 Code Reading Contacts (continued)

Secondary Adjustments (continued)

(A) ECCENTRIC UPSTOP


Requirement

With rubout combination selected, clutch engaged, and main shaft rotated until the sensing arms are in their uppermost position, there should be

Min some---Max 0.008 inch clearance between the upper contact leaf and its backstop.

To Adjust

Loosen the nut that secures the eccentric upstop to the front plate and turn the eccentric until the requirement is satisfied. The high part of the eccentric should be toward left.



(B) SENSING ARM SPRING

Requirement

With clutch disengaged
Min 2-1/2 oz---Max 3-1/2 oz
to start sensing arm moving.

SENSING ARM

SENSING ARM SPRING

ECCENTRIC UP-STOP

(C) SPLIT BAIL ECCENTRIC


Requirement

With the null combination selected and clutch tripped, clearance between the transfer levers and associated sensing arms

Min 0.020 inch---Max 0.030 inch

To Adjust

Rotate the split bail eccentric with its locknut loosened.



3.10 Code Reading Contacts (continued)

Final Adjustments (Strobing)

CONTACT BRACKET


Note 1: A DXD, if available, operating at 600 opm with an 11 unit code scale should be used for strobing.

- (1) Requirement
Marking pulse (trace) length
Min 625---Max 708 scale divisions
- (2) Requirement
Marking pulse breaks to be confined to first and last 15 scale divisions of trace.
- (3) Requirement
Spacing pulse (trace) length full scale trace without breaks.

To Adjust

Loosen the contact bracket mounting screws and position bracket to meet requirements.


Note 2: If requirements cannot be met, recheck Initial and Secondary Adjustments and refine if necessary.



3.11 Auxiliary No. 1 Contact Assembly

Initial Adjustments

Note: The initial adjustments should be made with the auxiliary contacts removed from the transmitter unit.



3.12 Auxiliary No. 1 Contact Assembly (continued)

Secondary Adjustments

Note: The secondary adjustments should be made with the auxiliary contacts installed.

(A) CONTACT BRACKET

Requirement

With clutch disengaged and latched, clearance between the insulator on the swinger and the bail

Min 0.025 inch---Max 0.035 inch

To Adjust

Position the contact bracket with its mounting screws loosened.


(B) CONTACT ASSEMBLY

Requirement

The swinger insulator should be centrally located with respect to its operating bail.

To Adjust

Loosen the contact assembly screws and position the swinger and contact springs.



(C) OPERATING BAIL SPRING

Requirement

Clutch disengaged

Min 5 oz---Max 7 oz

to move follower roller away from low part of its cam.

3.13 Auxiliary No. 1 Contact Assembly (continued)

Final Adjustment (Strobing)

CONTACT BRACKET

Note 1: A DXD, if available, operating at 600 opm with an 11 unit code scale should be used for strobing.

(1) Requirement

Auxiliary No. 1 contact trace should begin a minimum of 10 divisions after latest code reading contact has closed, have a minimum pulse length of 590 divisions, and end a minimum of 14 divisions before earliest code reading contact has opened.



(2) Requirement

Trace may have a maximum of two 2-division breaks within 8 divisions of the start or end of trace.

To Adjust

Loosen the contact mounting bracket screws and position bracket to meet requirements.

Note 2: If requirements cannot be met, recheck Initial and Secondary Adjustments.



3.14 Auxiliary No. 2 Contact Assembly

Initial Adjustments

(A) BREAK-MAKE CONTACT SPRING

Requirement

Min 4 oz---Max 5 oz
to open normally closed contacts.

To Adjust

Bend break-make contact spring.

(B) MAKE CONTACT STIFFENER

Requirement

Min 0.010 inch---Max 0.020 inch
gap between normally open contacts.

To Adjust

Bend stiffener.


(C) MAKE CONTACT SPRING

Requirement

Min 5-1/2 oz---Max 6 oz
to move make contact spring away
from stiffener.

To Adjust

Bend make contact spring.



3.15 Auxiliary No. 2 Contact Assembly (continued)

Secondary Adjustments

(A) CONTACT BRACKET

To Check

Disengage and latch clutch.

Requirement

Min 0.015 inch---Max 0.020 inch
clearance between insulator on break-make contact spring and
operating surface on cam follower.

To Adjust

Loosen contact mounting bracket screws and position contact
assembly using pry point.

(B) CONTACT ASSEMBLY

To Check


Clutch tripped, rotate main shaft until insulator on break-make
contact spring is in contact with cam follower.

Requirement

Insulator on break-make contact spring to be centrally located
on operating follower extension and contacts of contact
springs to be aligned.

To Adjust

Loosen contact assembly mounting screws and position contact springs.



(C) CAM FOLLOWER SPRING

To Check

Disengage clutch.

Requirement

Min 2-1/2 oz---Max 3-1/2 oz
to move cam follower away from cam.

3.16 Auxiliary No. 2 Contact Assembly (continued)

Final Adjustments (Strobing)

CONTACT BRACKET

Note 1: A DXD, if available, operating at 600 opm with an II unit code scale should be used for strobing. Disconnect one end of the filter network before strobing contacts.

(1) Requirement

Auxiliary No. 2 contact trace should begin a minimum of 296 divisions after latest code reading contact has closed, have a minimum pulse length of 253 divisions and a maximum of 275 divisions, and end a minimum of 21 divisions before earliest code reading contacts have opened.


(2) Requirement

Trace may have a 2-division break within the first and last 8 scale divisions of the trace.

To Adjust

Loosen the contact mounting bracket screws and position bracket to meet requirements.

Note 2: If the requirement cannot be met, recheck Initial and Secondary Adjustments.



35 CABINET FOR AUTOMATIC SEND-RECEIVE


TELETYPEWRITER SET

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL.	1	Upper cover position (front to rear) . . .	4
2. ADJUSTMENTS	2	Window (final)	10
		Window (preliminary)	6
Bubble latch plate (final)	10	1. GENERAL	
Bubble latch plate (preliminary)	6	1.01 This section is reissued to update for-	
Bubble position front and rear		mat and add recent engineering changes.	
(final).	10	Since this is a general revision, marginal ar-	
Bubble position front and rear		rows normally used to indicate change have been	
(preliminary).	6	omitted.	
Call control unit height	11	1.02 The adjustments in this section are ar-	
Call control unit mounting bracket. . .	11	ranged in a sequence that should be fol-	
Cleaning cabinets.	11	lowed if a complete readjustment is undertaken.	
Control panel.	9	A complete adjusting procedure should be read	
Copyright bracket and end of line		before attempting to make the adjustment. After	
lamp	5	an adjustment is completed, be sure to tighten	
Counterbalance arm	4	any nuts or screws that may have been loosened,	
Cover.	12	unless otherwise instructed.	
Cradle front to rear — earlier		1.03 The adjusting illustrations indicate tol-	
design	7	erances, positions of moving parts,	
Cradle front to rear — later		spring tensions, and the angle at which scales	
design	8	should be applied. The tools required to make	
Cradle height (final) — earlier		adjustments and check spring tensions are not	
design	7	supplied with the equipment, but are listed in	
Cradle height (final) — later		another section. Springs which do not meet the	
design	8	requirements, and for which there are no ad-	
Cradle height (preliminary) —		justing procedures, should be discarded and re-	
earlier design	7	placed by new springs.	
Cradle height (preliminary) —		1.04 Where adjustment instructions call for	
later design.	8	removal of components, assemblies,	
Front height of lower cover —		subassemblies or parts, all adjustments which	
later design.	8	the removal of the parts might facilitate should	
Latch.	4	be made before the parts are replaced or as the	
Line guide copyholder.	5	equipment is reassembled. When a part mounted	
Lower cover latch	15	on shims is removed, the number of shims and	
Lower panel pivot post	16	their location should be noted so that the iden-	
Opening and closing of cover	2	tical pile-up can be made when the part is re-	
Paper and form guide	10	placed.	
Tape chute	13	1.05 References made to left or right, up or	
Tape tearing edge.	14	down, or front or rear apply to the unit	
Transmitter control panel	12	in its normal operating position as viewed from	
Upper apparatus mounting rack		the operator's position in front of the unit.	
bracket.	11		
Upper cover clearance (latched)	4		


2. ADJUSTMENT

2.01 Opening and Closing of Cover




2.02 Opening and closing of Cover (continued)

(A) Follow instructions for opening of cover in Par. 2.01.



(B) Close upper cover to fully closed latched position.


INSIDE BACK OF COVER IN OPEN POSITION
(VIEW LOOKING STRAIGHT DOWN)



(D) Loosen hinge lock bracket mounting screw and slide bracket away from hinge.


(C) Remove the upper retaining shoulder screw from the right hand stop arm bracket.

LEFT STOP ARM




LEFT SIDE OF COVER

(E) Support cover from rear. Remove acorn type nut and disengage stop arm from cover.



RIGHT SIDE OF COVER

RIGHT STOP ARM



(F) Supporting the cover from the rear, remove by sliding sideways to separate hinges. The cover may be grasped as shown.

Note: Cover weighs approximately 39 pounds.

To replace cover, reverse removal procedure.

2.03 Upper Cover Arrangement

(B) UPPER COVER CLEARANCE (LATCHED)

Requirements

- (1) Rubber grommets should be slightly compressed.
- (2) There should be no metal-to-metal contact between upper and lower covers.
- (3) Clearance between upper cover and lower cover should be 0.090 inch maximum at sides and 0.200 inch maximum at rear.

To Adjust

Position cover with two screws, that mount each hinge to lower cover, loosened.

Note: This adjustment should be made in conjunction with the latch adjustments.

(A) UPPER COVER POSITION (FRONT TO REAR)

Requirement

Clearance between front of upper cover and edge of keyboard opening in lower cover (right and left ends of window depression) should be
Min 4-1/2 inches---Max 4-5, 8 inches

To Adjust

Position cover with three screws, at each hinge that mount upper cover, loosened. See figure below.



(C) LATCH

Requirements

- (1) Without depressing latch buttons as upper cover is lowered, camming surfaces of latches should contact lower cover.
- (2) Latch button should not become disengaged from guide slot in cover when fully depressed.
- (3) All requirements of upper cover clearance adjustment should be met. Upper cover should latch closed with slight compression of rubber bumpers and no metal-to-metal contact.

To Adjust

Position both latches with their pivot screws loosened.





(D) COUNTERBALANCE ARM

Requirements

- (1) There should be no free fall of upper cover from any position to which it is opened.
- (2) There should be some pressure required to close upper cover.


To Adjust

Tighten spring tension adjusting screws.



Note: LATCH adjustment should be made in conjunction with the UPPER COVER CLEARANCE (Par. 2.03).

2.04 Copyright and Line Guide Copyholder



COPYLIGHT BRACKET AND END OF LINE LAMP

(1) Requirement
 Clearance between copy lamp bulbs and the cabinet should be
 Min 0.030 inch---Max 0.090 inch

To Adjust
 Loosen the two bracket mounting nuts and position the copy
 lamp bracket to meet (1) Requirement.

(2) Requirement
 Filament of end of line lamp bulb should be centered under
 red lamp cover.


To Adjust
 Loosen the two bracket mounting screws and position the end
 of line lamp bracket to meet (2) Requirement.

LINE GUIDE COPYHOLDER

(Front View)

COPYHOLDER TRAY

LINE GUIDE COPYHOLDER



Requirement

Tension of line guide copyholder should be just sufficient to hold copy in
 place and prevent the line guide copyholder from slipping down the shaft.

To Adjust

Remove two shaft mounting screws from inside cover and take off line guide
 copyholder. Remove line guide from shaft and rotate bushing in direction
 to increase or decrease torsion spring tension against line guide. Reas-
 semble line guide and reinstall on cover.

2.05 Bubble and Window Position

Note: Adjustments on this page are preliminary.
Final adjustments to be made with typing unit in place.

(C) WINDOW (PRELIMINARY)

(1) Requirement


Clearance between rear edge of window and front edge of paper guide on bubble should be
Min 0.045 inch---Max 0.095 inch

(2) Requirement

The gap at both ends of the paper guide should not differ by more than 0.030 inch.

To Adjust

Loosen four screws which mount two window clamps and position window.



(B) BUBBLE LATCH PLATE (PRELIMINARY)

Requirement

Bubble should not open when upper cover is raised. Bearing surfaces of latch plates should protrude a minimum beyond edge of upper cover consistent with this requirement. Edges of cover and plates should be parallel.

To Adjust

Position latch plates with two nuts that fasten each plate to upper cover loosened.

(A) BUBBLE POSITION, FRONT AND REAR (PRELIMINARY)

Requirement

The bubble should be in the center of its frontmost and rear-most positions.

To Adjust


Loosen two mounting screws that mount each pivot bracket and position bubble, tighten screws.

2.06 Cradle Adjustments (Earlier Design)

(A) CRADLE HEIGHT (PRELIMINARY)

Requirement
Distance from pan to top of cradle at four corners should be 1-3/16 inches.

To Adjust
Loosen four cradle mounting screws. Turn adjustment bushing from beneath cabinet through access holes. Tighten cradle mounting screws.



(B) CRADLE HEIGHT (FINAL)

Note: Make this adjustment with motor and typing unit in place.

(C) CRADLE FRONT TO REAR

Note: Make this adjustment with motor and typing unit in place.

(1) **Requirement**
Clearance between cover and front edge of keyboard should be
Min 0.060 inch---Max 0.090 inch





(2) **Requirement**
Clearance between top front edge of keylever guideplate and upper surface of cover should be
Min 0.047 inch---Max 0.090 inch

To Adjust
With cradle mounting screws loosened, move cradle from front to rear until requirements are met. Refine cradle height if necessary. Tighten screws.

(1) **Requirement**
Clearance between top of keylever guideplate and upper edge of the cover should be
Min 0.047 inch---
Max 0.090 inch

(2) **Requirement**
Top of base at rear corners should be 3 inches above pan.

To Adjust
Refine adjustment (A) CRADLE HEIGHT (PRELIMINARY) above.



2.07 Cradle Adjustments (Later Design)


(A) CRADLE HEIGHT (PRELIMINARY)

Requirement

Distance from pan to top of cradle at four corners should be 1-3/16 inches.

To Adjust

Loosen four cradle mounting screws. Turn adjustment bushings from beneath cabinet through access holes. Tighten cradle mounting screws.



(B) CRADLE HEIGHT (FINAL)


Requirement

Motor and typing unit in place. Distance from pan to top of base at four corners should be

Min 2-15/16 inch---Max 3-1/16 inch

To Adjust

Loosen four cradle mounting screws. Turn adjustment bushings from beneath cabinet through access hole until requirement is met.




(C) CRADLE FRONT TO REAR

Requirement

Clearance between cover and front edge of keyboard should be 1/16 inch.

To Adjust

Move cradle to front or rear until requirement is met. Tighten cradle mounting screws.



(D) FRONT HEIGHT OF LOWER COVER

Requirement

Clearance between upper edge of cover and top edge of keylever guideplate should be


Min 0.047 inch---Max 0.090 inch

To Adjust

Loosen locknut on height adjustment screw. Turn screw until requirement is met. Tighten locknut.

Note: This adjustment should be made in conjunction with the CRADLE FRONT TO REAR (Par. 2.07).

2.08 Control Panel



Note: Adjustments on this page may be disturbed by jarring the cabinet or base. Before making adjustment, seat keyboard base firmly on centers of rubber mounts.

CONTROL PANEL

(1) Requirement

Clearance between control panel tops and under surface of lower cover should be
 Min panels may be touched but not moved in excess of 0.015 inch
 by lower cover---Max 0.060 inch

(2) Requirement

Clearance between keylever guideplate and adjacent control panels should be
 Min 0.060 inch---Max 0.090 inch


To Adjust (Earlier Design)

Loosen lower bracket mounting screws to friction tight and position brackets from left to right and front to rear. Loosen upper bracket mounting screws and adjust height and angle of control panels. Tighten screws. Make certain that cover rests on its support surfaces and not on control panels. Refine cradle height adjustment if necessary until top of keylever guideplate is flush with top control panels.

To Adjust (Later Design)

Loosen lower bracket mounting screws to friction tight and position brackets from left to right and front to rear. Loosen upper bracket mounting screws to friction tight and raise brackets to uppermost position. Lower the cover to push control panels down to proper positions. Raise cover and tighten mounting screws.

2.09 Paper and Form Guides



(D) WINDOW (FINAL)

- (1) Requirement - Friction Feed Paper Guide
Clearance between edge of window and paper guide should be
Min 0.045 inch---
Max 0.095 inch

- (2) Requirement
Clearance should not differ at each end of paper guide by more than 0.030 inch

To Adjust
Loosen four screws that fasten window clamps (see Par. 2.05) and position window. Tighten screws.

- (1) Requirement - Sprocket Feed Form Guide
Clearance between edge of window and form guide should be
Min 0.045 inch---
Max 0.095 inch

- (2) Requirement
Clearance should not differ at each end of paper guide by more than 0.030 inch. If stapled stationery is used, clearance should be increased to allow four or more copies to pass freely through paper emission slot.

To Adjust
Same as friction feed To Adjust.

(C) PAPER AND FORM GUIDE

- (1) Requirement - Friction Feed Paper Guide
Bottom edge of paper guide should be flush with bottom surface of window.
- (2) Requirement - Sprocket Feed Form Guide
Clearance between form guide and platen should be
Min 3/64 inch---
Max 5/64 inch

To Adjust
Position guide with three paper or form guide nuts loosened. Tighten nuts.

(A) BUBBLE POSITION FRONT AND REAR (FINAL)


Requirement
Front edge of paper or form guide should be about 1/4 inch in front of approximate center of platen. Form guide and bubble should clear all typing unit parts by at least 1/8 inch.

To Adjust
Loosen four mounting screws that mount bubble pivot brackets and position bubble (see Par. 2.05). Tighten screws.

(B) BUBBLE LATCH PLATE (FINAL)

Refine BUBBLE LATCH PLATE (PRELIMINARY) (Par. 2.05) if necessary.

2.10 Call Control Unit
Apparatus Mounting Rack



(B) CALL CONTROL UNIT HEIGHT

Requirement

Enlarged bases of six pushbuttons on call control unit should protrude an equal amount through bezel. Call control lights should protrude through bezel equal amounts.

To Adjust

Loosen five screws that mount front part of call control unit to adjustable bracket on pan and adjust height of front part of call control unit.

CALL CONTROL UNIT MOUNTING BRACKET


(A) CALL CONTROL UNIT MOUNTING BRACKET

Requirement

Pushbuttons and lights on call control unit should be centered in their respective openings in bezel.

To Adjust

Loosen two screws that fasten front call control bracket and position the bracket. Tighten screws.



(C) UPPER APPARATUS MOUNTING RACK BRACKET (Floor Standing Cabinets Only)

Requirement

Speed nut on upper rack bracket should touch back of apparatus mounting racks when bottom of rack is touching two lower brackets with pedestal and racks resting on floor.

To Adjust

Loosen bracket mounting screws and position the bracket. Tighten screws.

CLEANING CABINETS

A soft dry cloth should be used to remove dust, oil or grease from the cabinet. If necessary, a soft damp cloth and mild soap may be used. Rinse cabinet with damp cloth and buff with a dry cloth.

CAUTION: DO NOT USE ALCOHOL, MINERAL SPIRITS OR OTHER SOLVENTS FOR CLEANING THE CABINET.

2. 11 Transmitter Cover and Control Panel

(A) COVER

(1) Requirement


Clearance between paper fence and transmitter should be
Min 0.062 inch---Max 0.156 inch

(2) Requirement

Clearance as measured at both ends should not differ by more than 0.047 inch.

To Adjust

Loosen two paper tray mounting screws and position fence until requirement is met.



(B) TRANSMITTER CONTROL PANEL

(1) Requirement

Clearance between transmitter control panel and transmitter unit should be 0.062 inch.

(2) Requirement

Clearance as measured at both ends should not differ by more than 0.047 inch. The panel should just touch the under surface of the lower cover. The cover should not rest on the panel.


(3) Requirement

Clearance between control panel top and under surface of lower cover should be
Min panel may touch but not moved in excess of 0.015 inch by lower cover---
Max 0.060 inch.

To Adjust

See CONTROL PANEL (Par. 2.08) for instructions.

12 Tape Chute

**To Adjust**

Loosen the two screws which fasten the tape chute mounting bracket to the pan and adjust horizontally. Tighten screws. Loosen the two screws which fasten the tape chute to the bracket and adjust vertically. Tighten screws.

2. 13 Tape Tearing Edge

TAPE TEARING EDGE

(1) Requirement


Tape tearing edge should be approximately 1.16 inch above tape as it emerges from perforator.

(2) Requirement

Tape tearing edge should not interfere with the end of tape coming from perforator and permit tearing tape with straight edge.

To Adjust

With mounting nuts loose, position tape tearing edge until requirements are met.



2.14 Lower Cover Latch (Later Design Only)

LOWER COVER LATCH

(1) Requirement


Latching surfaces should be parallel as judged by eye.

(2) Requirement

Clearance between lower cover latch and latching surface should be
Min some---Max 0.060 inch

To Adjust

Loosen bracket mounting screws and latch mounting nut and make them friction tight. Position latch and bracket until requirements are met. Tighten mounting nut and mounting screws.



2.15 Lower Panel Pivot Post

LOWER PANEL PIVOT POST

(1) Requirement


Maximum endplay of lower compartment panel on its pivot post should be 0.030 inch.

(2) Requirement

Clearance at sides of lower compartment panel with endplay taken up in one direction should not differ by more than 0.045 inch.

To Adjust

Lower panel until engaged with the pivot posts. Loosen locknuts. Position pivot posts until requirements are met. Tighten locknuts.



35 REPERFORATOR BASES

ADJUSTMENTS

CONTENTS	PAGE
1. GENERAL	1
2. RECEIVING-ONLY REPERFORATOR BASE	2
Gear mesh	3
Motor adjusting stud	3
Tape container	2
Tape-out lever	4
Tape-out lever spring	4
Tight-tape arm	3
Timing belt	2
Switch mechanism mounting plate ..	5
Switch levers	5
Switch lever springs	4
Wire tape guide	3
3. AUXILIARY REPERFORATOR BASE	6
Gear bracket	6
Low tape switches	7
Motor mounting	6
Reperforator timing belt	6
4. MULTIPLE REPERFORATOR BASE	8
Tape-out lever spring	9
Tape-out switch assembly	9
Timing belt	8

1. GENERAL

1.01 This section provides adjustment information for the 35 receiving-only reperforator base, the 35 multiple reperforator base, and the 35 auxiliary reperforator base.

1.02 The adjustments in this section are arranged in a sequence that should be followed if a complete readjustment is undertaken. A complete adjusting procedure should be read before attempting to make the adjustment. After an adjustment is completed, be sure to tighten any nuts or screws that may have been loosened, unless otherwise instructed.


1.03 The adjusting illustrations indicate tolerances, positions of moving parts, spring tensions and the angle at which scales should be applied. The tools required to make adjustments and check spring tensions are not supplied with the equipment, but are listed in another section. Springs which do not meet the requirements, and for which there are no adjusting procedures, should be discarded and replaced by new springs.

1.04 Where adjustment instructions call for removal of components, assemblies, subassemblies or parts, all adjustments which the removal of the parts might facilitate should be made before the parts are replaced or as the equipment is reassembled. When a part mounted on shims is removed, the number of shims and their location should be noted so that the identical pile-up can be made when the part is replaced.

1.05 References made to left or right, up or down, front or rear apply to the unit in its normal operating position as viewed from the operator's position in front of the unit.

2. RECEIVING-ONLY REPERFORATOR BASE

2.01 Tape Container and Timing Belt



Requirement
Possible to insert full roll of tape into tape container through access door in dome.

To Adjust
Position tape container with two mounting screws loosened.

2.02 Intermediate Gears and Tight Tape Arm


GEAR MESH

Requirement

Motor drive gear and intermediate shaft driven gear should mesh at right angles.

To Adjust

Position drive assembly with mounting screws loosened. Recheck TIMING BELT adjustment (2.01).



WIRE TAPE GUIDE

Requirement

Tape should pass freely through wire guide and be aligned with perforator guide assembly.

To Adjust

Bend or position wire guide.

MOTOR ADJUSTING STUD

Requirement

Barely perceptible backlash between motor drive gear and intermediate shaft driven gear with gears at closest point.

To Adjust

Position stud in right motor mounting post up or down to meet requirement. Tighten nut while holding stud in position. Check that motor mounting screws are tight. Recheck GEAR MESH.


TIGHT-TAPE ARM

Requirement

With latchlever against its forward (clockwise) stop, tight-tape arm should clear table
Min 1/2 inch---Max 3/4 inch

To Adjust

With adjusting screw on trip lever loosened and trip lever holding latchlever against clockwise stop, position tight tape arm.



2.03 Low Tape Mechanism

TAPE-OUT LEVER

Requirement

Tape-out lever should be able to push both switch levers away from switch actuators but should not be able to lift wood filler with depleted tape roll out of slots in tape container.


To Adjust

If requirement is not met, check TAPE-OUT LEVER and SWITCH LEVER SPRING tensions (below).

TAPE-OUT LEVER SPRING

Requirement

Min 6 oz---Max 8 oz
To pull spring to length of 1-17/32 inches.



SWITCH LEVER SPRINGS (2)


Requirement

Min 1-3/4 oz---Max 2-1/4 oz
To pull spring to length of 1-5/16 inches.

2.04 Low Tape Mechanism - Continued

Note: The inner switch is nearest the mounting plate; the outer switch is farthest from the mounting plate.

(RIGHT SIDE VIEW)



(A) SWITCH LEVER

- (1) Requirement
Outer switch should operate before inner switch.
- (2) Requirement
Both switches should operate within limits of motion of tape-out lever and when diameter of tape roll is reduced to first, 2-7/16 inches, then to 2-5/16 inches (when using a 2-inch diameter core).


To Adjust
Bend outer switch lever toward switch assembly.

Note: Adjustment can be facilitated by removing switch mechanism from tape container.

(B) SWITCH MECHANISM MOUNTING PLATE

- Requirement
Outer switch should just operate when diameter of tape roll is reduced to 2-3/8 inches when using a 2-inch diameter core.


To Adjust
Position mounting plate with mounting screws loosened.



(LEFT SIDE VIEW)

3. AUXILIARY REPERFORATOR BASE


3.01 Gear Bracket Assembly and Motor Mounting



Requirement
 Motor mounting bracket should be spaced
 Min 0.030 inch---Max 0.060 inch
 from base plate.

To Adjust
 Tighten or loosen motor mounting screws to meet requirement.


3.02 Low Tape Mechanism



LOW TAPE SWITCHES

- (1) Requirement
Outer switch must operate first.
- (2) Requirement
Inner switch should just close when tape is depleted to a diameter of between 2-5/16 inches and 2-7/16 inches.


To Adjust
Bend switch actuator to meet requirement (1). Position mounting plate with mounting screws loosened to meet requirement (2).



4. MULTIPLE REPERFORATOR BASE

4.01 Timing Belt

Note: This adjustment should be made for each typing reperforator unit.



(RIGHT SIDE VIEW)

TIMING BELT

Requirement


Slight pressure at center of span (8 ± 1 oz) should deflect belt

Min $3/32$ inch---Max $5/32$ inch

CAUTION: BELT SHOULD NOT BE TIGHT.

To Adjust

With two anchor bracket screws and three mounting screws loosened, position typing reperforator unit. Tighten three mounting screws. Press anchor bracket against base plate and tighten screw holding bracket to reperforator. Tighten screw holding bracket to base.




(TOP VIEW)

TYPING REPERFORATOR UNIT

ANCHOR BRACKET SCREWS

4.02 Low Tape Mechanism



TAPE-OUT LEVER SPRING

Requirement
 Tape-out lever capable of pushing switch lever away from switch actuator but incapable of lifting wooden tape core with depleted cardboard tape roll out of slots in tape container.

TAPE-OUT SWITCH ASSEMBLY

Requirement
 Switch should operate when diameter of tape roll is
 Min 2-3/8 inch---Max 2-5/8 inch.
 (Check with test lamp.)

To Adjust
 With two mounting screws loosened, position switch assembly on tape container.

35 TYPING REPERFORATOR (LPR)

ADJUSTMENTS

CONTENTS	PAGE	CONTENTS	PAGE
1. GENERAL	3	Tape shoe torsion spring	34
2. BASIC UNIT	4	Ten characters per inch (final)	29
Function Mechanism		Ten characters per inch (preliminary)	29
Cam follower arm spring (early design)	18	Toggle bail eccentric (preliminary) . .	24
Cam follower arm spring (latest design)	19	Toggle operating arm	24
Cam follower roller	21	Ribbon Shift and Print Suppression Mechanism (Early Design)	
Cam follower roller alignment	21	Armature air gap	56
Clutch shoe lever	5	Armature downstop	56
Clutch shoe lever spring	6	Armature spring	56
Function clutch drum endplay	5	Armature upstop	56
Function clutch latchlever spring . . .	20	Ribbon shift and print suppression contacts	40
Function clutch release lever spring .	22	Ribbon shift and print suppression contact position	41
Function clutch trip lever	19	Ribbon Shift and Print Suppression Mechanism (Latest Design)	
Release downstop bracket	22	Armature air gap and downstop	57
Reset arm	20	Armature spring	57
Reset bail trip lever spring (early design)	18	Armature upstop	57
Reset bail trip lever spring (latest design)	18	Blocking link	57
Trip cam follower lever (preliminary)	18	Ribbon carrier	55
Punch Mechanism		Ribbon carrier spring	55
Bias spring (punch block)	32	Ribbon shift and print suppression contacts	42
Bias spring (tape chute)	32	Ribbon shift and print suppression contact position	43
Detent lever spring	33	Selector Mechanism	
Feed pawl	28	Clutch shoe lever	5
Feed pawl spring	33	Clutch shoe lever spring	6
Latchlever clearance	28	Clutch shoe spring	6
Lateral and front to rear feed wheel position detent (early design)	30	Marking locklever spring	9
Lateral and front to rear feed wheel position detent (latest design)	31	Oil shield	17
Perforator drive link spring	24	Pushlever reset bail spring	13
Punch mounting plate (final)	26	Range finder knob phasing	15
Punch mounting plate (preliminary) . .	23	Selector armature	7
Punch pin penetration	25	Selector armature downstop (final) . . .	10
Punch slide downstop position	25	Selector armature downstop (preliminary)	7
Punch slide guide (final)	25	Selector armature spring (final)	11
Punch slide latch spring	34	Selector armature spring (preliminary)	11, 12
Punch slide spring	32	Selector cam lubricator	17
Reset bail trip lever (final)	27		
Tape guide assembly spring	32		

CONTENTS	PAGE
Selector clutch drum endplay	14
Selector clutch latchlever spring.	13
Selector clutch stop arm	15
Selector lever spring	14
Selector magnet bracket	8, 9
Selector pushlever spring	14
Selector receiving margin	16
Spacing locklever spring	13
Start lever spring.	16
 Tape Depressor Mechanism	
Clamp plate screw with disc (latest design)	64
Clamp plate spring (early design)	63
Clamp plate spring (latest design)	64
Tape platform (early design)	63
Tape platform (latest design)	64
 Typing Mechanism	
Axial corrector (yielding)	49
Axial output rack guide roller.	51
Axial sector alignment	50
Bellcrank springs - 1 to 5	35
Bellcrank springs - 6 and 7	36
Bellcrank spring - 8	35
Cam follower roller arm position	44
Centering clearance	37
Correcting drive link (nonyielding).	52
Correcting drive link (yielding) extension spring.	49
Correcting drive link spring (nonyielding)	47
Detent spring.	63
Drive arm.	62
Drive arm spring.	63
Eccentric shaft detent lever spring.	50
Feed pawl spring	62
Function blade spring	47
Function box	38
Lifter operating range.	44
Lifter spring.	47
Lifter toggle link spring	47
No. 5 pulse lever spring	37
No. 7 pulse lever spring	37
Oscillating bail drive link	48
Oscillating bail pivot.	48
Print hammer	61
Print hammer accelerator latch spring	59
Print hammer accelerator spring	59
Print hammer return spring.	59
Print hammer trip lever spring	59
Printing latch	58
Pushbar guide bracket.	51
Pushbar location	39
Pushbar operating blade (preliminary).	35
Ratchet wheel torque spring.	62

CONTENTS	PAGE
Reperforator mounting	29
Rotary corrector arm.	54
Rotary corrector mesh	53
Shoulder clearance.	36
Toggle link	45
Toggle trip arm.	46
Type wheel (final).	60
Type wheel (preliminary).	60
Type wheel rack clearance.	52

3. VARIABLE FEATURES

End of Feed-Out for Noninterfering RUBOUT Tape Feed-Out Mechanism	
Contact assembly.	77
Contact assembly mounting bracket	78
Contact spring gap (preliminary).	77
Contact swinger (preliminary)	77
Latchlever spring.	77
Tape length adjusting plate.	78
 Manual and Power Drive Backspace Mechanism	
Armature hinge (early design)	80
Backspace pawl clearance	79
Backspace ratchet	79
Feed pawl eccentric (preliminary).	80
 Power Drive Backspace Mechanism	
Armature bail spring (early design)	84
Armature latch spring (early design)	84
Armature spring (latest design)	83
Armature upstop (early design).	81
Bellcrank spring	84
Drive link (early design)	81
Feed pawl spring	84
Final manual or power adjustment (latest design)	83
Latch (early design)	82
Latch extension (early design)	81
Latch extension spring (latest design).	83
Magnet position (latest design)	83
Nonrepeat arm (early design).	82
 Print Suppression Mechanisms	
Accelerator blocking link (latest design)	85
Accelerator blocking link (early design)	86
Control lever (manual)	87
 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism	
Adjusting lever	73
Armature backstop.	66
Armature hinge	65

CONTENTS	PAGE
Blocking bail spring	66
Blocking latch torsion spring	66
Drive arm spring	72
Drive bail spring	65
Feed pawl and front check pawl springs.	68
Front ratchet stop position.	69
Latchlever	67
Latchlever spring.	67
Magnet assembly	65
Mounting plate	65
Nonrepeat lever spring	66
Punch slide latch	72
Ratchet return spring	70
Rear check pawl.	68
Rear check pawl spring.	68
Release arm	71
Release arm spring	71
Release lever	66
Release lever spring.	67
Reset bail latch	76
Reset bail latch spring	76
Reset bail trip lever	74
Reset bail trip lever spring	76
Tape length adjusting plate.	75
Time delay lever	70
Time delay lever spring	70
Trip cam follower	73
Signal Bell and EOT Contacts	
Normally closed contact gap.	88
Normally open contact gap.	88




Figure 1 - Typical 35 Typing Reperforator
(Front View)

1. GENERAL

1.01 This section provides adjustments and requirements for the 35 typing reperforator (Figure 1). The section has been revised to include recent engineering changes and additions and to rearrange the text. Since this is a general revision, marginal arrows ordinarily used to indicate changes and additions are omitted.

1.02 The basic equipment includes selector mechanism, transfer mechanism, eight-level fully perforating punch mechanism, and printing mechanism. The printing mechanism includes letters-figures contacts and magnet and may include print suppression, remote control noninterfering rubout tape feed-out, end of feed-out timing contacts, and power drive back-space mechanisms.

1.03 Reference to left or right, front or rear, and up or down refer to the apparatus in its normal operating position, as viewed from the front with the selector mechanism to the right and the punch mechanism to the left. It is assumed that the elements depicted in illustrations in this section are being viewed from a position in front of the equipment, unless the illustrations are specifically labeled otherwise. In the illustrations, pivot points are shown by circles or ellipses that are solid black to indicate fixed points and cross-hatched to indicate floating points.

1.04 Tools required to make the adjustments and test the spring tensions are listed in Section 570-005-800TC. Spring tensions given in this section are indications, not exact values, and should be checked with the correct scale applied in the positions shown in the drawings.

1.05 The unit is in its unoperated, or stop, condition when it is not under power. It is in its idling condition when it is under power and clutches are disengaged (steady-marking condition of signal line). The unit is in the letters condition when the type wheel rack is in its upper position (the numerals appear on the top half of the type wheel). The unit is in the figures condition when the type wheel rack is in its lower position (the letters appear on the top half of the type wheel).

CAUTION: APPARATUS SHOULD NOT BE SEPARATED FROM ITS PROTECTIVE HOUSING UNLESS POWER IS DISCONNECTED. WHERE OPERATION OF THE EQUIPMENT IS REQUIRED AFTER IT

HAS BEEN SEPARATED FROM ITS PROTECTIVE HOUSING, APPROPRIATE PRECAUTIONARY MEASURES SHOULD BE TAKEN TO PREVENT ACCIDENTS.

1.06 When a requirement calls for a clutch to be DISENGAGED, the clutch shoe lever must be fully latched between its trip lever (or stop arm) and latchlever. The mainshaft will then turn freely without the clutch shoes dragging. When the clutch is ENGAGED, the shoe lever and cam disc stop-lug are moved apart, and the clutch shoes are wedged against the drum so that the clutch turns with the shaft.

Note: If the shaft is turned by hand, the clutch will not fully disengage upon reaching its stop position. Where a procedure calls for disengagement, rotate the clutch to its stop position, apply a screwdriver to the cam disc stop-lug and turn the disc in the normal direction of shaft rotation until the latchlever seats in its notch in the disc.

1.07 To manually operate the 35 typing reperforator, proceed as follows:

(a) Attach the armature clip to the selector magnet armature by carefully putting the flat formed end of the armature clip over the top of the armature between the pole pieces and then hooking the projection under the edge of the armature. The spring tension of the armature clip will hold the selector armature in the marking (attracted) position.

(b) While holding the selector magnet attracted by means of the armature clip, manually rotate the mainshaft in a counterclockwise direction until all the clutches are brought to their disengaged position.

(c) Fully disengage the clutches in accordance with 1.06, Note.

(d) Release the selector magnet armature momentarily to permit the selector clutch to engage.

(e) Rotate the mainshaft slowly until all the pushlevers have fallen to the left of their selecting levers.

(f) Strip the pushlevers from their selector levers if they are spacing in the code combination of the character or function that is being selected. Allow the pushlevers to move to the right. The pushlevers and selector levers move in succession, starting with the inner lever no. 1 to the outer lever no. 8.

(g) Continue to rotate the mainshaft until all operations initiated by the selector action clear through the unit.

1.08 Parts dismantled to facilitate checking or readjustment should be reassembled after the operation is completed. If a part mounted on shims is to be dismantled, the number of shims used at each mounting screw should be noted so that the same shim pileups can be replaced when the part is remounted. When parts removed are replaced, related adjustments which may have been affected should be checked.

1.09 Parts that are worn to the extent that they can no longer be made to meet the specified requirements by authorized adjustments, or which are worn to the extent that it seems probable that early further wear might cause a loss of adjustment, should be replaced by new parts. Springs which do not meet the requirements and for which there are no adjusting procedures should be discarded and replaced by new springs.

1.10 All contact points should meet squarely. Smaller points should fall wholly within the circumference of larger mating points. Points that are the same size should not be out of alignment more than 25 percent of the point diameter. Avoid sharp kinks or bends in the contact springs.

Note: Keep all electrical contacts free of oil and grease.

1.11 Where a 35 typing reperforator is used as a component of a receive only or a send-receive set, it is mounted on a base or keyboard base. Refer to the base, keyboard and other applicable sections for gear mesh and additional adjustment requirements.

2. BASIC UNIT

2.01 The following figures show the adjusting tolerances, position of parts, and spring tensions. The illustrations are arranged so that the adjustments are in the sequence that would be followed if a complete readjustment of the apparatus were being made. In some cases, where an illustration shows interrelated parts, the sequence that should be followed in checking the requirements and making the adjustments is indicated by the letters (A), (B), (C), etc.

2.02 Selector Mechanism

2.03 Function Mechanism

Note: For gear mesh adjustment, refer to applicable sections covering base or keyboard mounting facility.

(A) CLUTCH SHOE LEVER

Note: This adjustment should be made for both selecting and function clutches.

- (1) To Check
Disengage clutch. Measure clearance.
- (2) To Check
Align head of clutch drum mounting screw with stop-lug.
Engage clutch. Manually press shoe lever and stop-lug
together and allow to snap apart. Measure clearance.

Requirement

Clearance between shoe lever and stop-lug

Min 0.055 inch--Max 0.085 inch


greater when clutch engaged (2) than when disengaged (1).

To Adjust

Engage wrench or screwdriver with lug on adjusting disc.
Rotate disc with clamp screws loosened. Tighten screws.

Note: After making adjustment, disengage clutch.

Remove drum mounting screw. Rotate drum in
normal direction and check to see if it drags on shoe.
If it does, refine adjustment.



(B) FUNCTION CLUTCH DRUM ENDPLAY

Requirement

With function clutch disengaged
Min some---Max 0.015 inch
when play is taken up to make
clearance maximum.



To Adjust

With its mounting screw loosened,
move drum to extreme front posi-
tion. Tighten drum mounting
screw. Position collar with
mounting screw loosened.
Tighten screw.

2.04 Selector Mechanism (continued)


2.05 Function Mechanism (continued)

Note: These spring tensions apply to both clutches.



2.06 Selector Mechanism (continued)

Note: To facilitate making the following adjustments, remove the range finder assembly and selector magnet assembly. To insure better operation, pull a piece of bond paper between the armature and the pole pieces to remove any oil or foreign matter that may be present. Make certain that no lint or pieces of paper remain between the pole pieces and the armature.


**SELECTOR ARMATURE**

Note: These requirements need not be made nor checked if the selector magnet bracket and receiving margin requirements are met.

- (1) Requirement
Clearance
Min 0.010 inch
between armature hinge clamp strip and the pivot edge of the magnet bracket casting at their closest point.
- (2) Requirement
Outer edge of armature should be flush within 0.015 inch with outer edge of both pole pieces.
- (3) Requirement
Start lever should drop freely into armature extension slot.

To Adjust

Position armature spring adjusting nut to hold armature firmly against pivot edge of casting. Position armature with mounting screws loosened. Tighten screws.

**SELECTOR ARMATURE DOWNSTOP (Preliminary)****Requirement**

Remove oil shield. With magnet de-energized, locklevers on high part of their cam, and armature resting against its downstop, clearance between end of armature and left edge of left pole piece


Min 0.030 inch---Max 0.035 inch

To Adjust

Position downstop bracket with mounting screw loosened. Replace oil shield and check OIL SHIELD (2.16) adjustment. Tighten screw.

2.07 Selector Mechanism (continued)

Note: The appropriate preliminary SELECTOR ARMATURE SPRING (2.10) requirement must be made prior to this adjustment.

SELECTOR MAGNET BRACKET

(1) Requirement

Spacing locklever on high part of cam.
Armature in contact with pole piece.
Clearance between end of armature extension and shoulder on spacing locklever

Min 0.020 inch---Max 0.035 inch

(2) Requirement

Spacing locklever on high part of cam.
Armature in contact with pole piece.
Min some---Max 0.003 inch
clearance between upper surface of the upper step of the spacing locklever when locklever is held downward.

To Adjust

Position upper end of magnet bracket.
Tighten two magnet bracket mounting screws.
Recheck requirement (1).

To Adjust

Loosen two magnet bracket mounting screws and adjusting link clamp screw.
Position magnet bracket by means of adjusting link and tighten link clamp screw only.

Note: See following page for requirement (3).

2.08 Selector Mechanism (continued)

Note: See preceding page for SELECTOR MAGNET BRACKET adjustment, requirements (1) and (2).

SELECTOR MAGNET BRACKET (continued)


(3) Requirement

Marking locklever on low part of cam. Magnet energized. Armature in contact with left pole piece. Some clearance between lower surface of armature extension and upper surface of marking locklever.

To Adjust


Position upper end of magnet bracket with mounting screws loosened. Tighten mounting screws and recheck requirements (1) and (2).

ARMATURE EXTENSION



ARMATURE

MARKING LOCKLEVER



MARKING LOCKLEVER SPRING

Requirement

Rubout combination (12345678) selected. Mainshaft rotated until selector clutch is disengaged. Push scale applied to lower extension of locklever
 — Min 2 oz ---Max 4 oz
 to start lever moving.

MARKING LOCKLEVER
 SPRING

MARKING LOCKLEVER

2.09 Selector Mechanism (continued)

SELECTOR ARMATURE DOWNSTOP (Final)

Requirement


With the selector magnet de-energized and the spacing locklever on the low part of its cam, there should be

— Min 0.005 inch--- Max 0.015 inch

clearance between the top of the armature extension and the bottom of the lower step of the spacing locklever.

To Adjust

Refine the SELECTOR ARMATURE DOWNSTOP (Preliminary) (2.06) adjustment.




2.10 Selector Mechanism (continued)

SELECTOR ARMATURE SPRING (Preliminary)

(For Units Employing Selector Armature With Two Antifreeze Buttons Only)

Requirement

With locking levers and start lever on high part of their cams, scale applied as nearly vertical as possible under end of armature extension, it should require approximately the following tensions to move the rear antifreeze button against the magnet core.




Note: See SELECTOR RECEIVING MARGIN (2.15) adjustment

SELECTOR ARMATURE SPRING (Final)

(1) Requirement

When a distortion test set is available, the selector armature spring tension should be refined (15 grams min), if necessary, to obtain satisfactory receiving margins. The front antifreeze button must contact the magnet core when the magnet coils are energized.



(2) Requirement

See SELECTOR RECEIVING MARGIN (2.15) adjustment.

2.11 Selector Mechanism (continued)

SELECTOR ARMATURE SPRING (Preliminary) (continued)

(For Units Employing Selector Armature With Single Antifreeze Button Only)

(1) Requirement


With locking levers and start lever on high part of their cams, scale applied as nearly vertical as possible under end of armature extension, it should require the following tensions to move armature to marking position:

- 0.060 Ampere - Min 2-1/2 oz---Max 3 oz
- 0.500 Ampere - Min 4-1/2 oz---Max 5-1/2 oz

Note: This spring can be adjusted for maximum selector performance only when printer is connected to the specific circuit over which it is to operate under service conditions. Since there are several operating speeds and since circuits vary widely, it is impossible to adjust spring for maximum performance at the factory. The foregoing spring tension requirement is given to permit operation prior to measurement of receiving margins. Readjustment made to obtain satisfactory receiving margin should not be disturbed in order to meet requirements of this adjustment.

To Adjust


Position adjusting nut.



(2) Requirement

See SELECTOR RECEIVING MARGIN (2.15) for final adjustment


2.12 Selector Mechanism (continued)



(A) PUSHLEVER RESET BAIL SPRING

Requirement

Pushlever reset bail on low part of cam, 32 oz scale applied to reset bail.
 — Min 4 oz---Max 8 oz
 to move bail from cam.



(B) SELECTOR CLUTCH LATCHLEVER SPRING

Requirement


Latch resting on low part of its cam disc.
 — Min 2 oz---Max 3-1/2 oz
 to start latch moving.

(C) SPACING LOCKLEVER SPRING

Requirement

Selector armature released. Spacing locklever on low part of its cam. Spring scale applied to lower end of spacing locklever.
 — Min 3 oz---Max 6 oz
 to move spacing locklever from its pivot shaft.

2.13 Selector Mechanism (continued)



To Adjust
 Position clutch drum on mainshaft with
 mounting screw loosened.

2.14 Selector Mechanism (continued)


(A) RANGE FINDER KNOB PHASING

Requirement

With range finder knob turned to either end of rack, zero mark on scale should be in line with scribed line on range finder plate ± 3 points.

To Adjust

Remove mounting nut, disengage knob from rack and position knob. Re-engage knob with rack and replace mounting nut.



Note: Replace range finder and selector magnet assembly before checking these adjustments.

(B) SELECTOR CLUTCH STOP ARM


Requirement

Range scale set at 60. Selector clutch disengaged. Armature in marking position. Clutch stop arm should engage clutch shoe lever by approximately full thickness of stop arm.

To Adjust

Position stop arm on stop arm bail with clamp screw loosened. Tighten screw.

2.15 Selector Mechanism (continued)



SELECTOR RECEIVING MARGIN

- (1) Requirement (For Units Employing Armature With One Antifreeze Button)
 When a signal distortion test set is available for determining the receiving margins of the selector, and where the condition of the components is equivalent to that of new equipment, the range and distortion tolerances below should be met.
- (2) Requirement (For Units Employing Armature With Two Antifreeze Buttons)
 When a distortion test set is available, the selector armature spring tension should be refined, if necessary, to obtain satisfactory receiving margins. The front antifreeze button must contact the magnet core when the magnet coils are energized.

To Adjust

Refine the SELECTOR ARMATURE SPRING (2.10) adjustment.

SELECTOR RECEIVING MARGIN MINIMUM REQUIREMENTS


Current	Speed in WPM	Points Range with Zero Distortion	Percentage of Marking and Spacing Bias	End Distortion Tolerated with Scale at Bias Optimum Setting
0.500 Amp (Windings Series)	100	72	38	35

2.16 Selector Mechanism (continued)

OIL SHIELD (If Applicable)


(1) Requirement

Magnet de-energized. Stop arm bail on low part of its cam. Clearance between start lever and oil shield
Min 0.020 inch




(2) Requirement

Magnet energized. Stop arm bail on high part of its cam. Clearance between end of armature and oil shield.
Min 0.010 inch



To Adjust

Position shield with mounting screw loosened. Make sure oil shield mounting stud is secure before making adjustment. Check to be sure there is clearance between the oil shield and armature extension when the armature is energized. Tighten screw.



SELECTOR CAM LUBRICATOR

Requirement

High part of selector lever cams should contact leather wick but should not deflect wick more than 1/32 inch gauged visually.

To Adjust

Position lubricator assembly around lower screw with mounting screws loosened. Tighten screws.

2.17 Function Mechanism (continued)

Note 1: For units equipped with automatic noninterfering rubout tape feed-out mechanism, substitute adjustment in variable features, Part 3.

(A) TRIP CAM FOLLOWER LEVER (Preliminary)

(1) Requirement

With follower lever on high part of cam clearance between release and main trip lever
Min 0.010 inch---Max 0.030 inch

(2) Requirement

Some clearance between main trip lever and downstop bracket.

To Adjust


By means of pry point, position adjusting arm on follower lever with locknut loosened. Tighten nut.

(C) RESET BAIL TRIP LEVER SPRING (Latest Design)

Requirement

Trip reset bail trip lever extension. Pulling at top of lever
Min 1 oz---Max 4 oz
to start lever moving.

Note 2: It may be necessary to remove ribbon feed mechanism when checking this tension.



(B) CAM FOLLOWER ARM SPRING (Early Design)

Requirement


With follower lever on high part of trip cam and main trip lever held away from adjusting arm
Min 2-1/2 oz---Max 4 oz
to start adjusting lever moving.

RESET BAIL TRIP LEVER SPRING (Early Design)

Requirement


With follower lever on high part of trip cam
Min 2-1/2 oz---Max 4-1/2 oz
to start trip lever moving.

2.18 Function Mechanism (continued)



CAM FOLLOWER ARM SPRING (Latest Design)

Requirement
 With cam follower arm on low part of trip cam and reset bail trip lever held away from adjusting arm
 — Min 1 oz---Max 4 oz
 to start adjusting arm moving.



FUNCTION CLUTCH TRIP LEVER

(1) Requirement
 With release resting on main trip lever (see 2.19), function clutch trip lever should engage full thickness of shoe lever.

(2) Requirement
 Min some---Max 0.006 inch
 endplay in trip lever.

To Adjust
 Position trip lever on its shaft with clamp screw loosened. Tighten screw.

2.19 Function Mechanism (continued)

(A) RESET ARM

To Check

Trip function clutch and position mainshaft so that reset arm is held in its highest position by cam pin.

(1) Requirement


Clearance between release and main trip lever
Min 0.010 inch---Max 0.030 inch

(2) Requirement

Latchlever endplay
Min some---Max 0.010 inch

To Adjust

Position reset arm with clamp screw loosened. Tighten screw.




(B) FUNCTION CLUTCH LATCHLEVER SPRING

Requirement

With function clutch turned to stop positions and latchlever unlatched

Min 12 oz---Max 15 oz to start latchlever moving.



2.20 Function Mechanism (continued)

(A) CAM FOLLOWER ROLLER


Requirement

With rocker bail positioned to its extreme left and upper roller in contact with function cam

Min some---Max 0.004 inch clearance between cam and lower roller at point of least clearance.

To Adjust

Position lower roller mounting screw in elongated slot with locknut loosened. Tighten nut.



(Rear View)

(B) CAM FOLLOWER ROLLER ALIGNMENT

(1) **Requirement**


Rocker bail rollers should engage full thickness of function cam.

(2) **Requirement**

Lifter roller in full engagement with rocker bail camming surface.

To Adjust

Position rocker bail and guide bracket with guide bracket mounting screws loosened. Tighten screws.



(Right Side View)


2.21 Function Mechanism (continued)

(A) FUNCTION CLUTCH RELEASE LEVER SPRING

Requirement

Trip function clutch. Rotate mainshaft until release is reset on reset ball trip lever.

Min 5 oz---Max 8 oz to start release moving.



(B) RELEASE DOWNSTOP BRACKET

Requirement

With function clutch tripped, rotate shaft until clearance between function clutch disc stop-lug and clutch stop lever is at a minimum. Release lever resting against downstop bracket. Clearance between function clutch disc stop-lug and stop lever

Min 0.002 inch---Max 0.045 inch

To Adjust

Remove tape guide. With downstop bracket mounting screws friction tight position bracket. Tighten screws.

2.22 Punch Mechanism

PUNCH MOUNTING PLATE (Preliminary)


Requirement

The punch mechanism mounting screw, beneath punch block, and mounting screw at lower edge of punch mechanism backplate should be located centrally within their respective mounting holes.

Note: The mounting holes are oversize to facilitate use of punch mechanism on the typing reperforator.

To Adjust

Remove mounting screw at the lower edge of punch mechanism backplate. With the two remaining backplate mounting screws and mounting bracket screw friction tight, position punch mechanism so that the tapped hole of the frame is centrally located (as gauged by eye) within large body hole of punch mechanism backplate. Tighten the two backplate mounting screws and recheck to see that requirement is met. Replace and tighten the lower backplate mounting screw. Tighten the bracket mounting screw.



2.23 Punch Mechanism (continued)

Note: Before proceeding with the punch mechanism adjustments, check the CAM FOLLOWER ROLLER (2.20) adjustment and loosen the punch slide downstop mounting nut and guide mounting stud.


(A) TOGGLE BAIL ECCENTRIC (Preliminary)

Requirement

The indent (high side of eccentric) should be in its uppermost position.

To Adjust

With the toggle eccentric shaft locknut friction tight position eccentric. Tighten nut.



(B) TOGGLE OPERATING ARM

(1) Requirement

Trip function clutch and rotate mainshaft until the upper rocker bail roller is on high part of its cam. Min 0.002 inch---Max 0.005 inch clearance between feed pawl stud and the TP159926 gauge.

(2) Requirement


Clearance between arm and oscillating shaft bearing hub. Min 0.002 inch---Max 0.015 inch with play taken up in direction to make clearance minimum.

To Adjust

With clamp screw friction tight, position toggle bail and operating arm. Tighten screw.

Note: After FEED PAWL (2.27) adjustment has been made and PUNCH PIN PENETRATION (2.24) and FEED PAWL requirements are met, this requirement should be considered fulfilled.

(C) PERFORATOR DRIVE LINK SPRING



Requirement

Min. 3-1/2 oz---Max. 8 oz. to pull springs to installed length

2.24 Punch Mechanism (continued)

(A) PUNCH PIN PENETRATION

(1) Requirement

With the RUBOUT combination selected, function clutch engaged, rotate mainshaft until all punch pins are into or above the tape aperture in punch block. With the TP159926 gauge in position

— Min 0.050 inch
clearance between feed pawl stud and the gauge.


(2) Requirement

With RUBOUT combination selected, function clutch engaged, rotate mainshaft until all punch pins have cleared the punch block. With the TP159926 gauge in position

Min some---Max 0.080 inch
clearance between feed pawl stud and gauge.

To Adjust

Refine the TOGGLE BAIL ECCENTRIC (2.23) adjustment keeping the indent to the right of a vertical centerline through the shaft. Tighten nut.



(C) PUNCH SLIDE DOWNSTOP POSITION

Requirement


With function clutch disengaged and latched, play taken up toward the top, clearance between both the front and rear punch slides and the downstop plate

— Min some---Max 0.008 inch
All other punch slides should have some clearance.

Note: To check for some clearance, place unit in stop position, trip function trip mechanism and latches. The punch slides should move fully to their operated position.

To Adjust

With unit in stop position, loosen the two downstop plate mounting locknuts and locate the downstop plate to meet the requirement.



(B) PUNCH SLIDE GUIDE (Final)

Requirement

The punch slides should align with their corresponding punch pins and be free of binds after tightening the guide mounting studs. Each punch slide should return freely after being pushed in not more than 1/16 inch.

To Adjust

Position the guide with its mounting studs friction tight. Tighten studs.

2.25 Punch Mechanism (continued)

PUNCH MOUNTING PLATE (Final)

(1) To Check

Select RUBOUT code combination (12345678). Rotate until function clutch trips with punch levers in extreme left-hand position.

Requirement

Clearance between punch slide and punch slide latch
 Min 0.015 inch---Max 0.045 inch
 at slide where clearance is least.

To Adjust

Loosen perforator mounting screws, adjusting clamp lock screw, adjusting clamp pivot screw, and anchor bracket screw until friction tight. Place tip of screwdriver between screw and rim of pry hole and pry perforator up or down. Tighten only adjusting clamp lock screw.

(2) To Check


Remove ribbon and tape. With unit in stop position and upper no. 7 pushbar to the right, check clearance between rear leg of stripper plate and type wheel. Select the R code combination (-2-5-78), trip the function clutch, and move rocker bail to its extreme left position. Check clearance between front leg of the stripper plate and type wheel.

Requirement

Clearance between the character P and the front or rear leg of stripper plate (whichever has the least clearance) should be
 Min 0.075 inch---Max 0.085 inch

To Adjust

Position perforator with two mounting screws, adjusting clamp pivot screw, and anchor bracket screw friction tight. Tighten screws. Check RESET BAIL TRIP LEVER (2.26) requirement for some clearance and adjust if necessary.



2.26 Punch Mechanism (continued)

RESET BAIL TRIP LEVER (Final)

(1) Requirement

Manually select the NULL code combination. Manually rotate reset bail trip lever. The punch slide reset bail should trip before the function clutch is tripped.

To Adjust


With trip lever extension lockscrew friction tight and RUBOUT combination selected, position reset bail against punch slides. Take up play between reset bail and trip lever in a counterclockwise direction. Position trip lever by means of its pry point. Tighten screw.

(2) Requirement

With function and selector clutches disengaged and latched, the punch slide reset bail should fully engage the punch slide latching surface when play in parts is taken up in direction to make the engagement the least.

To Adjust

Recheck requirement (1) above and refine adjustment if necessary.



(Front View)

2.27 Punch Mechanism (continued)

(A) LATCHLEVER CLEARANCE



Requirement

With NULL combination selected, the function clutch disengaged and latched, clearance between the punch slide and its associated latchlever should be

Min 0.008 inch---Max 0.020 inch _____
for the slide having the least clearance.

To Adjust

Rotate the reset bail eccentric shaft with its locknut loosened. Keep the indentation in the eccentric above center of shaft. Tighten locknut.



(B) FEED PAWL

Requirement


Function clutch disengaged, indentation in detent lever eccentric at right angle to lever, detent roller in contact with ratchet wheel, high part of feed pawl eccentric to the right of its lockscrew. The feed pawl should engage the first tooth below a horizontal centerline through the ratchet wheel with no perceptible clearance.

To Adjust

Rotate the feed pawl eccentric with lockscrew loosened. Tighten screw.

Note: This adjustment is related to TEN CHARACTERS PER INCH (2.28), and two adjustments should be made at same time.


2.28 Punch Mechanism (continued)



Note: Before proceeding with the following adjustment check both BIAS SPRING (2.31) tensions, and if unit is equipped with a slack tape mechanism having a clamp plate with an adjustable wear disc, loosen the mounting nut and turn a new edge of the disc toward the tape. Tighten nut.

REPERFORATOR MOUNTING**Requirement**

Mount the reperforator to the base and adjust in accordance with the associated base section.

TEN CHARACTERS PER INCH (Final)**(1) Requirement**

With a piece of tape perforated with six series of 9 NULL code combinations followed by a rubout combination placed over the smooth side of the TP156011 tape gauge so that the circular portion of the first number 2 code hole in the tape is concentric with the first hole of the tape gauge, the next four holes in the tape gauge should be visible through the number 2 code holes in the tape and the circular portion of the last (sixth) number 2 code hole in the tape should be entirely within the 0.086 diameter hole of the tape gauge.

(2) Requirement

With tape shoe held away from feed wheel, feed pawl and detent disengaged and tape removed, feed wheel should rotate freely.

To Adjust

With tape removed from punch mechanism, loosen eccentric locknut and rotate die wheel eccentric shaft until it binds against feed wheel. Back off eccentric until die wheel is just free. Check through 3 or 4 rotations. Keep the indent of eccentric below the horizontal centerline of the stud. Refine adjustment for requirement (1), if necessary, by moving the die wheel toward the feed wheel to decrease the character spacing and away from the feed wheel to increase the character spacing. Tighten nut.

CAUTION: WITH TAPE REMOVED. MAKE SURE FEED WHEEL AND DIE WHEEL DO NOT BIND. RECHECK REQUIREMENT (1). IF NECESSARY, REFINE.

Note: First through fifth holes in gauge are same size as code holes in tape (0.072 inch diameter). Sixth hole in gauge is larger (0.086 inch). This arrangement allows ± 0.007 inch variation in 5 inches.

TEN CHARACTERS PER INCH (Preliminary)**(1) Requirement**

Indent of die wheel eccentric stud pointing downward.

To Adjust

Position die wheel eccentric stud with locknut loosened. Tighten nut.

(2) Requirement

With tape shoe blocked away from feed wheel, feed pawl and detent disengaged, and tape removed, feed wheel should rotate freely. Check through 3 or 4 revolutions of feed wheel. Refine requirement (1) above if necessary to meet this requirement.

2.29 Punch Mechanism (continued)

(For Latest Design see 2.30)

LATERAL AND FRONT TO REAR FEED WHEEL POSITION DETENT (Early Design)**Requirement**


With the reperforator operating under power, obtain a tape sample consisting of a series of NULL perforations, by a visual inspection of the perforated feed holes, laterally and front to rear, the indentations of the feed wheel should be fully punched out.

(1) To Adjust (Laterally)


To meet the lateral requirement, loosen the detent eccentric stud locknut and rotate the detent eccentric clockwise to move the feed wheel perforations towards the lead edge of the feed hole. Rotate the detent eccentric counterclockwise to move the feed wheel perforation towards the trailing edge of the feed hole. Tighten nut. Refine the feed pawl adjustment.

(2) To Adjust (Front to Rear)

To meet the front to rear requirement with respect to the reference edge of the tape, loosen the adjusting screw locknut and position the adjusting screw. To move the indentations in the tape away from the reference edge of the tape, move the feed wheel towards the front plate of the punch mechanism by rotating the adjusting screw counterclockwise. To move the indentations in the tape towards the reference edge of the tape, move the feed wheel towards the backplate of the punch mechanism by rotating the adjusting screw clockwise. Tighten nut. Refine the adjustment above to align the lateral indentations of the feed wheel if required.



2.30 Punch Mechanism (continued)

LATERAL AND FRONT TO REAR FEED WHEEL POSITION DETENT (Latest Design)**Requirement**

The indentations punched by the feed wheel should be centrally located between the punched feed holes (gauged by eye) and on same horizontal centerline. The unit must backspace the tape at least 30 characters without losing its point of registration.

To Check


Perforate 6 inches of RY tape. Backspace 30 characters. Reperforate with RUBOUT characters. Code holes must coincide except for first two characters which may be elongated ± 0.010 inch.

To Adjust (Laterally)

Rotate detent eccentric clockwise to move the feed wheel perforation toward the leading edge of the feed hole and rotate eccentric counterclockwise to move the perforation toward the trailing edge of the feed hole. Tighten locknut. Refine FEED PAWL (2.27) adjustment if necessary.

To Adjust (Front to Rear)

Loosen locknut on adjusting screw and rotate the screw counterclockwise to move the indentations in the tape away from the reference edge (rear) of the tape. To move indentations in the tape toward the reference edge of the tape, rotate adjusting screw clockwise. Tighten nut. Refine the lateral adjustment above if necessary.




2.31 Punch Mechanism (continued)

PUNCH SLIDE SPRING

Requirement


RUBOUT combination set up, and punch slides in selected position
 Min 2-1/4 oz---Max 3-1/4 oz
 to start each slide moving.



TAPE GUIDE ASSEMBLY SPRING

- (1) Requirement
 Min 16 oz
 to pull tape guide assembly away from tape guide block.
- (2) Requirement
 Tape guide assembly should move freely on shaft.

To Adjust
 With mounting screws loosened, position mounting post. Tighten screws.



BIAS SPRING (TAPE CHUTE)

Requirement

With selector and function clutches disengaged and latched, tape threaded through punch mechanism, it should require
 Min 1-1/4 oz---Max 2-1/4 oz
 to just move the spring away from the tape.

To Adjust
 Bend the spring.



Note: It is necessary to remove several parts, on units equipped with backspace mechanism, in order to check this spring tension. It should not be checked unless there is good reason to believe that requirements are not met.

BIAS SPRING (PUNCH BLOCK)

- (1) Requirement
 With tape removed from the punch block, the tape guide spring should rest against the clearance slot in the block in a symetrical manner.
- (2) Requirement
 With tape in the punch block and the reperforator operating under power, the spring should not distort the edge of the tape.

To Adjust
 Bend the spring and position it with its mounting screw loosened. Tighten screw.

PUNCH BLOCK




2.32 Punch Mechanism (continued)

FEED PAWL SPRING

Requirement

Function clutch disengaged and latched.
 Detent spring unhooked from toggle bail

Min 3 oz---Max 4-1/2 oz
 to start the detent lever moving.




DETENT LEVER SPRING

Requirement

Function clutch disengaged and latched.
 Feed pawl spring unhooked.

Min 7 oz---Max 10 oz
 to start the detent lever moving.





2.33 Punch Mechanism (continued)

TAPE SHOE TORSION SPRING

Requirement

Min 13 oz---Max 18 oz
to move tape shoe from feed wheel.



PUNCH SLIDE LATCH SPRING

To Check

Select RUBOUT code combination (12345678). Position rocker bail to extreme left. Strip pushlevers from selecting levers.

Requirement

For one-shaft unit
— Min 1 oz---Max 3 oz
to start latch moving.
For two-shaft unit
— Min 3/4 oz---Max 2 oz
to start latch moving.

2.34 Typing Mechanism

(A) PUSHBAR OPERATING BLADE (Preliminary)

To Check


Manually select RUBOUT code combination (12345678). Rotate mainshaft until function clutch trips. Hold no. 2 and 3 bellcranks against stop post.

Requirement

Operating blade parallel to (not necessarily flush with) no. 2 and 3 pushbars.

To Adjust

With its mounting screws friction tight, pry transfer mounting bracket all the way to the right. Tighten screws. Add or remove shims under the rear leg of the operating blade. Place extra shims on rear mounting screw between blade and flat washer. Tighten screws.



(B) BELLCRANK SPRINGS - 1 TO 5

To Check

Select RUBOUT code combination (12345678). Rotate mainshaft until function clutch trips.

Requirement

Min 1 oz---Max 3 oz to start pushbar moving.

Note: Check all five springs.

(C) BELLCRANK SPRING - 8

To Check


Select RUBOUT combination (12345678). Rotate mainshaft until function clutch trips. With scale applied horizontally over end of the tooth section.

Requirement

Min 3 oz---Max 5 oz to start bellcrank moving.

Note: This adjustment is completed on the following page.

2.35 Typing Mechanism (continued)



(D) BELLCRANK SPRINGS - 6 AND 7

To Check

Select RUBOUT combination (12345678). Rotate mainshaft until function clutch trips.

(1) Requirement (Bellcrank Spring 6)

With scale applied vertically to ball end of bellcrank contact operating arm
 — Min 2 oz---Max 4 oz
 to start bellcrank moving.

(2) Requirement (Bellcrank Spring 7)

With seven-pulse beam spring removed and scale applied vertically to ball end of bellcrank operating arm
 — Min 3 oz---Max 6 oz
 to start bellcrank moving.

SHOULDER CLEARANCE

To Check

Manually select RUBOUT code combination (12345678). Rotate mainshaft until function clutch trips. Manually seat pushbars in detented position. In bar which is nearest left edge of blade, take up play to left and rear, and then release.

(1) Requirement

Clearance between bar and left edge of blade
 — Min 0.015 inch---Max 0.030 inch

(2) Requirement


Some clearance between right edge of blade and pushbars when play in bars has been taken up to right and released.

(3) Requirement


With unit in stop position, some clearance between right edge of blade and bars when play in bars has been taken up to right and released.

To Adjust

With mounting screws loosened, position operating blade in elongated holes. Tighten screws.



2.36 Typing Mechanism (continued)



(Top View)

To Check


Select NULL combination. Position rocker bail through a complete cycle to insure the clearance is a minimum.

Requirement

Clearance between function box rear plate and pushbar operating blade
 ---Min 0.005 inch---Max 0.020 inch
 at a point in the cycle where play is taken up to make clearance minimum.

To Adjust

Position rocker bail pilot stud in elongated hole with locknut loosened. Tighten nut.



NO. 7 PULSE LEVER SPRING

Requirement

Min 20 oz---Max 25 oz
 to pull spring to length of 7/16 inch.

2.37 Typing Mechanism (continued)

FUNCTION BOX

Requirement

With letters pushbar to extreme right and fully detented, RUBOUT code (12345678) selected, punch slides disengaged and function clutched tripped, eliminate play in downward direction, then release. Keep operating blade parallel with no. 2 and no. 3 pushbars and take up function box play in a clockwise direction. The top of the operating blade should be


Min flush---Max 0.020 inch
above top rubout pushbars.

(1) To Adjust


Loosen the two screws mounting function box to spacer posts on front plate and set pry point in center of the cutout.

(2) To Adjust

Loosen the two screws which mount guide to the bracket and position guide to meet above requirement. Tighten screws.




2.38 Typing Mechanism (continued)



2.39 Ribbon Shift and Print Suppression Mechanism (Early Design)

Note: Refer to variable features (Part 3) for additional adjustments applying to print suppression only.



Note: The contact assembly can be identified by gold-plated contact points with a common transfer contact point on the contact swinger spring.

(1) Requirement

With the two contact swingers positioned toward each other, the clearance between the swingers should be
 Min 0.035 inch---Max 0.060 inch

To Adjust

Disconnect all power from unit. Remove the contact assembly from the function box by removing the two mounting bracket screws. With the four contact cover mounting screws friction tight, position the contact swingers. Check the alignment of the associated contacts with each swinger and tighten the four contact cover mounting screws.

(2) Requirement – Preliminary

With the contact assembly still removed from the function box, there should be
 Min 0.015 inch---Max 0.020 inch

clearance between the two swinger contact points and their associated normally open contact points. The top surface of the plastic insulators on both swingers should be parallel to each other and in the same plane (as gauged by eye).


(3) Requirement

In addition to the clearance requirement, it should take
 Min 2 oz---Max 3 oz


to start each swinger moving and to start normally open contacts moving away from their associated stiffeners.

To Adjust

Adjust the contacts with a contact adjusting tool.



2.40 Ribbon Shift and Print Suppression Mechanism (Early Design) (continued)



(For Latest Design see 2.42)

(Rear View)

RIBBON SHIFT AND PRINT SUPPRESSION CONTACT POSITION

Note: The following adjustments are to be made with the contact assembly mounted on the unit.

(1) Requirement

Manually select the NULL combination. With the function clutch tripped, the follower portion of the no. 6 and no. 7 bellcranks should be centrally positioned with respect to the insulator followers on the contact swingers as viewed from the front of the unit.

To Adjust

With the contact mounting bracket support mounting screws friction tight, position the contact assembly. Tighten screws.


(2) Requirement

With the NULL combination still selected and the function clutch tripped

Min some---Max 0.004 inch clearance between each of the two spacing contacts and their stiffeners. Take up the play in the function box in a clockwise direction (as viewed from the selector side of the unit).

To Adjust

With the contact bracket mounting screws friction tight, position the bracket. Tighten screws.




(Rear View)

2.41 Ribbon Shift and Print Suppression Mechanism (Latest Design)

Note: Refer to variable features (Part 3) for additional adjustments applying to print suppression only.

(For Early Design see 2.39)



RIBBON SHIFT AND PRINT SUPPRESSION CONTACTS

Note: The contact assembly can be identified by silver contact points with a common transfer contact point on the contact swinger spring and one retaining ring for fastening the cover. The cover may be removed by taking off the cover retaining ring snapped in place over the special cover mounting screw.

(1) Requirement

With the two contact swingers positioned toward each other, the clearance between the swingers should be
 Min 0.035 inch---Max 0.060 inch

To Adjust

Disconnect all power from unit. Remove the contact assembly from the function box by removing the two mounting bracket screws. With the four contact mounting screws friction tight, position the contact swingers. Check the alignment of the associated contacts with each swinger and tighten the four screws.

(2) Requirement - Preliminary


With the contact assembly still removed from the function box, there should be
 Min 0.015 inch---Max 0.020 inch
 clearance between the two swinger contact points and their associated normally open contact points. The top surface of the plastic insulators on both swingers should be parallel to each other and in the same plane (as gauged by eye).

(3) Requirement


In addition to the clearance requirement, it should take
 Min 45 grams---Max 60 grams
 to start each swinger moving and to start normally open contacts moving away from their associated stiffeners.

To Adjust

Adjust the contacts with a contact adjusting tool.



2.42 Ribbon Shift and Print Suppression Mechanism (Latest Design) (continued)



(For Early Design see 2.40)

RIBBON SHIFT AND PRINT SUPPRESSION CONTACT POSITION


Note: The following adjustments are to be made with the contact assembly mounted on the unit.

(1) Requirement

Manually select the NULL combination. With the function clutch tripped, the follower portion of the no. 6 and no. 7 bellcranks should be centrally positioned with respect to the insulator followers on the contact swingers as viewed from the front of the unit.

To Adjust

With the contact mounting bracket support mounting screws friction tight, position the contact assembly. Tighten screws.




(2) Requirement

With the RUBOUT combination selected and the function clutch tripped, there should be
 Min 0.025 inch--Max 0.045 inch
 clearance between the bellcranks and the insulated portion of their respective swingers. Take up the play in the function box.

To Adjust

With the contact bracket mounting screws friction tight, position the bracket. Tighten screws. Replace the cover and secure it with the cover retaining ring.

2.43 Typing Mechanism (continued)



(A) CAM FOLLOWER ROLLER ARM POSITION

To Check

Trip function clutch. Move rocker arm to extreme left position and observe travel of lifter roller on right dwell surface. Move rocker bail to extreme right position and observe travel of roller on left dwell surface.

Requirement

Approximately equal travel on each dwell surface.

To Adjust

Loosen lifter lever lock plate screw until friction tight. With eccentric screw locknut friction tight, position lifter lever. Tighten lifter lever lock plate screw. Do not tighten locknut.


(B) LIFTER OPERATING RANGE

Requirement

With function clutch disengaged, clearance between closest projection of bellcranks and associated function blade projection
Min 0.008 inch---Max 0.020 inch


To Adjust

Position lifter lever eccentric screw with locknut loosened. Tighten nut.



2.44 Typing Mechanism (continued)

Note: Preliminary when no function blades are used.



TOGGLE LINK

- (1) Requirement
With RUBOUT code combination (12345678) selected and rocker arm to extreme left, toggle linkage should move through a point where upper and lower toggle links are in a straight line without raising lifter blade
- (2) Requirement
With upper and lower toggle links in a straight line, clearance between the upper toggle link and lifter blade pin
Min some---Max 0.015 inch

To Adjust

Position lower toggle link by moving its extension arm up or down with clamp screw friction tight. Tighten screw.

Note: To avoid interference with the lower toggle link clamp screw and the axial corrector link, it may be necessary to move the high part of the corrector bushing above its horizontal center line.

2.45 Typing Mechanism (continued)

Note: Preliminary when no function blades are used.


TOGGLE TRIP ARM

Requirement

As rocker arm approaches extreme right position, the lifter toggle should break and lifter arm roller should drop onto right dwell surface.

To Adjust

By means of pry points, position toggle trip post with clamp screw loosened. Tighten screw.



2.46 Typing Mechanism (continued)

(A) LIFTER TOGGLE LINK SPRING


Requirement

With unit in stop position
 Min 1-1/2 oz---Max 2-1/4 oz
 to pull spring to installed length.

(B) FUNCTION BLADE SPRING (2 Or More)

Requirement (If so equipped)

With unit in stop position
 Min 7 oz---Max 10 oz
 to start function blade moving.



(C) LIFTER SPRING

Requirement

With unit in stop position
 Min 7 oz---Max 9 oz
 to pull spring to installed length.

(D) CORRECTING DRIVE LINK SPRING (NONYIELDING)

Requirement

With unit in stop position
 Min 5 oz---Max 9 oz
 to start drive link moving.

2.47 Typing Mechanism (continued)

(A) OSCILLATING BAIL DRIVE LINK

To Check


Position rocker bail to its extreme left.

Requirement

Sector mounting stud, toggle pivot screw and oscillating bail mounting screw should approximately line up.

To Adjust

With locknut friction tight, position oscillating link by means of its eccentric bushing. Tighten nut.



(B) OSCILLATING BAIL PIVOT

Requirement

With NULL combination selected, rotate mainshaft taking up the axial play in type wheel shaft toward the front of the unit. The axial corrector roller should enter first notch of the sector centrally.

To Adjust

With oscillating bail adjusting screw friction tight, select NULL combination. Position oscillating bail by means of its elongated mounting hole so corrector roller enters first notch of the sector when rocker bail moves to its extreme left position. Hold corrector roller firmly in first notch and take up the play in oscillating bail linkage by applying a force to the oscillating bail. Tighten oscillating adjusting screw.


2.48 Typing Mechanism (continued)

CORRECTOR DRIVE LINK (YIELDING) EXTENSION SPRING

Requirement

With the NULL code combination selected, function clutch tripped, and rocker bail in its extreme left position, place a 32 oz spring scale hook on the end of the corrector axial plate. It should take

Min 16 oz---Max 32 oz to move roller from notch in the sector.



AXIAL CORRECTOR (YIELDING)

Requirement

With all NULL code combination selected, function clutch tripped and rocker bail in its extreme left position, the axial corrector roller should seat in the first sector notch and there should be

Min 0.005 inch


between the ends of the slot and the spring post. Check both sides and check seating in fourth notch (letters selection). Turn the retaining ring that fastens drive link extension to corrector plate to check the minimum requirement.

To Adjust

Loosen two drive link adjusting screws. Position drive link to meet the requirement and retighten the screws.

2.49 Typing Mechanism (continued)


(A) AXIAL SECTOR ALIGNMENT



- (1) Requirement
Teeth of axial sector and axial output rack should engage by their full thickness.
- (2) Requirement
Guide roller free to rotate.

To Adjust
Loosen locknut. Disengage rack. Remove retaining ring and guide roller. Add or remove shims. Place extra shims on top of shim used to retain felt washer. Tighten nut.


Note: On units equipped with larger (0.594 inch diameter) roller, no adjustment is required.



(B) ECCENTRIC SHAFT
DETENT LEVER SPRING - (6)



Requirement
Min 7 oz --- Max 10 oz
to start detent lever moving.

Note: Check all 6 springs. There are two on the axial positioning mechanism and four on the rotary positioning mechanism.



2.50 Typing Mechanism (continued)

(A) AXIAL OUTPUT RACK GUIDE ROLLER



(B) PUSHBAR GUIDE BRACKET

To Check
Manually select CARRIAGE RETURN code combination (1-34---8). Rotate mainshaft so that no. 4 pushbar moves through complete range of travel.

Requirement
When play is taken up to make clearance maximum
Min some---Max 0.008 inch
between no. 4 pushbar and guide bracket throughout complete travel of bar.




To Adjust
Position guide bracket with mounting screws loosened. Tighten screws.

2.51 Typing Mechanism (continued)

(A) CORRECTING DRIVE LINK (NONYEELDING)

- (1) To Check
 Select the NULL code combination. Trip function clutch and move rocker bail to extreme left.
 Requirement
 Roller on axial correcting plate firmly seated in first notch of axial sector.
- (2) To Check
 Select RUBOUT code combination (12345678). Trip function clutch and move rocker bail to extreme left.
 Requirement
 Roller on axial correcting plate firmly seated in fourth notch of axial sector.

To Adjust
 Loosen drive link adjusting screws. Holding roller firmly seated in first notch and holding drive link down (bottomed) against bushing, tighten adjusting screws.



(B) TYPE WHEEL RACK CLEARANCE

Requirement
 With function clutch disengaged and upper no. 7 pushbar to the right
 Min some---Max 0.015 inch
 clearance between idler gear and rack at the closest point when all
 play is taken up in a direction to make clearance a maximum.
 There should be some clearance throughout travel of the rack.

To Adjust
 With mounting screw friction tight, position idler gear eccentric
 shaft by means of three adjusting holes in top of shaft. Tighten
 screw.

2.52 Typing Mechanism (continued)

ROTARY CORRECTOR MESH

(1) Requirement


With X code combination selected and the pushbars manually detented, the second tooth from the top of the rotary output rack should seat between the lobes of the rotary corrector arm.

To Adjust



Loosen clamp arm screw and eccentric bushing locknut. With the pivot of the corrector arm to the right of the center of the bushing, position rotary corrector. Tighten bushing locknut. Do not tighten clamp arm screw at this point.

(2) Requirement

In a manner similar to that described above, check engagement of fifth tooth (--34--7), ninth tooth (---4---), and sixteenth tooth (--3-5--). Refine the adjustment if necessary.



2.53 Typing Mechanism (continued)



ROTARY CORRECTOR ARM

To Check

With unit in letters condition, select the RUBOUT code combination (12345678). Position rocker bail to extreme left. Manually seat corrector arm in rack.

Requirement

The rotary corrector arm should seat firmly in the rotary output rack.
 Min some---Max 0.006 inch endplay between clamp arm and bushing, with unit in the stop position.


To Adjust (Units equipped with a yielding axial corrector)

As the rocker bail approaches the extreme left and the spring post of the axial corrector starts to leave the end of its slot, take up play of drive arm in its operating fork towards main bail and position the rotary corrector arm finger tight against rotary output rack and tighten clamp arm screw.

To Adjust (Units equipped with nonyielding axial corrector)

As the rocker bail approaches the extreme left, measure clearance between the axial corrector roller and the sector notch. When clearance is

Min some---Max 0.005 inch position rotary corrector arm finger tight against rotary output rack, and tighten correcting clamp arm screw.




2.54 Ribbon Shift and Print Suppression Mechanism (Latest Design) (continued)

RIBBON CARRIER SPRING

Requirement

With unit in stop position
Min 7 oz---Max 10 oz
to start carrier moving.



RIBBON CARRIER

Requirement

With function clutch disengaged,
manually lift blocking lever so
that it is opposite ribbon carrier
and against the type wheel shaft
housing.

Min 0.040 inch---Max 0.060 inch
clearance between blocking link
and ribbon carrier.

To Adjust

Loosen lockscrew. Position ribbon
oscillating lever, using adjusting
slot. Tighten screw.

2.55 Ribbon Shift and Print Suppression Mechanism (Early Design) (continued)

Note: The following adjustments apply to units with graphics either suppressed or in red (red of red-black ribbon towards rear of unit) when magnet is de-energized.

(B) ARMATURE AIR GAP**Requirement**

With armature on downstop screw
 Min 0.015 inch---Max 0.020 inch
 clearance between magnet core
 and armature at closest point and
 Min some---Max 1/32 inch
 clearance between rear of armature
 slot and blocking link as gauged by
 eye.

To Adjust

Position magnet bracket with screws
 loosened. Tighten screws. Check for
 binds.

(A) ARMATURE DOWNSTOP**Requirement**

With rocker bail in extreme left position
 and ribbon carrier biased downward,
 hold the blocking link against the type
 wheel shaft housing.


Min some---Max 0.005 inch
 clearance between top surface of block-
 ing link and lower surface of ribbon
 carrier.

To Adjust

Position armature downstop screw with
 lock nut loosened.

(D) ARMATURE SPRING**Requirement**

With spring disconnected
 Min 3-1/2 oz---Max 4-1/2 oz
 when pulled to installed length.


**(C) ARMATURE UPSTOP****Requirement**

With armature held against
 upstop screw (magnet is not
 to be energized)

Min 0.004 inch---Max 0.007 inch
 clearance between magnet core
 and armature at closest point.

To Adjust

Position upstop screw with lock-
 nut loosened. Tighten nut.



Note: Refer to Part 3 for additional print suppression adjustments.

2.56 Ribbon Shift and Print Suppression Mechanism (Latest Design) (continued)

Note: The following adjustments apply to units with printing of graphics either suppressed or in red (red of red-black ribbon towards front of unit) when magnet is de-energized.

(C) ARMATURE AIR GAP AND DOWNSTOP

Requirement

With armature resting on downstop screw

Min 0.015 inch---Max 0.020 inch clearance between magnet core and armature at closest point.

To Adjust

Position downstop screw with locknut loosened. Tighten nut.

(B) BLOCKING LINK

Requirement

With armature held against upstop screw (magnet is not to be energized) and ribbon carrier biased upward

Min some---Max 0.008 inch clearance between blocking link lower surface and ribbon carrier top surface at closest point and

Min some---Max 0.031 inch clearance between rear of armature slot and blocking link as gauged by eye.

To Adjust

Position magnet bracket with screws loosened. Tighten screws.

(A) ARMATURE UPSTOP

Requirement

With armature held against upstop screw (magnet is not to be energized) ribbon carrier biased upward

Min 0.005 inch---Max 0.010 inch clearance between magnet core and armature at closest point.

To Adjust


Position upstop screw with locknut loosened. Tighten nut.

(D) ARMATURE SPRING

Requirement

With spring disconnected

Min 3-1/2 oz---Max 4-1/2 oz when pulled to installed length.



Note: Refer to Part 3 for additional print suppression adjustments.

2.57 Typing Mechanism (continued)

PRINTING LATCH

Note 1: For units with adjustable printing latch mounting bracket.

(1) Requirement

With rocker bail in its extreme left position, manually raise the print hammer accelerator. The clearance between the print hammer accelerator and the printing latch should be

Min some---Max 0.015 inch

(2) Requirement

With rocker bail in its extreme right position, there should be some over-travel of the print hammer accelerator with respect to the latching surface of the printing latch and some clearance between the print hammer accelerator and the ribbon carrier (or accelerator blocking link if present).

To Adjust

(1) Position the rocker bail to the extreme right. With the high part of the eccentric to the left, rotate the eccentric so that the clearance between the print hammer accelerator and the ribbon carrier is




Approximately 0.065 inch

With mounting screws friction tight, position the printing latch mounting bracket to its extreme rear position.

(2) With the rocker bail to the extreme left, move the printing latch mounting bracket toward the front until the print hammer accelerator just trips. Tighten the mounting screws.


(3) With the rocker bail to the extreme left, position the trip lever eccentric (keeping the high part to the left) until the clearance between the printing latch and the print hammer accelerator is as called for in requirement (1). Tighten nut.

Note 2: For units with non-adjustable printing latch mounting bracket use above "(1) Requirement" and adjust according to "To Adjust (3)."



(Left Side Views)

2.58 Typing Mechanism (continued)



PRINT HAMMER RETURN SPRING

Requirement

With unit in the stop position, it should require
 Min 1 oz---Max 3 oz
 to pull the print hammer lever so that the top
 of the hammerhead is level with the type wheel.

PRINT HAMMER ACCELERATOR SPRING

Requirement

With the unit in the stop position
 Min 32 oz---Max 42 oz
 to pull the spring to its installed length.

PRINT HAMMER ACCELERATOR LATCH SPRING


Requirement

With the unit in the stop position
 Min 5 oz---Max 7 oz
 to pull the spring to its installed length.

PRINT HAMMER TRIP LEVER SPRING


Requirement

Min 4 oz---Max 7 oz
 to pull spring to installed length.



PRINTING TRIP LEVER SPRING

2.59 Typing Mechanism (continued)



TYPE WHEEL (Preliminary)

To Check

Select H code combination (---4--78). Place rocker bail to extreme left. Correcting arm should be firmly seated in type wheel rack.

Requirement

Type wheel aligned so that full character is printed uniformly and six and one half code hole spaces behind its perforated code hole.

To Adjust

Position type wheel with locknut loosened. Check printing by manually lifting accelerator to latched position and releasing it.

Note: For best results, it may be necessary to make PRINT HAMMER (2.60) adjustment and then refine this adjustment.

TYPE WHEEL (Final)

To Check

With unit operating under power.

Requirement

All characters should be legible and six and one half code hole spaces behind the perforated code holes.

To Adjust

Refine type wheel position with locknut friction tight. Tighten locknut.

Note: For best results, it may be necessary to make PRINT HAMMER (2.60) adjustment and refine this adjustment.

2.60 Typing Mechanism (continued)

PRINT HAMMER**To Check**

With unit operating under power.


Requirement

Print hammer aligned with type wheel so as to obtain quality printing with some clearance between the pin points on the feed wheel and the side of the print hammer.

To Adjust

Position print hammer shaft with its locknut friction tight. Tighten locknut.

Note: It may be necessary to make the TYPE WHEEL (Final) (2.59) adjustment and then refine this adjustment.



(Front View)

2.61 Typing Mechanism (continued)

FEED PAWL SPRING


Requirement

With rocker bail to extreme right
 Min 4 oz---Max 6 oz
 to pull feed pawl spring to installed
 length.

RATCHET WHEEL
 TORQUE SPRING

Requirement

Min 1 oz---Max 3 oz
 applied tangentially to
 the ratchet wheel to
 start it to rotate.



DRIVE ARM

To Check

Position rocker bail to extreme left. Hold the ribbon reversing arm under lower reversing extension of feed pawl.

(1) Requirement

Clearance between blocking edge of ribbon reverse arm and reversing extension of feed pawl
 Min some

(2) Requirement

Clearance should not be so great as to allow feed pawl to feed more than two teeth at a time.

(3) Requirement

Feed pawl detented in both its right and left position.

To Adjust


Position drive arm adjustable extension lever with its mounting screw loosened. Tighten screw.

2.62 Typing and Tape Depressor Mechanisms

DRIVE ARM SPRING

Requirement

With rocker bail to extreme right
 Min 9 oz---Max 14 oz
 to pull drive arm spring to
 installed length.




DETENT SPRING

Requirement

With reversing arm in its extreme
 right or left position
 Min 2 oz---Max 4 oz
 to pull detent spring to its installed
 length.

TAPE DEPRESSOR



(Front View)

TAPE PLATFORM (Early Design)

Requirement

Top surface of tape platform
 should be flush with top surface
 of tape guide.

To Adjust

With tape platform mounting
 screws loosened, position tape
 platform. Tighten screws.

CLAMP PLATE SPRING
 (Early Design)

Requirement

Function clutch disengaged and
 latched. Clamp plate spring
 bowed to the right.

Min 18 oz---Max 24 oz
 to move clamp plate from bottom
 of slot in tape depressor.

2.63 Tape Depressor Mechanism (continued)

CLAMP PLATE SCREW WITH DISC (Latest Design)

Requirement


Loosen nut and turn screw with disc so that a new area of the disc contacts the tape. Tighten nut.

Note: This adjustment should be made once every lubrication period or when the ten holes per inch requirement is not being held.

CLAMP PLATE SPRING (Latest Design)

Requirement

Min 30 grams applied to tab of clamp plate to start it moving



TAPE PLATFORM (Latest Design)

Requirement


The top surface of tape platform and tape guide should be flush with the top surface of tape guide.

To Adjust

With tape platform mounting screws loosened, position tape platform. Tighten screws.

3. VARIABLE FEATURES

3.01 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism




(A) ARMATURE HINGE

Requirement

With armature manually operated, it should be flush against pole face and magnet bracket extension.

To Adjust

Loosen armature hinge bracket mounting screws, position armature and tighten screws.



(B) DRIVE BAIL SPRING

Requirement

Rotate mainshaft until drive bail is on high part of its cam.

Min 23 oz---Max 32 oz to start the drive bail moving.

(C) MOUNTING PLATE

Requirement

With armature in unoperated position. Rotate mainshaft until drive bail is on high part of its cam. Clearance between the blocking bail and drive bail surface

Min 0.006 inch---Max 0.015 inch

To Adjust

Position blocking bail with mounting plate clamp screw and spring post friction tight. Tighten screw and nut.

(D) MAGNET ASSEMBLY


Requirement

With armature held in operated position, rotate mainshaft until drive bail roller is on high part of its cam. Clearance between blocking bail and right edge of drive bail at its closest point

Min 0.005 inch---Max 0.015 inch

To Adjust

Position magnet assembly, armature held against magnet pole piece with magnet bracket mounting screws friction tight. Tighten screws.




3.02 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)

(A) BLOCKING LATCH TORSION SPRING

Requirement

With armature in unoperated position and drive bail roller on high part of its cam.

Min 15 grams---Max 40 grams to start blocking latch moving.



(B) ARMATURE BACKSTOP

(1) Requirement

With armature in operated position, rotate mainshaft until drive bail roller is on high part of its cam. The drive bail should engage the blocking bail by at least 2/3 of its thickness.

(2) Requirement

Min some---Max 0.005 inch between blocking latch and non-repeat latch.

To Adjust

With the armature backstop mounting screws friction tight, position by means of pry point. Tighten screws.

(C) NONREPEAT LEVER SPRING

Requirement

With armature in unoperated position and drive bail roller on high part of its cam

Min 6 oz---Max 9 oz to pull spring to installed length.

(D) BLOCKING BAIL SPRING

Requirement

With armature in unoperated position and drive bail roller on high part of its cam.

Min 3 oz---Max 5 oz to pull spring to installed length.

(E) RELEASE LEVER


Requirement

With armature in operated position, rotate mainshaft until drive bail roller is in indent of its cam. Clearance between release lever and latchlever.

Min 0.010 inch---Max 0.025 inch

To Adjust

With clamp screw friction tight, position release lever. Tighten screw.



3.03 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)


RELEASE LEVER SPRING

To Check

Trip selector clutch. Rotate mainshaft until reset cam follower is on peak of reset bail cam. With spring hook, hold front ratchet check pawl away from release lever.

Requirement

Min 5 oz---Max 7 oz
to start release lever moving.



LATCHLEVER

(1) Requirement

Trip selector clutch. Rotate mainshaft until stripper cam follower is on peak of cam, where the clearance for the following adjustment is at a minimum.

Min 0.018 inch---Max 0.028 inch
between release lever and latchlever.

(2) Requirement

Min some---Max 0.008 inch
endplay between cam follower and
bushing.

To Adjust

Position latchlever with clamp screw on
stripper cam follower loosened.

LATCHLEVER SPRING

To Check

Trip selector clutch. Rotate mainshaft
until reset cam follower is on peak of re-
set bail cam.

Requirement

Min 2 oz---Max 4 oz
to pull spring to installed length.

3.04 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)


(C) FEED PAWL AND FRONT CHECK PAWL SPRINGS

Requirement

With unit in feed out cycle (see "To Check" of REAR CHECK PAWL adjustment below).

Min 1 oz---Max 3 oz
to pull each spring to installed length.

FRONT CHECK PAWL



(B) REAR CHECK PAWL SPRING

Requirement

Min 28 grams---Max 56 grams
to start rear check pawl moving.


(A) REAR CHECK PAWL

Requirement

With unit in feed-out cycle and the feed pawl in its extreme left position,
Min 0.008 inch---Max 0.020 inch
between rear check pawl and ratchet tooth.

To Adjust


With clamp screw loosened, position rear check pawl by means of pry point. Tighten screw.



Note: Proceed to FRONT RATCHET STOP POSITION (3.05) adjustment.

3.05 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)

Note: See REAR CHECK PAWL (3.04) adjustment before making this adjustment.




3.06 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)

(C) RATCHET RETURN SPRING

Requirement
 With unit in stop position
 Min 5 oz---Max 7 oz
 to pull spring to installed length.

(B) TIME DELAY LEVER SPRING

Requirement
 With unit in stop position
 Min 2 oz---Max 3 oz
 to pull spring to installed length.



(A) TIME DELAY LEVER

To Check

Trip selector clutch and rotate mainshaft until reset cam follower is on high part of reset bail cam.

(1) Requirement
 Min 0.040 inch---Max 0.060 inch
 clearance between time delay lever
 and high part of time delay cam.

(2) Requirement
 With unit in stop position
 Min some
 clearance between time delay lever and
 high part of time delay cam.

To Adjust
 With clamp screw loosened, position
 eccentric bushing. Tighten screw.

3.07 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)

(A) RELEASE ARM

(1) Requirement

With unit in the feed-out cycle, ratchets advanced beyond the time delay, clearance between the drive arm and upper surface of release arm
 Min 0.010 inch---Max 0.030 inch
 Rotate cam so that the mating surfaces of the drive arm bail and release arm are approximately parallel.


(2) Requirement

With unit in stop position, the surface of the drive arm bail that does not engage the release arm should not exceed

Max 0.015 inch

To Adjust

With clamp nut friction tight, position release arm by means of eccentric screw on time delay lever. Tighten nut.



(B) RELEASE ARM SPRING

Requirement

With clutches disengaged and drive arm latched by release arm

Min 2 oz---Max 5 oz
 to pull spring to installed length.


3.08 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)

(A) DRIVE ARM SPRING

Requirement

With unit in feed-out cycle and drive arm roller held firmly against its cam indent

Min 42 oz---Max 50 oz
to pull spring to installed length.



(B) PUNCH SLIDE LATCH

Requirement

With the NULL code combination selected and the unit in the feed-out cycle, the ratchets advanced beyond the time delay and drive arm on low part of its cam, the clearance between punch slide and punch slide latch should be

Min 0.010 inch---Max 0.030 inch
at slide where clearance is a minimum.

Note: See that the reset bail is tripped.

To Adjust

With clamp screw loosened, position drive arm adjusting plate by means of its pry point. Tighten screw.

3.09 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)

(B) ADJUSTING LEVER

To Check

Place unit in feed-out cycle by positioning release lever on lower step of latch-lever and advancing high part of time delay cam beyond time delay lever. Position mainshaft so that drive arm roller is on low part of cam.

(1) Requirement

Min 0.010 inch--Max 0.030 inch between release and main trip lever.

(2) Requirement

Some clearance between main trip lever and downstop bracket.

To Adjust

Loosen the clamp screw on the adjusting lever and position, making sure the adjusting lever rides fully on the slide trip lever. Tighten screw.

(A) TRIP CAM FOLLOWER

(1) Requirement

With follower lever on high part of trip cam


Min 0.010 inch--Max 0.030 inch between release and main trip lever.

(2) Requirement


Some clearance between main trip lever and downstop bracket.

To Adjust

With locknut loosened, position adjusting arm by means of pry point. Tighten nut.



3.10 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)



RESET BAIL TRIP LEVER

To Check


Select RUBOUT code combination (12345678). Rotate mainshaft until function clutch trips. Position punch slides against downstop. Trip cam follower on high part of cam.

- (1) Requirement
Min 0.008 inch---Max 0.020 inch
between punch slide and reset bail.
- (2) Requirement
With clutches fully disengaged and latched, reset bail should fully engage notches in punch slides.

To Adjust

With clamp screw loosened, position reset bail trip lever by means of adjusting slot. Tighten screw.

3.11 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)

TAPE LENGTH ADJUSTING PLATE

Note: Amount of tape fed out can be set for any length up to 18 inches.

(1) Requirement

Place unit in feed-out cycle by positioning release lever on lower step of latchlever. Manually advance ratchets so that front ratchet is in the tooth preceding trip off. Rotate mainshaft until feed pawl is in the extreme left position. Clearance between adjusting plate and latchlever projection
Min 0.002 inch---Max 0.020 inch

(2) Requirement

When operating under power, unit should feed out correct length of tape.

To Adjust


With spring post friction tight. Position adjusting plate. Tighten post.

3.12 Remote Control Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)

(B) RESET BAIL LATCH SPRING

Requirement

With unit in stop condition
Min 1 oz---Max 3 oz
to start reset bail latch moving.



(A) RESET BAIL LATCH

(1) To Check (Vertical Clearance)

Select RUBOUT code combination (12345678). Rotate mainshaft until function clutch trips and punch slides are to extreme left. Manually set up the NULL code combination (-----) in selector. Rotate mainshaft until punch slides are just latched.

(1) Requirement

Min 0.008 inch---Max 0.020 inch
between reset bail and reset bail latch.

To Adjust

With mounting screws loosened, position mounting plate by means of pry points. Tighten screws.

(2) Requirement (Horizontal Clearance)

With clutches disengaged,
Min 0.005 inch---Max 0.020 inch
between reset bail and reset bail latch.

To Adjust

With a clamp screw loosened, position bail latch by means of its pry points so its latching surface is approximately at midpoint in thickness of the reset bail. Tighten screw.

(2) To Check

Select RUBOUT code combination (12345678). Rotate mainshaft until function clutch trips. Manually set up the NULL code combination (-----). Rotate mainshaft to stop position.

Requirement

Punch slides latched by punch slide latches.

To Adjust

Refine requirements (1) and (2) above.


(C) RESET BAIL TRIP LEVER SPRING

To Check



Disengage both clutches. Trip function clutch by pivoting main trip lever counterclockwise. Hold reset bail trip lever up against reset bail.

Requirement

Min 18 oz---Max 24 oz
to pull spring to installed length.




3.13 End of Feed-Out Contacts for Noninterfering RUBOUT Tape Feed-Out Mechanism



LATCHLEVER SPRING


Requirement
Trip selector and rotate mainshaft until stripper cam follower lies on high part of its cam
Min 9 oz---Max 12 oz
to stretch spring to its installed length.



3.14 End of Feed-Out Contacts for Noninterfering RUBOUT Tape Feed-Out Mechanism (continued)

Note: See preliminary contact adjustments, 3.13.

(D) CONTACT ASSEMBLY MOUNTING BRACKET



- (1) Requirement (Unit in stop position)
When normally open contacts are used and release lever is above lower step of latchlever

Min 0.005 inch visible overtravel of swinger after it makes contact with normally open contact.

- (2) Requirement
When normally closed contacts are used and release lever is on upper step of latchlever, the normally closed contacts should be closed and bail should not exert any force against swinger insulator button.

To Adjust
Position contacts with bracket mounting screws loosened. Tighten screws.

(E) TAPE LENGTH ADJUSTING PLATE

- (1) Requirement
With unit in stop position and release lever on lower step of latchlever, manually advance ratchets so that feed pawl is in the front tooth preceding trip off (not in deep tooth of rear ratchet). Hold bail lightly against latchlever extension

Min 0.002 inch--Max 0.020 inch clearance between adjusting plate and bail.

- (2) Requirement
When operating under power, unit should feed out correct length of tape.

To Adjust
Position adjusting plate with spring post loosened. Tighten post.

Note: Feed pawl in extreme left position and adjusting plate in dotted position for adjustment (B) only.

3.15 Manual Backspace Mechanism

(A) BACKSPACE RATCHET

Requirement

Teeth of backspace and feed wheel ratchets to line up (visual alignment). Feed wheel ratchet to be in detented position.

To Adjust

With adjusting clamp mounting screw friction tight, rotate backspace ratchet to meet the requirement. Tighten screw.

(B) BACKSPACE PAWL CLEARANCE

(1) Requirement (Preliminary)

With backspace bellcrank rotated clockwise, the backspace pawl should miss the first tooth by a clearance of Min 0.003 inch---Max 0.010 inch at point of least clearance.


(2) Requirement (Final)

The backspace pawl should miss the first tooth and engage the second tooth by at least 1/2 of the right engaging surface of the backspace pawl (as gauged by eye) when backspace pawl first contacts the ratchet tooth.

To Adjust


Take up all rotational play of backspace ratchet in relation to feed ratchet by rotating it clockwise at same time rotate bellcrank clockwise. With mounting screw friction tight, rotate eccentric post to meet the requirements. Tighten screw.

Final minimum engagement: 1/2 of surface with second ratchet tooth at first point of contact.



3.16 Manual and Power Drive Backspace Mechanism (continued)

(A) FEED PAWL ECCENTRIC (Preliminary)



(1) Requirement (Manual Backspace)

With the backspace bellcrank assembly in its operated position and the feed wheel detented back one space. Min some---Max 0.003 inch clearance between the backspace ratchet tooth and the backspace feed pawl with all the rotational play of the backspace ratchet taken up in a direction to make the clearance maximum.

(2) Requirement (Power Drive Backspace)

With the backspace bellcrank assembly in its operated position, the high side of the eccentric should be in its uppermost position.

To Adjust

Loosen the nut post (friction tight) and rotate the eccentric with an allen wrench. Tighten the nut post.

(B) ARMATURE HINGE (Early Design)


Requirement

With armature bail spring removed, armature held against the pole face, take up play at hinge in a downward direction. Clearance between the armature and magnet bracket. Min some---Max 0.004 inch

To Adjust


With hinge mounting screws friction tight, position hinge. Armature should touch front and rear of pole face. Tighten screws and recheck adjustment.

Note: For dc operation, the armature should be positioned so that the side marked "C" faces pole face of magnet core. For ac operation, unmarked side faces pole.



Note: For latest design armature adjustments see 3.19.

3.17 Power Drive Backspace Mechanism



(A) ARMATURE UPSTOP (Early Design)


Requirement
 Armature in unoperated position.
 Gap between armature and pole face
 Min 0.025 inch---Max 0.030 inch
 at closest point.

To Adjust
 Rotate eccentric with mounting nut
 loosened. Keep high part of eccen-
 tric to left. Tighten nut.

(B) DRIVE LINK (Early Design)

Requirement
 With high part of eccentric arm in left-
 hand position, armature against pole
 face to allow drive arm latchlever to
 rest against eccentric link
 Min 0.040 inch---Max 0.045 inch
 clearance between step on eccentric
 arm and latchlever with play taken up
 to make gap a maximum.

To Adjust
 With drive arm screw friction tight,
 position adjusting link. Tighten screw.




(C) LATCH EXTENSION (Early Design)

Requirement
 With backspace mechanism in unoperated position, eccentric high part at the left, armature
 against the pole face, latch resting on the eccentric arm notch, clearance between top of
 armature extension and latch extension
 Min 0.005 inch---Max 0.020 inch

To Adjust
 With magnet mounting screws friction tight, swing magnet left or right. Tighten screws.

3.18 Power Drive Backspace Mechanism (continued)



(A) LATCH (Early Design)

Requirement

Backspace mechanism in unoperated position, armature off pole face (de-energized), latch extension against end of armature, eccentric arm at its closest point to under side of latchlever. Clearance between latch and eccentric arm with play in the links taken up to make the clearance a minimum should be

Min 0.005 inch---Max 0.025 inch

To Adjust

With latch extension screw friction tight, position latch. Tighten screw.

(B) NONREPEAT ARM (Early Design)

Requirement


Backspace mechanism in unoperated position. Clearance between top surface of nonrepeat arm and lowest point of latch extension

Min 0.002 inch---Max 0.010 inch

To Adjust

With arm screw friction tight, position adjusting arm. Tighten arm screw.

LATCH EXTENSION




3.19 Power Drive Backspace Mechanism (continued) (Nonadjustable Backspace Magnet Assembly)

Note 1: For early design adjustable magnet assembly see 3.16.

(A) ARMATURE SPRING (Latest Design)

Requirement
Min 15 oz---Max 20 oz
to pull spring to installed
length.



(B) LATCH EXTENSION SPRING (Latest Design)

Requirement
Min 1 oz---Max 2-1/4 oz
to start latch moving.

(C) MAGNET POSITION (Latest Design)

Requirement

The armature extension should engage the latch by approximately its full thickness when the magnet is de-energized.

To Adjust

Position the magnet assembly by means of its mounting screws. Tighten screws.

Note 2: The final adjustment requirement for all backspace mechanisms, manual or power drive, regardless of the type of unit will read as follows:

(D) FINAL MANUAL OR POWER ADJUSTMENT (Latest Design)

(1) Requirement

With tape in the unit, place the feed wheel shaft oil hole in its uppermost position, operate the backspace mechanism once. The ratchet wheel should be backed one space into a fully detented position.

Note 3: A fully detented position is defined as: With the detent roller in contact with the ratchet wheel the punch unit feed pawl should engage the first tooth below the horizontal centerline of the feed wheel ratchet with no perceptible clearance.

(2) Requirement

With the unit operating under power, perforate approximately two inches of tape with the RUBOUT combination selected. Backspace twelve characters in succession with the unit still under power. Again perforate approximately two inches of tape with the RUBOUT combination selected. Clipping of the code holes should be held to a minimum and should not exceed more than 0.005 inch, as gauged by eye.

To Adjust

On manual operated backspace mechanisms refine the FEED PAWL ECCENTRIC (Preliminary) (3.16) adjustment. On backspace mechanisms equipped with power drive, loosen the arm adjusting screw and position the adjusting plate. Tighten the arm adjusting screw.

3.20 Power Drive Backspace Mechanism (continued)

(A) FEED PAWL SPRING

Requirement

Backspace mechanism in unoperated position.

Min 4 oz---Max 6 oz
to start feed pawl moving.

(B) BELLCRANK SPRING

Requirement


Min 9 oz---Max 12 oz
to pull spring to installed length.

(C) ARMATURE LATCH SPRING
(Early Design)

Requirement

Min 1 oz---Max 2-1/4 oz
to pull armature latch spring
to installed length.

Note: All spring tensions should be taken with the mechanism in unoperated position.



(D) ARMATURE BAIL SPRING
(Early Design)


Requirement

With armature latch spring
unhooked

Min 3-1/2 oz---Max 6-1/2 oz
to start armature moving.

3.21 Print Suppression Mechanism

Note 1: Refer to Part 2 for preliminary adjustments in common with ribbon shift adjustments in all units.



ACCELERATOR BLOCKING LINK (Latest Design)

(1) Requirement

With the rocker bail in the extreme left position, there should be
 Min 0.075 inch---Max 0.095 inch
 clearance between the accelerator lever and the accelerator blocking link.

(2) Requirement

With the unit in the stop position, there should be
 Min some _____
 clearance between the top surface of the accelerator and the blocking link.

(3) Requirement


With the ribbon shift magnet armature resting against its upstop screw and when the mainshaft is rotated through a complete revolution, there should be
 Min some _____
 clearance between the accelerator and blocking link at its closest point.

To Adjust

Loosen the two screws which mount the accelerator blocking link and position the link both horizontally and vertically to meet the requirements. Tighten screws.

3.22 Print Suppression Mechanism (continued)

Note 1: Refer to Part 2 for preliminary adjustments in common with ribbon shift adjustments in all units.



Note 2: The following adjustment pertains to units that block the ribbon carrier when the shift magnet armature is held attracted.

ACCELERATOR BLOCKING LINK (Early Design)

Requirement

Function clutch tripped and mainshaft rotated until print hammer trip lever just touches print release latch. There should be

Min 0.020 inch--Max 0.030 inch

clearance between the upper surface of the print suppression link and the lower surface of the print hammer accelerator.

To Adjust

Position the print suppression link all the way to the rear of the slots on the ribbon carrier. Position link in vertical direction with mounting screws loosened to meet requirement. Tighten screws.

3.23 Print Suppression Mechanism (continued)

CONTROL LEVER (Manual)

(1) Requirement

There should be a clearance of
Min 0.015 inch

between the print suppress lever and the print hammer when the lever extension is in the print position (down).


(2) Requirement

When the lever extension is in the nonprint position (up), the blocking extension should extend across the full thickness of the print hammer with a clearance of


Min 0.015 inch
at the side of the print hammer.

To Adjust

Loosen the eccentric bushing mounting nut and position the bushing until the requirements are met. The high part of the eccentric should be down and to the right as viewed from the rear of the unit. Tighten nut.



LEVER SHOULD EXTEND ACROSS
FULL THICKNESS OF PRINT HAMMER.



3.24 Signal Bell and EOT Contacts

Note 1: The following adjustments should be made prior to installing the contact bracket assembly on unit.


(A) NORMALLY OPEN CONTACT GAP

Requirement

Min 0.008 inch---Max 0.015 inch

To Adjust

Bend normally open contact spring.



(B) NORMALLY CLOSED CONTACT

Requirement

Min 8 grams---Max 15 grams to move the swinger contact away from the normally closed contact.

To Adjust

Bend normally closed contact spring.

Note 2: The following adjustments should be made after the contact bracket assembly is mounted to the unit.

NORMALLY CLOSED CONTACT

(C) NORMALLY OPEN CONTACT GAP

(1) Requirement

With the function blade in its lowest position in the nonselected condition, clearance between the contact swinger insulator button and the function blade

Min some

(2) Requirement

Contact gap

Min 0.008 inch---Max 0.015 inch

To Adjust

Bend normally closed contact spring.

(3) Requirement


With the function blade in its lowest position in the selected condition, gap between the swinger contact and normally closed (now open) contact

Min 0.015 inch

and some overtravel of the normally open contact.

To Adjust

Bend normally closed contact spring. Refine previous adjustments to maintain requirements.



28 AND 35 ANSWER-BACK UNIT

ADJUSTMENTS

CONTENTS	PAGE
1. GENERAL	1
2. BASIC UNITS	2
Trip Mechanism	
Armature extension gap	2
Clutch trip magnet armature spring .	3
Contact block position (final)	3
Contact block position (preliminary) .	2
Feed Mechanism	
Code drum contact wire spring	6
Code drum detent spring	6
Eccentric stop position	5
Feed bail spring	4
Feed pawl	4
Feed pawl spring	5
Relay Brackets and Contacts	
Motor hold and relay pull-up contact bracket	6
Motor hold and relay pull-up contact .	7
Nonrepeat relay	7
Distributor Brushes	
Brush holder spring	8
Distributor brush holder	8
Gear Backlash	
Gear backlash - ASR (transmitter base)	10
Gear backlash - RO, KSR	9
Gear backlash - self-contained unit . .	9

1.02 The adjustments in this section are arranged in a sequence that should be followed if a complete readjustment is undertaken. A complete adjusting procedure should be read before attempting to make the adjustment. After an adjustment is made, be sure to tighten any nuts or screws that may have been loosened, unless otherwise instructed.

1.03 The adjustment illustrations indicate tolerances, positions of moving parts, spring tensions, and the angle at which scales should be applied. The tools required to make adjustments and check spring tensions are not supplied with the equipment, but are listed in the appropriate section under separate cover. Springs which do not meet the requirements, and for which there are no adjusting procedures, should be discarded and replaced by new springs.

1.04 Where adjustment instructions call for removal of components, assemblies, subassemblies, or parts, all adjustments which the removal of these parts might facilitate should be made before the parts are replaced, or as the equipment is reassembled. When a part mounted on shims is removed, the number and location of shims should be noted so that the identical pile-up can be made when the part is replaced.

1.05 All electrical contact points should meet squarely. Contacts with the same diameter should not be out of alignment more than 25 per cent of the contact diameter. Check contacts for pitting and corrosion and clean or burnish them before making the specified adjustment or tolerance measurement. Avoid sharp kinks or bends in the contact springs.

Note: Keep all electrical contacts free of oil and grease.

1. GENERAL

1.01 This section is reissued to add coverage of the 5- and 8-level answer-back unit. Since this revision is of a general nature, marginal arrows have been omitted.

1.06 References made to left or right, up or down, and front or rear apply to the answer-back unit as viewed from the side with

the answer-back mechanism to the left and the motor to the right.


1.07 Unless otherwise specified, where the stop position of the answer-back mechanism is referred to, the lugs of both the clutch release lever and shaft stop lever should be against the armature, with the armature exten-

sion resting in the stop indent of the code drum stop cam.

1.08 Instructions for coding the answer-back drum are not included in this section. Refer to the appropriate section covering installation of the answer-back unit for detailed coding instructions.

2. BASIC UNITS

2.01 Trip Mechanism




CONTACT BLOCK POSITION (PRELIMINARY)

Requirement

Answer back in stop position, armature extension must drop into stop indent in code drum stop cam.

To Adjust

Step code drum to last character. Rotate main shaft further until the motor hold cam allows armature to drop. Position the contact block until armature extension drops into indent with the contact block mounting screws loosened.



ARMATURE EXTENSION GAP

Requirement


With armature held against magnet core Min some---Max 0.015 inch between armature extension and high part of code drum stop cam.

To Adjust

Hold armature against magnet core and position magnet yoke assembly with its mounting screws friction tight. Recheck clearance after tightening screws.

Note: When holding armature against core, press between pivot and core to prevent lifting armature.

2.02 Trip Mechanism (continued)



CONTACT BLOCK POSITION (FINAL)

Requirement

Answer back in stop position, the armature must fall into the stop indent freely with some clearance between the extension and each side of the stop indent. The side to side play of the armature must be limited by the width of the groove in the contact block rather than the edges of the yoke.

To Adjust


Position the contact block with its mounting screws loosened.

Note: Keep back of block approximately parallel and in line with back of frame.


CLUTCH TRIP MAGNET ARMATURE SPRING

Requirement

Min 7 oz---Max 9 oz
to start heel end of armature moving.



2.03 Feed Mechanism



FEED BAIL SPRING


Requirement

With code drum removed and feed bail on high part of its cam to start bail moving.
Min 15 oz---Max 17 oz

To Adjust

With bracket mounting screws friction tight, position bracket to increase or decrease tension. Tighten screws.

Note: When new code drum is installed, refine spring tension toward 17 ozs.



FEED PAWL

Requirement


Answer back in stop position, clearance between feed pawl engaging surface and tooth on code drum.

Min 0.005 inch---Max 0.015 inch

To Adjust

Position feed pawl with its mounting nut loosened. Tighten nut and recheck.


2.04 Feed Mechanism (continued)

FEED PAWL SPRING

Requirement

With answer back in stop position and code drum in place

Min 1/2 oz---Max 1-1/2 oz
to start pawl moving.

ECCENTRIC STOP POSITION

Requirement

With feed bail in lowest position of its travel opposite low part of its cam resting on eccentric stop, clearance between feed cam and feed bail.


Min 0.055 inch---Max 0.075 inch

To Adjust

Rotate eccentric with its mounting screw loosened.

Note: Keep high part of eccentric away from pivot point of feed bail to insure that eccentric stop bears against flat surface of bail extension and not on its lower edge.

2.05 Feed Mechanism (continued)



CODE DRUM CONTACT WIRE SPRING

Requirement


Min 1 oz.---Max 2 oz
to start contact wire moving away from
common terminal.

CODE DRUM DETENT SPRING

Requirement

Min 9 oz---Max 11 oz
to start detent moving.

2.06 Relay Brackets and Contacts



MOTOR HOLD AND RELAY PULL-UP CON-
TACT BRACKET

Requirement


Trip magnet armature released clearance
between insulator on contact and armature
—Min 0.015 inch---Max 0.030 inch

To Adjust

Position contact bracket with its mounting
screw loosened.

Note: Keep bracket parallel with armature.

2.07 Relay Brackets and Contacts (continued)

MOTOR HOLD AND RELAY PULL-UP CONTACT


Note: The adjustments are made before installation into the unit and should be checked or remade only in case of malfunction attributed to maladjustment of the contacts. If it should become necessary to remake the adjustment, the following procedure should be followed. Remove contact assembly with bracket from magnet yoke.

Requirements

- (1) The gap between the contacts in the unoperated position should be
Min 0.020 inch---Max 0.030 inch
- (2) Min 25 grams---Max 50 grams to close both contacts.

To Adjust

Bend contacts to meet requirements.

NONREPEAT RELAY

Note: These adjustments are made before installation into the unit and should be checked or remade only in case of malfunction attributed to maladjustment. If it should become necessary to remake the adjustment, the following procedure should be followed:

(1) Requirement

With armature released, clearance between armature stops and frame
Min 0.015 inch---Max 0.025 inch

(2) Requirement

The "make" contact (double) should close a minimum of 0.003 inch before the "break" (single) contact opens.

(3) Requirement

Minimum of 15 grams to move the swinger away from the stationary contacts when the armature is in either the operated or unoperated position.

(4) Requirement


The minimum contact gap should be 0.012 inch.

To Adjust

Bend armature stops, stationary contacts, and contact springs to meet requirements.

2.08 Distributor Brushes

DISTRIBUTOR BRUSH HOLDER



Requirement

With answer back in stop position, the pointer on the brush holder should point to the feeder of the stop segment.

To Adjust

Turn brush holder clockwise with its mounting screw loosened.

CAUTION: DO NOT TURN BRUSH HOLDER COUNTERCLOCKWISE. DAMAGE TO BRUSHES MAY RESULT.

BRUSH HOLDER SPRING


Requirement

New brush


Min 10-1/2 oz---Max 13-1/2 oz

Brush worn to 1/4 in. length

Min 7-1/2 oz---Max 10-1/2 oz
to start outer brush spring moving.



2.09 Gear Backlash




GEAR BACKLASH - SELF-CONTAINED UNIT

Requirements

- (1) Backlash between motor pinion and drive gear should be
Min 0.004 inch---Max 0.008 inch
- (2) Adjust for minimum noise.

To Adjust

With motor mounting and nut plate screws friction tight, position motor until requirements are met.



Note: The following adjustment is made after intermediate gear assembly to typing unit gear and motor pinion gear adjustments have been made.

GEAR BACKLASH - RO, KSR

Requirement

Backlash, at point of minimum clearance between answer-back main shaft gear and outboard gear of intermediate gear assembly on base
Min 0.004 inch---Max 0.008 inch
gauge by feel.

To Adjust

With two nut plate screws (B) friction tight, loosen four answer-back mounting screws (A). Move answer back all the way toward front in mounting holes. Tighten four answer-back mounting screws to friction tight and loosen two nut plate screws. Position assembly. Tighten all screws.

2.10 Gear Backlash (continued)

