Please do not upload this copyright pdf document to any other website. Breach of copyright may result in a criminal conviction.

This Acrobat document was generated by me, Colin Hinson, from a document held by the Henlow Signals Museum, believed to be out of copyright. It is presented here (for free) and this pdf version of the document is my copyright in much the same way as a photograph would be. If you believe the document to be under other copyright, please contact me.

The document should have been downloaded from my website https://blunham.com/Radar, or any mirror site named on that site. If you downloaded it from elsewhere, please let me know (particularly if you were charged for it). You can contact me via my Genuki email page: https://www.genuki.org.uk/big/eng/YKS/various?recipient=colin

You may not copy the file for onward transmission of the data nor attempt to make monetary gain by the use of these files. If you want someone else to have a copy of the file, point them at the website. (https://blunham.com/Radar). Please do not point them at the file itself as it may move or the site may be updated.

It should be noted that most of the pages are identifiable as having been processed by m	It should be	noted that	most of the	pages are	identifiable as	having been	processed by me
--	--------------	------------	-------------	-----------	-----------------	-------------	-----------------

I put a lot of time into producing these files which is why you are met with this page when you open the file.

In order to generate this file, I need to scan the pages, split the double pages and remove any edge marks such as punch holes, clean up the pages, set the relevant pages to be all the same size and alignment. I then run Omnipage (OCR) to generate the searchable text and then generate the pdf file.

Hopefully after all that, I end up with a presentable file. If you find missing pages, pages in the wrong order, anything else wrong with the file or simply want to make a comment, please drop me a line (see above).

It is my hope that you find the file of use to you personally – I know that I would have liked to have found some of these files years ago – they would have saved me a lot of time!

Colin Hinson

In the village of Blunham, Bedfordshire.



Operating & Service Instructions



PYE TELECOMMUNICATIONS LTD . CAMBRIDGE . ENGLAND

DESCRIPTION

The Pye Radiotelephone Test Meter Type TMl is an instrument designed for servicing Vanguard and Cambridge Pye Radiotelephone equipments. It enables performance checks to be readily carried out in both the transmitters and receivers. It is supplied with a 9-lead cableform terminating in a suitable plug for test sockets in the Vanguard equipment, test leads terminating in insulated test prods, a two-range diode probe and a retractable built-in antenna.

When not in use, the 9-way plug, test prods and the diode probe are stowed in the lower compartment and the selector switch set to TRANSIT.

OPERATION

All tests on the Vanguard and Cambridge should be carried out in accordance with the instructions given in the relevant sections of the Service Manuals supplied with these equipments. The Test Meter TM1 has a sensitivity of 20,000 Ω /volt and covers the following ranges:-

0 to 15.0 volts

0 to 2,5 volts

0 to 50μA

DIODE PROBE


This has two ranges (Xl and X10) selected by the double pole changeover switch on the meter front panel and is used with the selector switch at the position marked PROBE.

TEST PRODS

These are used in conjunction with the selector switch, the appropriate meter ranges being selected by plugging the prod leads into the correct sockets on the front panel.

ANTENNA

This must be extended as required and used with the selector switch in the position marked RADIATION, for radiation tests. The test meter should be placed adjacent to the transmitter antenna; it should not be connected to the equipment.



Circuit Diagram

AM & FM VANGUARD TESTS

Insert the 9-way plug into the appropriate test socket on the front panel of Vanguard transceiver and carry out the tests with the selector switch in positions indicated below:-

AM & FM CAMBRIDGE

For checks on Cambridge equipment the normal position of the selector switch is at METER + -; this may be changed to - + to reverse the meter reading without disconnecting the test prods. This is particularly useful for centring the discriminator.

The leads are plugged into the appropriate sockets to give the required meter range.

RECEIVERS

Selector Switch Position	AM Receiver *PT B10 AM To measure:-	AM Receiver AM 25 B To measure:-	FM Receiver FM 25 B To measure:-
1	Ig - V2 01	not used	not useđ
2	not used	not used	not used
3	not used	not used	not used
4	not used	not used	not used
5	not used	not used	not used
6	not used	net used	not used
7	Id MR1	Id MR1	not used

^{*} Home Office version

TRANSMITTERS

Selector Switch Position	AM Transmitter *PT Bl0 AM To measure:-	AM Transmitter AM 25 B To measure:-	FM Transmitter FM 25 B To measure:-
1	Ig - V201	not used	Ig - V602
2	Ig - V202	Ig - V201	Ig - V603
3	Ig - V203a	Ig - V202a	Ig - V604a
4	Ig - V203b	Ig - V202b	Ig - V604b
5	Ig - V204	Ig - V203	Ig - V605
6	not used	not used	Ig - V606
7	Ia - V204	Ia - V203	Ia - V6 06

PARTS LIST

Code		ELECTRICAL		
C1/2/3 R1 R2 R3 R4 R5 R6 R7 M1	1n 250kΩ 47kΩ 47Ω 1. 2kΩ 1. 2kΩ 8. 2kΩ 10kΩ	Disc ceramic Meter Germanium diode HG101	$300V + 80-20\%$ $\frac{1}{4}W \pm 1\%$ $\frac{1}{4}W \pm 1\%$ $\frac{1}{2}W \pm 10\%$ $\frac{1}{4}W \pm 1\%$ $\frac{1}{3}W \pm 10\%$ $\frac{1}{2}W \pm 10\%$ $\frac{1}{2}W \pm 10\%$ $\frac{1}{2}W \pm 10\%$	660433 NC25471 NC47371 NG47030 NC12271 NG12230 NG82230 NG10430 9633930 9634166
MRZ		Germanium diode OA81		707302

MISCELLANEOUS

PLI	Test plug	9633983
SKT1/2/3	Test sockets (black)	9633932
SKT4	Test socket (red)	9633931
AE	Antenna (telescopic)	9633261
SA	Selector switch	9660049
SB	Double Pole Changeover switch	9634000

MECHANICAL

Test lead assy red	9637214
Test lead assy black	9637215
Probe assy.	9637216
Cast box assy.	9637247
Front panel assy.	9637 250
Cable assy.	963 725 l
4-way tagstrip assy.	963 325 4
Escutcheon plate	96 08378
Knob	9633960
Handle	9633968
Capacitor clip	704792
Terminal knob	9 634006
Eyelet	QK52103/A
Clip	700650
Components retaining clip	9608409